




User Manual



ASMB-920IR

ADVANTECH

Enabling an Intelligent Planet

Copyright

The documentation and the software included with this product are copyrighted 2012 by Advantech Co., Ltd. All rights are reserved. Advantech Co., Ltd. reserves the right to make improvements in the products described in this manual at any time without notice. No part of this manual may be reproduced, copied, translated or transmitted in any form or by any means without the prior written permission of Advantech Co., Ltd. Information provided in this manual is intended to be accurate and reliable. However, Advantech Co., Ltd. assumes no responsibility for its use, nor for any infringements of the rights of third parties, which may result from its use.

Acknowledgements

Intel and Pentium are trademarks of Intel Corporation.

Microsoft Windows and MS-DOS are registered trademarks of Microsoft Corp.

All other product names or trademarks are properties of their respective owners.

Product Warranty (2 years)

Advantech warrants to you, the original purchaser, that each of its products will be free from defects in materials and workmanship for two years from the date of purchase.

This warranty does not apply to any products which have been repaired or altered by persons other than repair personnel authorized by Advantech, or which have been subject to misuse, abuse, accident or improper installation. Advantech assumes no liability under the terms of this warranty as a consequence of such events.

Because of Advantech's high quality-control standards and rigorous testing, most of our customers never need to use our repair service. If an Advantech product is defective, it will be repaired or replaced at no charge during the warranty period. For out-of-warranty repairs, you will be billed according to the cost of replacement materials, service time and freight. Please consult your dealer for more details.

If you think you have a defective product, follow these steps:

1. Collect all the information about the problem encountered. (For example, CPU speed, Advantech products used, other hardware and software used, etc.) Note anything abnormal and list any onscreen messages you get when the problem occurs.
2. Call your dealer and describe the problem. Please have your manual, product, and any helpful information readily available.
3. If your product is diagnosed as defective, obtain an RMA (return merchandise authorization) number from your dealer. This allows us to process your return more quickly.
4. Carefully pack the defective product, a fully-completed Repair and Replacement Order Card and a photocopy proof of purchase date (such as your sales receipt) in a shippable container. A product returned without proof of the purchase date is not eligible for warranty service.
5. Write the RMA number visibly on the outside of the package and ship it prepaid to your dealer.

A Message to the Customer

Advantech Customer Services

Each and every Advantech product is built to the most exacting specifications to ensure reliable performance in the harsh and demanding conditions typical of industrial environments. Whether your new Advantech equipment is destined for the laboratory or the factory floor, you can be assured that your product will provide the reliability and ease of operation for which the name Advantech has come to be known.

Your satisfaction is our primary concern. Here is a guide to Advantech's customer services. To ensure you get the full benefit of our services, please follow the instructions below carefully.

Technical Support

We want you to get the maximum performance from your products. So if you run into technical difficulties, we are here to help. For the most frequently asked questions, you can easily find answers in your product documentation. These answers are normally a lot more detailed than the ones we can give over the phone.

So please consult this manual first. If you still cannot find the answer, gather all the information or questions that apply to your problem, and with the product close at hand, call your dealer. Our dealers are well trained and ready to give you the support you need to get the most from your Advantech products. In fact, most problems reported are minor and are easily solved over the phone.

In addition, free technical support is available from Advantech engineers every business day. We are always ready to give advice on application requirements or specific information on the installation and operation of any of our products.

Declaration of Conformity

FCC

This device complies with the requirements in part 15 of the FCC rules:

Operation is subject to the following two conditions:

- This device may not cause harmful interference
- This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this device in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his/her own expense. The user is advised that any equipment changes or modifications not expressly approved by the party responsible for compliance would void the compliance to FCC regulations and therefore, the user's authority to operate the equipment.

Caution! *There is a danger of a new battery exploding if it is incorrectly installed. Do not attempt to recharge, force open, or heat the battery. Replace the battery only with the same or equivalent type recommended by the manufacturer. Discard used batteries according to the manufacturer's instructions.*



Peripheral Compatibility

Category	Advantech PN	Vendor	Part Description	Remarks
MB	ASMB-920IR-00A1E	Advantech	Support BMC module & SAS HDD	
	ASMB-920-00A1E	Advantech	Basic sku	
CPU	96MPXE-2.1-20M20T	Intel	Xeon E5-2658/2.1GHz/8cores	95W
	96MPXE-2.0-15M20T	Intel	Xeon E5-2620/2.0GHz/6cores	95W
	96MPXE-1.8-20M20T	Intel	Xeon E5-2648L/1.8GHz/8cores	70W
SATA3 HDD	96HD500G-ST-SG7K12	SEAGATE	500G 3.5" SATA 7KRPM 16M	ST500DM002
	96HD1000G-ST-SG7K6	SEAGATE	1T 3.5" SATA 7KRPM 64M	ST1000DM003
	96HD2000G-ST-SG7K2	SEAGATE	2T 3.5" SATA 7KRPM 64M	ST2000DM001
SAS2 HDD	96HD300G-SS-SG15K1	SEAGATE	300G 3.5" SAS 15KRPM 6G 16M(G)	ST3300657SS
Memory/ REG	96D3-1G1333ER-AP	Apacer	1G DDR3-1333 240PIN REG 128X8 ELP(G)	78.01GCC.AF0
	96D3-2G1333ER-AP	Apacer	2G DDR3-1333 240PIN REG 128X8 ELP(G)	78.A1GDR.4200C
	96D3-4G1333ER-AP1	Apacer	4G DDR3-1333 240PIN REG 256X8 HYX(G)	78.B1GDR.4201C
	TBD	Transcend	1G DDR3-1333 240PIN ECC REG	TS128MKR72V3U
	TBD	Transcend	2G DDR3-1333 240PIN ECC REG	TS256MKR72V3U
	TBD	Transcend	4G DDR3-1333 240PIN ECC REG	TS512MKR72V3N
	TBD	ADATA	4G DDR3-1333 240PIN ECC REG	EL931C18
	TBD	ADATA	8G DDR3-1333 240PIN ECC REG	EL931D18
	TBD	InnoDisk	4G DDR3-1333 240PIN ECC REG	ACT4GHR72P8H 1333H
	TBD	InnoDisk	8G DDR3-1333 240PIN ECC REG	ACT8GHR72Q4H 1333S
Memory/ ECC	TBD	InnoDisk	16G DDR3-1066 240PIN ECC REG	ACT16GHR72Q4J 1333S
	TBD	Transcend	1G DDR3-1333 240PIN ECC	TS128MLK72V3U
	TBD	Transcend	2G DDR3-1333 240PIN ECC	TS256MLK72V3U
	TBD	Transcend	4G DDR3-1333 240PIN ECC	TS512MLK72V3N
	TBD	InnoDisk	4G DDR3-1333 240PIN ECC	M3CN-4GHJ3C09
Memory/ UNB	TBD	ADATA	4G DDR3-1333 240PIN ECC	EL031C18
	TBD	ADATA	4G DDR3-1600 240PIN	EL64C1C16
UNB	96D3-4G1333NN-TR	Transcend	4G DDR3-1333 240PIN	TS512MLK64V3N
Cooler	1960055362N001	AVC	Cooler I-LGA2011 S-95W 90x90x65.65-SS 12V0.42A-5 Z6UR41J001	
Option Card	PCA-AUDIO-HDA1E	Advantech	Audio card	
Daughter Board (PME)	ASMB-FF208-02A1E	Advantech	ASMB-FF208(Only support PCI-E Gen1 signal)	2x PCI-Ex16(x8 link)
	ASMB-FF3PX-12A1E	Advantech	ASMB-FF3PX	2x PCI-X + 1x PCI
	ASMB-FF20F-02A1E	Advantech	ASMB-FF20F(Only support PCI-E Gen2 signal)	2x PCI-Ex16(x16 link)

Initial Inspection

Before installing motherboard, please make sure that the following materials have been shipped:

- 1 x ASMB-920IR EATX motherboard
- 1 x ASMB-920IR Startup Manual
- 1 x Driver CD (user manual is included)
- 2 x Serial ATA HDD data cables
- 1 x I/O port bracket
- 2 x SATA power cable
- 1 x Warranty card

If any of these items are missing or damaged, contact distributor or sales representative immediately. We have carefully inspected the ASMB-920IR mechanically and electrically before shipment. It should be free of marks and scratches and in perfect working order upon receipt. When unpacking the ASMB-920IR, check it for signs of shipping damage. (For example, damaged box, scratches, dents, etc.) If it is damaged or it fails to meet the specifications, notify our service department or local sales representative immediately. Also notify the carrier. Retain the shipping carton and packing material for inspection by the carrier. After inspection, we will make arrangements to repair or replace the unit.

Order Information

Part Number	HDD	Expansion Slot	IPMI
ASMB-920IR-00A1E	6 SATA + 8 SAS/SATA	2 x PCIe x16	Yes
ASMB-920-00A1E	6 SATA	2 x PCIe x16	-

Contents

Chapter 1 Overview.....1

1.1	Introduction	2
1.2	Features	2
1.3	Specifications	3
	Table 1.1: Specifications	3
1.4	Board Layout, Jumpers and Connectors.....	5
	Figure 1.1 Board Layout	5
	Figure 1.2 Rear I/O	6
	Table 1.2: Onboard LAN LED Color Definition	6
	Table 1.3: Jumpers.....	6
	Table 1.4: Connectors	6
	Table 1.5: Onboard LED.....	8
1.5	Block Diagram.....	8
	Figure 1.3 Block Diagram	8
1.6	System Memory	8
1.7	Memory Installation Procedures.....	9
1.8	Processor Installation.....	9

Chapter 2 Connections.....11

2.1	Introduction	12
2.2	USB Ports and LAN Ports (USB0~USB10/LAN1/LAN2/IPMI_LAN1)	12
2.3	VGA Connector	13
2.4	Serial Ports (COM1/COM2)	14
2.5	PS2 Keyboard and Mouse Connectors (KBMS1)	15
2.6	CPU Fan Connector (CPU FAN0/FAN1)	16
	Table 2.1: CPU FAN0 Pin Definition.....	16
2.7	System Fan Connector (SYS FAN0/FAN1/FAN2)	17
	Table 2.2: SYS FAN0 Pin Definition	17
2.8	Front Panel Connector (JFP1)	18
2.8.1	Power LED (JFP1).....	18
	Table 2.3: ATX Power Supply LED Status	18
2.8.2	External Speaker (JFP1 pins 10, 12, 14, 16).....	18
2.8.3	HDD LED Connector (JFP1 Pins 5 & 7)	19
2.8.4	Reset Connector (JFP1 Pins 2 & 4).....	19
2.8.5	Case Open (JFP1 Pins 6 & 8).....	19
2.9	SATA SGPIO (SATA_SGPIO1)	20
2.10	SAS SGPIO (SGPIO_1/SGPIO_2)	21
2.11	Front Panel LAN Indicator Connector (LANLED1).....	22
2.12	Serial ATA Interface (SATA0 ~ 5)	23
2.13	PCIe x16 Expansion Slots (PCIEX16_SLOT6/PCIEX16_SLOT7).....	24
2.14	Serial Attached SCSI Interface (SAS0 ~ 7).....	25
2.15	Auxiliary Power Connector (ATX_8P_PQ/ATX_8P_P1/ATX_P24).....	26
2.16	HD Audio Interface Connector (AUDIO1)	27
2.17	LPC Connector (LPC1) for Optional TPM Module	28
2.18	Clear CMOS Connector (JCMOS1)	29
2.19	PMBUS Connector (PMBUS1).....	30
2.20	Front Panel SMBUS Connector (SMBUS1)	31
2.21	IPMI Module Connector (IPMI1)*	32
2.22	PME Module Slot*	33
2.23	VOLT1 Connector	34

Chapter	3	AMI BIOS.....	35
	3.1	Introduction	36
	3.2	BIOS Setup	37
	3.2.1	Main Menu	37
	3.2.2	Advanced BIOS Features Setup.....	37
	3.2.3	Chipset.....	54
	3.2.4	Server Management	61
	3.2.5	Boot	62
	3.2.6	Security.....	63
	3.2.7	Save & Exit	64
Chapter	4	Chipset Software Installation Utility	65
	4.1	Before Beginning	66
	4.2	Introduction	66
	4.2.1	Main Menu	66
	4.3	Windows XP / Windows 2003 / Windows 2008 / Windows 7 Driver Setup. 67	
Chapter	5	VGA Setup	69
	5.1	Introduction	70
	5.2	Windows Series Driver Setup	70
Chapter	6	Lan Configuration	71
	6.1	Introduction	72
	6.2	Features.....	72
	6.3	Installation.....	72
	6.4	Windows Series Driver Setup (LAN).....	72
Appendix A		Programming the Watchdog Timer .	75
	A.1	Watchdog Timer Overview.....	76
	A.2	Programming the Watchdog Timer	76
		Table A.1: Watchdog Timer Registers.....	78
	A.2.1	Example Programs	78
Appendix B		I/O Pin Assignments	83
	B.1	USB Header (USB45, USB67, USB89)	84
		Table B.1: USB Header (USB45,USB67,USB89,USB1011)	84
	B.2	VGA Connector (VGA1).....	84
		Table B.2: VGA Connector (VGA1)	84
	B.3	RS-232 Interface (COM2).....	85
		Table B.3: RS-232 Interface (COM2)	85
	B.4	PS/2 Keyboard and Mouse Connector (KBMS1).....	85
		Table B.4: Keyboard and Mouse Connector (KBMS1)	85
	B.5	External Keyboard Connector (KBMS2)	86
		Table B.5: External Keyboard Connector (KBMS2).....	86
	B.6	System Fan Power Connector (SYSFAN0~2)	86
		Table B.6: Fan Power Connector (SYSFAN0/SYSFAN1/ SYSFAN2).....	86
	B.7	Power LED (JFP1).....	86

	Table B.7: Power LED (JFP1).....	86
B.8	External Speaker Connector (JFP1)	87
	Table B.8: External Speaker Connector (JFP1).....	87
B.9	Reset Connector (JFP1)	87
	Table B.9: Reset Connector (JFP1).....	87
B.10	HDD LED Connector (JFP1).....	87
	Table B.10:HDD LED Connector (JFP1)	87
B.11	ATX Soft Power Switch (JFP1)	88
	Table B.11:ATX Soft Power Switch (JFP1).....	88
B.12	Front panel SMBus Connector (SMBUS1).....	88
B.13	USB/LAN Ports (LAN1_USB01 and LAN2_USB23)	88
	Table B.12:USB Port.....	88
	Table B.13:Giga LAN 10/100/1000 Base-T RJ-45 Port	89
B.14	Audio Connector (AUDIO1).....	89
	Table B.14:Front Panel Audio Connector (FPAUD1).....	89
B.15	8-pin Alarm Board Connector (VOLT1).....	89
	Table B.15:8-pin Alarm Board Connector (VOLT1)	89
B.16	Case Open Connector (JFP1).....	90
	Table B.16:Case Open Connector (JFP1)	90
B.17	Front Panel LAN LED Connector (LANLED1).....	90
	Table B.17:LAN LED Connector (LANLED1).....	90

Chapter 1

Overview

1.1 Introduction

The ASMB-920IR serverboard is the most advanced Intel Xeon E5-2600 series board for server-grade IPC applications that require high-performance computing. The serverboard supports an Intel Xeon E5-2600 series processor and DDR3 1066/1333/1600 MHz memory up to 128GB.

ASMB-920IR provides dual PCIe x16 slots which can support two high performance graphic cards.

For multi-interface expansion card applications, ASMB-920IR can support three additional expansion slots with a PME board.

In addition, the ASMB-920IR has dual Gigabit Ethernet LAN ports via a dedicated PCIe x1 bus, which offer bandwidth up to 500 MB/s, eliminating network bottlenecks.

The ASMB-920IR has a third RJ-45 LAN connector which is dedicated for IPMI function allowing remote control

High reliability and outstanding performance makes ASMB-920IR the ideal platform for industrial server/networking applications.

By using the Intel C600 chipset, the ASMB-920IR offers a variety of features such as 4 onboard SATA II, and 2 onboard SATA III interfaces; it provides software RAID 0, 1, 10 and 5 (Windows only); and it has 11 USB 2.0 connectors.

ASMB-920IR has an embedded LSI SAS controller SAS2008, which can support 8 SAS/SATA HDDs and RAID 0,1,1E.

These powerful I/O capabilities ensure even more reliable data storage capabilities and high-speed I/O peripheral connectivity.

Note!



1. *IPMI module sold separately.*
2. *4 rear USB connectors; 3 USB pin headers onboard (2 ports from one header); 1 type-A USB connector onboard.*

1.2 Features

General

- **Intel next generation dual processor platform:** ASMB-920IR supports two Intel E5-2600 series Quad/Six/Eight core processors.
- **High performance I/O capability:** Dual Gigabit LAN via PCIe x1 bus, two PCIe X16 slots, 6 SATA connectors, 11 USB 2.0 ports, and 8 SAS/SATA connectors.
- **Standard EATX form factor with industrial features:** ASMB-920IR provides industrial features like long product lifecycle, reliable operation under wide temperature range, watchdog timer, etc.
- **SAS hard drive support:** Embedded LSI SAS2008 controller which can support eight SAS/SATA HDD with RAID 0,1,1E.
- **IPMI 2.0 support:** ASMB-920IR equipped with Aspeed 2300 BMC chip supports IPMI 2.0 (Intelligent Platform Management Interface 2.0) via dedicated LAN port.
- **KVM over IP:** ASMB-920IR KVM over IP function allows remote control of system through your own computer.

1.3 Specifications

Table 1.1: Specifications

Processor	
CPU	<ul style="list-style-type: none"> ■ Dual Intel LGA2011 XEON processor sockets ■ Supports Intel XEON E5-2600 series processor with Quad/Six/Eight cores ■ Supports TDP 70W/95W Intel XEON E5-2600 series processor
Processor Bus	QPI bus speed 8 GT/s
System Memory	
Memory Capacity	<ul style="list-style-type: none"> ■ Xeon processor supports DDR3 memory bus ■ Total 8 memory slots provided ■ 4 channels per processor, 1 memory slot per channel ■ Supports up to 128 GB memory
Memory Type	Supports DDR3 1066/1333/1600 MHz ECC Registered / ECC Unbuffered / Non-ECC Unbuffered Modules.
DIMM Sizes	Each memory slot supports 1GB, 2GB, 4GB, 8GB, 16GB memory size modules.
Memory Voltage	1.35V & 1.5 V
Error Detection	<ul style="list-style-type: none"> ■ Corrects single-bit errors ■ Detects double-bit errors (using ECC memory)
On-Board Devices	
Chipsets	Intel C602J PCH provide 8xPCIe Gen2 lanes for SAS, VGA, Network.
Network Controllers	<ul style="list-style-type: none"> ■ 1 x Intel 82574L Gigabit Ethernet Controller connected to C600 through PCIe Gen2 Lane. ■ 1x Intel 82579LM Gigabit PHY connected to C600 MAC. ■ Above network Supports 10BASE-T, 100BASE-TX, and 1000BASE-T, RJ-45 output. ■ 1 x 10/100BASE RealTek 8201EL-VB PHY connected to AST2300 for dedicated IPMI/iKVM.
VGA	ASPEED AST2300 controller with 64 MB VGA memory provides basic 2D VGA function.
Super I/O	Nuvoton NCT6776F chip provide motherboard keyboard mouse, RS-232, and hardware monitor functions.
SAS (IR SKU Only)	<ul style="list-style-type: none"> ■ LSI SAS2008 provides 8 x SAS 6 Gb/s ports and support RAID 0, 1, 1E. ■ LSI SAS2008 connected to C600 occupies 4 x PCIe-Gen2 lanes. ■ 8 x SAS ports are controlled by LSI SAS2008 chip with standard 7-pin connector.
BMC (IR SKU Only)	ASPEED AST2300 provides IPMI & iKVM function.
Input / Output	
Serial ATA	<ul style="list-style-type: none"> ■ Total 6 x SATA ports, 2 ports provide 6 Gb/s bandwidth, 4 ports provide 3 Gb/s bandwidth. ■ RAID 0, 1, 5, 10 support (Windows only).
LAN	<ul style="list-style-type: none"> ■ 2 x RJ-45 LAN ports (10/100/1000 Base-T LAN). ■ 1 x RJ-45 Dedicated IPMI LAN port(10/100 Base-T) for IPMI only, there is no regular LAN function (IR SKU Only).

Table 1.1: Specifications

USB	<ul style="list-style-type: none"> ■ 4 x USB ports at rear window. ■ 3 x USB internal headers (6 ports). ■ 1 x internal Type-A USB port.
VGA	<ul style="list-style-type: none"> ■ 1 x VGA port
Keyboard / Mouse	<ul style="list-style-type: none"> ■ PS/2 keyboard and mouse connector at rear window.
Serial Port / Header	<ul style="list-style-type: none"> ■ 1 x internal header (2 x 5 2.5 mm pitch) for UART port ■ 1 x external DB9 UART
Power Connector	
System Power	1 x 24-pin SSI EPS 12 V power connector (Input 12 V, 5 V, 3.3 V, 5 V standby)
CPU Power	2 x 8 pin SSI EPS 12 V power connector for CPU & Memory power (12V)
Expansion Slots	
PCI-Express	<ul style="list-style-type: none"> ■ 2 x PCI-E x16 slot (Gen2 x16 Link) (Slot 6 and 7) ■ 1 x PME slot*
System BIOS	
BIOS Type	64 Mb SPI Flash EEPROM with AMI BIOS
PC Health Monitoring	
Voltage	Monitors for CPU Cores, +3.3 V, +5 V, +12 V, +5 V Standby, VBAT
FAN	<ul style="list-style-type: none"> ■ Two 4-pin heads for CPU cooler and three 4-pin headers for system fan. ■ All fans with tachometer status monitoring ■ Thermal control for all fan connectors
Temperature	<ul style="list-style-type: none"> ■ Monitoring for CPU *2 (PECI) ■ Monitoring for System (SIO)
Other Features (Case Open)	<ul style="list-style-type: none"> ■ Chassis intrusion detection ■ Chassis Intrusion header
Operating Environment / Compliance	
RoHS	RoHS Compliant 6/6 Pb Free
Environmental Spec.	<ul style="list-style-type: none"> ■ Operating Temperature: 0 to 40°C ■ Non-operating Temperature: -10 to 70°C ■ Operating Relative Humidity: 0% to 90% (non-condensing) ■ Non-operating Relative Humidity: 5% to 95% (non-condensing)

Note! If you need more expansion slots, apply a PME to ASMB-920IR.



PMEs have different types and design flexibility for different interface expansion cards. Please visit Advantech official website to see what kind of PME can be used.

1.4 Board Layout, Jumpers and Connectors

Connectors on the ASMB-920IR are linked to external devices such as hard disk drives. In addition, ASMB-920IR has a number of jumpers that are used to configure system for specific applications.

The tables below list the functions of each jumper and connector. Later sections in this chapter give instructions for setting jumpers. Chapter 2 gives instructions for connecting external devices to ASMB-920IR.




Figure 1.1 Board Layout




Figure 1.2 Rear I/O

Table 1.2: Onboard LAN LED Color Definition

10/100/1000 Mbps LAN Link/Activity LED Scheme

		LAN1 & LAN2		IPMI LAN1	
		Left LED	Right LED	Left LED	Right LED
10 Mbps	Link	Off	Green	Amber	-
	Active	Off	Blinking green		Blinking green
100 Mbps	Link	Amber	Green	Amber	-
	Active	Amber	Blinking green		Blinking green
1000 Mbps	Link	Green	Green	-	-
	Active	Green	Blinking green		
No Link		Off	Off	Off	Off

Table 1.3: Jumpers

Label	Function
JCMOS1	CMOS Clear
JME1	ME update

Table 1.4: Connectors

Label	Function
ATX_8P_P0	SSI EPS 12 V auxiliary power connector (for CPU0) and memory
ATX_8P_P1	SSI EPS 12 V auxiliary power connector (for CPU1) and memory
ATX_24P_P1	SSI EPS 24-pin main power connector (for system)
COM2	Serial port: RS-232
CPU0	Intel LGA2011 CPU0 socket
CPU1	Intel LGA2011 CPU1 socket
CPUFAN0	CPU0 fan connector (4-pin)

Table 1.4: Connectors

CPUFAN1	CPU1 fan connector (4-pin)
DIMMA1	Channel A DIMM1 of CPU0
DIMMB1	Channel B DIMM1 of CPU0
DIMMC1	Channel C DIMM1 of CPU0
DIMMD1	Channel D DIMM1 of CPU0
DIMME1	Channel E DIMM1 of CPU1
DIMMF1	Channel F DIMM1 of CPU1
DIMMG1	Channel G DIMM1 of CPU1
DIMMH1	Channel H DIMM1 of CPU1
JFP1	Front panel pin header connector
AUDIO1	HD audio Interface connector
IPMI1	IPMI connector
LANLED1	LAN1/2 LED extension connector
LPC1	LPC port for debug & TPM module
PCIEX16_SLOT6	PCIe x16 slot
PCIEX16_SLOT7	PCIe x16 slot
SAS0	SAS0 hard drive connector(IR SKU only)
SAS1	SAS1 hard drive connector(IR SKU only)
SAS2	SAS2 hard drive connector(IR SKU only)
SAS3	SAS3 hard drive connector(IR SKU only)
SAS4	SAS4 hard drive connector(IR SKU only)
SAS5	SAS5 hard drive connector(IR SKU only)
SAS6	SAS6 hard drive connector(IR SKU only)
SAS7	SAS7 hard drive connector(IR SKU only)
SATA0	Serial ATA0 hard drive connector(SATA III)
SATA1	Serial ATA1 hard drive connector(SATA III)
SATA2	Serial ATA2 hard drive connector(SATA II)
SATA3	Serial ATA3 hard drive connector(SATA II)
SATA4	Serial ATA4 hard drive connector(SATA II)
SATA5	Serial ATA5 hard drive connector(SATA II)
SAS_SGPIO_1	SGPIO connector for SAS0 ~ SAS3(IR SKU only)
SAS_SGPIO_2	SGPIO connector for SAS4 ~ SAS7(IR SKU only)
SYS FAN0	System fan connector (4-pin)
SYS FAN1	System fan connector (4-pin)
SYS FAN2	System fan connector (4-pin)
USB45	USB port 4, 5
USB67	USB port 6, 7
USB89	USB port 8, 9
USB10	USB port 10 (Type-A)

Table 1.5: Onboard LED

LED	Description	LED Definition	
5V_LED1	Power on LED	Off: Power off	On (Green): System is On
5VSB_LED1	Standby LED	Off: No input AC Power	On (Green): System is ON, in sleep mode, or in soft-off mode
LED1	SAS error LED (IR SKU Only)	On (Red): Failed to initial SAS controller	
LED2	SAS heartbeat LED (IR SKU Only)	Blinking (Green) : Controller is working normally	
LED3	BMC heartbeat LED (IR SKU Only)	Blinking (Green) : Controller is working normally	

1.5 Block Diagram




Figure 1.3 Block Diagram

1.6 System Memory

ASMB-920IR has eight 240-pin memory slots for DDR3 1066/1333/1600 MHz memory modules with maximum capacity of 128 GB (Maximum 16 GB for each DIMM).

ASMB-920IR supports registered DIMMs or unbuffered DIMM with ECC / Non-ECC memory module.

1.7 Memory Installation Procedures

To install DIMMs, make sure that two handles of the DIMM socket are in the "open" position. The handles lean outward. Slowly slide the DIMM module along the plastic guides on both ends of the socket, and then press the DIMM module right down into the socket, until you hear a click. This is when the two handles have automatically locked the memory module into the correct position of the DIMM socket. To remove the memory module, just push both handles outward, and the memory module will be ejected by the mechanism in the socket.

Quantity of memory installed	Single CPU Installed (CPU0)				Dual CPU Installed (CPU0 & CPU1)							
	1	2	3	4	1	2	3	4	5	6	7	8
DIMMA-1	V	V	V	V	V	V	V	V	V	V	V	V
DIMMB-1	V	V	V	V	V	V	V	V	V	V	V	V
DIMMC-1	V	V	V	V	V	V	V	V	V	V	V	V
DIMMD-1	V	V	V	V	V	V	V	V	V	V	V	V
DIMME-1					V	V	V	V	V	V	V	V
DIMMF-1					V	V	V	V	V	V	V	V
DIMMG-1					V	V	V	V	V	V	V	V
DIMMH-1					V	V	V	V	V	V	V	V

1.8 Processor Installation

The ASMB-920IR is designed for dual LGA2011, Intel E5-2600 series Xeon processor.

Chapter 2

Connections

2.1 Introduction


You can access most of the connectors from the top of the board as it is being installed in the chassis. If you have a number of cards installed, you may need to partially remove a card to make all the connections.

2.2 USB Ports and LAN Ports (USB0~USB10/LAN1/LAN2/IPMI_LAN1)


The USB ports comply with USB specification rev. 2.0. Transmission rates of up to 480 Mbps and fuse protection are supported. The USB interface can be disabled in the system BIOS setup.

The ASMB-920IR is equipped with two high-performance 1000 Mbps Ethernet LANs. They are supported by all major network operating systems. The RJ-45 jacks on the rear plate provide convenient 1000Base-T operation.

ASMB-920IR is also equipped with the additional 100 Mbps Ethernet LAN (IPMI_LAN1 Port) which is shared with IPMI for system management.




Example: Set USB45 (pin definitions are the same as USB67 & USB89)




2.3 VGA Connector

The ASMB-920IR includes a VGA interface that can drive conventional CRT and LCD displays.




2.4 Serial Ports (COM1/COM2)

The ASMB-920IR offers 2 serial ports (One on the rear panel and one onboard).



2.5 PS2 Keyboard and Mouse Connectors (KBMS1)

Two 6-pin mini-DIN connectors (KBMS1) on the rear panel of the motherboard provide PS/2 keyboard and mouse connections.



2.6 CPU Fan Connector (CPU FAN0/FAN1)

If a fan is used, this connector supports cooling fans that draw up to 500 mA (6 W).




Table 2.1: CPU FAN0 Pin Definition

	CPU FAN0	CPU FAN1
1	GND	GND
2	+12V	+12V
3	CPU0_TACH	CPU1_TACH
4	CPU0_PWM	CPU0_PWM

2.7 System Fan Connector (SYS FAN0/FAN1/FAN2)






Table 2.2: SYS FAN0 Pin Definition

	SYS FAN0	SYS FAN1	SYS FAN2
1	GND	GND	GND
2	+12V	+12V	+12V
3	FAN0_TACH	FAN1_TACH	FAN2_TACH
4	FAN0_PWM	FAN1_PWM	FAN2_PWM


2.8.3 HDD LED Connector (JFP1 Pins 5 & 7)

You can connect an LED to connector JFP1 to indicate when the HDD is active.




2.8.4 Reset Connector (JFP1 Pins 2 & 4)

Many computer cases offer the convenience of a reset button.





2.8.5 Case Open (JFP1 Pins 6 & 8)



A Chassis Intrusion header is located at JFP1 on the motherboard. Attach the appropriate cable from the chassis to be informed of a chassis intrusion when the chassis is opened.



2.9 SATA SGPIO (SATA_SGPI01)





2.10 SAS SGPIO (SGPIO_1/SGPIO_2)



SAS_SGPIO_1		SAS_SGPIO_2	
1	SIOCLK1	1	SIOCLK2
2	NC	2	NC
3	SIOEND1	3	SIOEND2
4	SIOEND1	4	SIOEND2
5	SIODIN1	5	SIODIN2


2.11 Front Panel LAN Indicator Connector (LANLED1)



1	LAN1_LED0_ACT	2	LAN2_LED1_ACT
3	VCC3_LAN1LED	4	VCC3_LAN2LED
5	LAN1_LED1_1000M	6	LAN2_LED2_1000
7	LAN1_LED2_100M	8	LAN2_LED0_100
9	VCC3	10	NC


2.12 Serial ATA Interface (SATA0 ~ 5)

ASMB-920IR features two serial ATA III (SATA 0 & SATA 1) interfaces (up to 600 MB/s) and four serial ATA II (SATA 2 ~ SATA 5) interfaces (up to 300 MB/s) which ease cabling to hard drives with thin and long cables.




2.13 PCIe x16 Expansion Slots (PCIEX16_SLOT6/ PCIEX16_SLOT7)

The ASMB-920IR provides two PCIe x16 slots (two PCIe x16 links).




2.14 Serial Attached SCSI Interface (SAS0 ~ 7)

The ASMB-920IR provides eight SAS II ports.





2.15 Auxiliary Power Connector (ATX_8P_PQ/ ATX_8P_P1/ATX_P24)





- Note!**
1. Please use a power supply which is of SSI type; minimum output should be at least 760W.
 2. ATX 8P_P0 & ATX 8P_P1 & ATX 24P_P1 sockets should be connected with power supply, otherwise ASMB-920IR will not boot up normally.

2.16 HD Audio Interface Connector (AUDIO1)



1	+5 V_AUD	2	GND
3	ACZ_SYNC	4	ACZ_BITCLK
5	ACZ_SDOUT	6	ACZ_SDIN0
7	ACZ_SDIN1	8	ACZ_RST#
9	+AC_12V	10	GND
11	GND	12	NC



2.17 LPC Connector (LPC1) for Optional TPM Module



1	CLK_33M_TPM	2	LPC_AD1
3	PLTRST_LPC	4	LPC_AD0
5	LPC_FRAME	6	+3.3 V
7	LPC_AD3	8	GND
9	LPC_AD2	10	SMB_SCL_LPC
11	SERIRQ_PCH	12	SMB_SDA_LPC
13	+5V_AUX	14	+5V

2.18 Clear CMOS Connector (JCMOS1)



Setting jumper from pin 1_2 to pin 2_3, then back to pin 1_2 to reset CMOS data.



JCMOS1
PH_3x1V_2.54mm


1	SRTC_RST_PCH
2	RTC_RST_PCH
3	GND

2.19 PMBUS Connector (PMBUS1)




1	SMB_SCL_PM
2	SMB_SDA_PM
3	SMB_ALT_PM
4	GND
5	+3.3V

2.20 Front Panel SMBUS Connector (SMBUS1)




SMBUS1



1	+3.3V_AUX
2	SMB_SCL_FRU
3	SMB_SDA_FRU
4	GND


2.21 IPMI Module Connector (IPMI1)*



Note! To enable IPMI, you must buy an IPMI module made by Advantech.




2.22 PME Module Slot*


**Note!**

1. To enable PME slot, install 2nd processor in CPU1 socket.
2. PMEs have different types and design flexibility for different interface expansion cards. Please visit Advantech's website to see what kind of PME you can use.

2.23 VOLT1 Connector



VOLT1 connects to the alarm board of Advantech chassis. These alarm boards give warnings if a power supply or fan fails, if the chassis overheats, or if the backplane malfunctions.




1	5VSB	5	+5V
2	GND	6	+3.3V
3	GND	7	-12V
4	-5V	8	+12V

Chapter 3

AMI BIOS

3.1 Introduction

AMI BIOS has been integrated into many motherboards for over a decade. In the past, people often referred to the AMI BIOS setup menu as BIOS, BIOS setup or CMOS setup. With the AMI BIOS Setup program, you can modify BIOS settings and control the special features of your computer. The Setup program uses a number of menus for making changes and turning the special features on or off. This chapter describes the basic navigation of the ASMB-920IR setup screens.



AMI's BIOS ROM has a built-in Setup program that allows users to modify the basic system configuration. This type of information is stored in battery-backed up CMOS so it retains the Setup information when the power is turned off.

Note! *The BIOS setup screens shown in this chapter are just for reference only, it may not exactly match what you see on your display devices.*



3.2 BIOS Setup

3.2.1 Main Menu

Press to enter AMI BIOS CMOS Setup Utility, the Main Menu will appear on the screen. Use arrow keys to select among the items and press <Enter> to accept or enter the sub-menu.




The Main BIOS setup screen has two main frames. The left frame displays all the options that can be configured. Grayed-out options cannot be configured; options in blue can be. The right frame displays the key legend. Above the key legend is an area reserved for a text message. When an option is selected in the left frame, it is highlighted in white. Often a text message will accompany it.

3.2.1.1 System Time / System Date


Use this option to change the system time and date. Highlight System Time or System Date using the <Arrow> keys. Enter new values through the keyboard. Press the <Tab> key or the <Arrow> keys to move between fields. The date must be entered in MM/DD/YY format. The time must be entered in HH:MM:SS format.

3.2.2 Advanced BIOS Features Setup

Select the Advanced tab from the ASMB-920IR setup screen to enter the Advanced BIOS setup screen. You can select any of the items in the left frame of the screen, such as CPU configuration, to go to the sub menu for that item. You can display an Advanced BIOS Setup option by highlighting it using the <Arrow> keys. All Advanced BIOS Setup options are described in this section. The Advanced BIOS Setup screens are shown below. The sub menus are described on the following pages.



3.2.2.1 PCI Subsystem Settings




- **PCI ROM Priority**

Default setting is EFI Compatible mode. In case PCI legacy Option ROM required, you can change the mode from EFI to Legacy.


- **Above 4G Decoding**
Enables or Disables 64-bit capability. Devices to be decoded in Above 4G Address Space (Only if System Supports 64bit PCI Decoding).
- **PCI Latency Timer**
Value in units of PCI clocks for PCI device latency timer register.
- **VGA Palette Snoop**

3.2.2.2 ACPI Settings



- **Enable ACPI Auto Configuration**
"Enable or disable" ACPI Auto Configuration.
- **Enable Hibernation**
"Enable or disable" Hibernation.
- **ACPI Sleep State**
Specifies the ACPI sleep state when the system enters suspend.
- **Lock Legacy Resources**
"Enabled" or "Disabled" Lock Legacy Resources.

3.2.2.3 Trusted Computing




- **TPM Support**
"Enable or disable" TPM Support. Purchase Advantech LPC TPM module to enable TPM function. P/N: PCA-TPM-00A1E.

3.2.2.4 WHEA Support




- **WHEA Support**
"Enable or disable" Windows Hardware Error Architecture.


3.2.2.5 CPU Configuration



■ Socket 0 CPU Information



- Socket 1 CPU Information



- **Hyper-threading**

Enable or disable Intel Hyper Threading technology.

- **Active Processor Core**

Select how many processor cores to activate when using a dual or quad core processor.

- **Limit CPUID Maximum**

Set this item to [Enable] allows legacy operating systems to boot even without support for CPUs with extended CPUID functions.

- **Execute Disable Bit**

This item specifies the Execute Disable Bit Feature. The settings are Enabled and Disabled. The Optimal and Fail-Safe default setting is Enabled. If Disabled is selected, the BIOS forces the XD feature flag to always return to 0.

- **Hardware Prefetcher**

Hardware Prefetcher is a technique that fetches instructions and/or data from memory into the CPU cache memory well before the CPU needs it, so that it can improve the load-to-use latency. Set to enable or disable.

- **Adjacent Cache Line Prefetch**

The Adjacent Cache-Line Prefetch mechanism, like automatic hardware prefetch, operates without programmer intervention. When enabled through the BIOS, two 64- byte cache lines are fetched into a 128-byte sector, regardless of whether the additional cache line has been requested or not. Set to enable or disable.


- **DCU Streamer Prefetch**

- **DCU IP Prefetcher**


- **Intel Virtualization Technology**

This feature is used to enable or disable the Intel Virtualization Technology (IVT) extension. It allows multiple operating systems to run simultaneously on the same system. It does this by creating virtual machines, each running its own x86 operating system.

■ CPU Power Management Configuration



Power technology default is “Energy Efficient”.




User can set “EIST”, “P-STATE”, “C3”, “C6”, “C7”, “Package C State limit” under “Custom” Mode.

3.2.2.6 Runtime Error Logging



User can Enable or disable Runtime Error Logging Support.

3.2.2.7 SATA Configuration



- **SATA Mode**
Configured as IDE/RAID/AHCI or Disabled.

■ **IDE Mode**


Serial-ATA Controller 0

This item appears only when SATA Mode item set to [IDE Mode]. Set to [Enhanced] to support two SATA 6.0 Gb/s and four SATA 3.0 Gb/s devices. Set to [Compatible] when using Windows 98/NT/2000/MS-DOS. Up to four SATA devices are supported by controller 0 and two SATA devices are supported by controller 1 when under these operating systems.

Serial-ATA Controller 1


This item appears only when SATA Mode item to [IDE Mode] is set. Set to [Enhanced] to support two SATA 3.0 Gb/s devices.

■ **Serial-ATA Controller 1**




Set to [AHCI Mode] to have the SATA hard disk drives use the AHCI (Advanced Host Controller Interface). The AHCI allows the onboard storage driver to enable advanced Serial ATA features that increases storage performance on random workloads by allowing the drive to internally optimize the order of commands.

■ **RAID Mode**



Set to [RAID Mode] to create a RAID configuration from the SATA hard disk drives.

3.2.2.8 USB Configuration




■ Legacy USB Support

This is for supporting USB device under a legacy OS such as DOS. When choosing "AUTO", the system will automatically detect if any USB device is plugged into the computer and enable USB legacy mode when a USB device is plugged and disable USB legacy mode when no USB device is plugged.

- **EHCI Hand-off**
Enables or disables supporting an OS without EHCI hand-off feature.
- **USB Transfer Time-out**
Selects the USB transfer time-out value. [1,5,10,20sec]
- **Device Reset Time-out**
Selects the USB device reset time-out value. [10,20,30,40 sec]
- **Device Power-up Delay**
This item appears only when Device power-up delay item is set to [manual].
- **Mass Storage Devices**
This item appears only when plugging in a USB flash device. User can choose "Auto", "Floppy", "Forced FDD", "Hard Disk" and "CD-ROM" to simulate USB flash device.


3.2.2.9 Super I/O Configuration





Serial Port 0 Configuration


- **Serial Port**
To “enable” or “disable” Serial Port 0.
- **Change Settings**
To select an optimal setting for serial port 0.




Serial Port 1 Configuration

- **Serial Port**
To “enable” or “disable” Serial Port 1.
- **Change Settings**
To select an optimal setting for serial port 1.

3.2.2.10 H/W Monitor




- **Case Open Warning**
Enable/Disable the Chassis Intrusion monitoring function. When enabled and the case is opened, the warning message will show in post screen.
- **CPU Warning Temperature**
Set the CPU warning temperature threshold. When the system reaches the warning temperature, the speaker will beep.
- **ACPI Shutdown Temperature**
Set the ACPI shutdown temperature threshold. When the system reaches the shutdown temperature, it will be automatically shut down by ACPI OS to protect the system from overheat damage.
- **Watchdog Timer**
Enable and Disable the watchdog timer function.
- **Smart Fan Mode Configuration**
When set to manual mode, fan duty setting can be set; the range is from 0~255, default setting is 127.




3.2.2.11 Serial Port Console Redirection

■ Console Redirection

To "Enable or disable" console redirection feature,



■ Console Redirection Settings



■ Terminal Type

Select a terminal type to be used for console redirection.
Options available: VT100/VT100+/ANSI /VT-UTF8.

■ Bits Per Second

Select the baud rate for console redirection.
Options available: 9600/19200/57600/115200.

■ Parity

A parity bit can be sent with the data bits to detect some transmission errors.
Even: parity bit is 0 if the num of 1's in the data bits is even.
Odd: parity bit is 0 if num of 1's the data bits is odd.
Mark: parity bit is always 1. Space: Parity bit is always 0.
Mark and Space Parity do not allow for error detection.
Options available: None/Even/Odd/Mark/Space.

■ Stop Bits

Stop bits indicate the end of a serial data packet. (A start bit indicates the beginning).
The standard setting is 1 stop bit. Communication with slow devices may require more than 1 stop bit.
Options available: 1/2.

■ Flow Control

Flow control can prevent data loss from buffer overflow. When sending data, if the receiving buffers are full, a 'stop' signal can be sent to stop the data flow. Once the buffers are empty, a 'start' signal can be sent to re-start the flow. Hardware flow control uses two wires to send start/stop signals.
Options available: None/Hardware RTS/CTS.

■ Recorder Mode

When this mode enabled, only text will be send. This is to capture Terminal data.


Options available: Enabled/Disabled.

- **Legacy OS Redirection Resolution**

On Legacy OS, the number of Rows and Columns supported redirection.

Options available: 80x24/80X25.

- **Putty Keypad**



- **Console Redirection Setting**

- **Out-of-Band Mgmt Port**

To select the com port user would like to set for having console redirection feature.

- **Terminal Type**

Set as "VT100", "VT100+", "VT-UTF8", or "ANSI". "VT-UTF8" is the default setting.


- **Bits Per Second**

To select serial port transmission. Speed must be matched on the other side. It can be set as "9600", "19200", "57600", or "115200". "115200" is the default setting.


- **Flow Control**

Flow control can prevent data loss from buffer overflow. It can be set as "None", "Hardware RTS/CTS", or "Software Xon/Xoff". "None" is the default setting.

3.2.3 Chipset



3.2.3.1 North Bridge



Numa

Enable/Disable non uniform memory access (NUMA)

Patrol Scrub

Enable/Disable patrol scrub feature

Demand Scrub


Enable/Disable demand scrub feature

Data Scrambling

Enable/Disable data scrambling

Device Tagging

Enable/Disable device tagging


IOH Configuration

- **Intel I/OAT**
Enable/Disable Intel I/O Acceleration Technology function.
- **DCA Support**
Enable/Disable Direct Cache Access Support
- **VGA Priority**
Determines priority between onboard and 1st offboard video device found.
- **IOU 0 PCIe port Bifurcation control**
 - IOU2 - PCIe Port(PCIEX16_SLOT6)**
Functions visible based on this setting : x4x4x4x4 (Fun 0/1/2/3 visible)
x4x4x8 (Fun 0/2/3 visible), x8x4x4(Fun 0/1/2 visible), x8x8 (Fun 0/2 visible),
x16 (Fun 0 visible)
 - PORT 2A Link Speed**
Select Target Link Speed Gen1, Gen2, Gen3
 - IOU2 - PCIe Port(PCIEX16_SLOT7)**
Functions visible based on this setting : x4x4x4x4 (Fun 0/1/2/3 visible)
x4x4x8 (Fun 0/2/3 visible), x8x4x4(Fun 0/1/2 visible), x8x8 (Fun 0/2 visible),
x16 (Fun 0 visible)
 - PORT 3A Link Speed**
Select Target Link Speed Gen1, Gen2, Gen3
- **IOU 1 PCIe port Bifurcation control**

IOU2 - PCIe Port(PCIE_PME1)

Functions visible based on this setting : x4x4x4x4 (Fun 0/1/2/3 visible)
x4x4x8 (Fun 0/2/3 visible), x8x4x4(Fun 0/1/2 visible), x8x8 (Fun 0/2 visible),
x16 (Fun 0 visible), Auto (Auto detect PME board)


Intel(R) VT for Directed I/O Configuration



Intel VT-d

Enable/Disable Intel Virtualization Technology for Directed I/O

QPI Configuration




- **Isoc**
Enable/Disable Isoc
- **QPI Link Speed Mode**
Select the QPI link speed as either the Fast mode or Slow Mode.
- **QPI Link Frequency Select**
Allows for selecting the QPI Link frequency.
- **QPI Link0p**
Enable/Disable QPI Link0p
- **QPI Link1**
Enable/Disable QPI Link1


Compatibility RID

Support for Compatibility Revision ID (CRID). Functionality mentioned in BIOS spec

DIMM Information




3.2.3.2 South Bridge



- **PCH Compatibility RID**
Enable/Disable PCH Compatibility Revision ID (CRID) Functionality.
- **SMBus Controller**
Enable/Disable SMBus controller


- **Restore AC Power Loss**
Specify what state to go to when power is re-applied after a power failure (G3 state).
- **SLP_S4 Assertion Stretch Enable**
Enable/Disable SLP_S4 Assertion Stretch function
- **Onboard SAS Oprom**
Enable/Disable onboard LSI SAS option rom
- **Onboard SATA RAID Oprom**
Enable/Disable onboard SATA RAID option rom if Launch Storage Oprom is enabled.
- **Azalia HD Audio**
Enable/Disable Azalia HD audio function
- **High Precision Timer**
Enable/Disable high precision timer function

LAN Configuration




- **LAN1 Controller**
Enable/Disable Intel 82579LM Controller support.
- **LAN1 PXE Oprom**
Enable/Disable Boot option for Intel 82579LM controller.
- **LAN1 Wake up from S5**
Enable/Disable Intel 82579LM controller wake up from S5 support.
- **LAN2 Controller**
Enable/Disable Intel 82574L Controller support
- **LAN2 PXE Oprom**
Enable/Disable Boot option for Intel 82574L controller.
- **LAN2 Wake up From S5**
Enable/Disable Intel 82574L controller wake up from S5 support.

USB Configuration




- **All USB Devices**
Enable/Disable all USB devices
- **EHCI Controller 1**
Enable/Disable USB 2.0 (EHCI) support
- **EHCI Controller 2**
Enable/Disable USB 2.0 (EHCI) support
- **USB Port 0 ~ 10**
Enable/Disable USB 0 ~ 10 port

3.2.3.3 ME Subsystem



3.2.4 Server Management



- **BMC Support**
Enable/Disable interfaces to communicate with BMC
- **Wait for BMC**

If enabled, motherboard will wait 60 seconds until BMC module boots up completely, after which normal BIOS post screen will be displayed.
If disabled, motherboard will not wait for BMC module's response.

3.2.4.1 BMC Self Test Log

- **Erase Log**
Erase log options
- **When Log is Full**
Select the action to be taken when log is full


3.2.4.2 System Event Log

- **SEL Components**
Enable/Disable all features of system event logging during boot
- **Erase SEL**
Choose options for erasing SEL
- **When SEL is Full**
Choose options for reactions to a full SEL
- **Log EFI Status Codes**
Disable the logging of EFI status codes or log only error code or only progress code or both

3.2.4.3 BMC Network Configuration


- **Configuration Address Source**
Select to configure LAN channel parameters statically or dynamically (by BMC). Unspecified option will not modify any BMC network parameters during BIOS phase.

3.2.5 Boot




- **Setup Prompt Timeout**
Number of seconds to wait for setup activation key. 16(0x10) means indefinite waiting.
- **Bootup NumLock State**
Select the keyboard NumLock state
- **Quit Boot**
Enable/Disable quiet boot option
- **Interrupt 19 Capture**
Enable: Allows option ROMs to trap Int 19
- **Boot Option**
Sets the system boot priorities

3.2.6 Security



3.2.7 Save & Exit



- **Save Changes and Exit**
Exit system setup after saving the changes
- **Discard Changes and Exit**
Exit system setup without saving any changes
- **Save Changes and Reset**
Reset the system after saving changes
- **Discard Changes and Reset**
Reset system setup without saving any changes
- **Save Changes**
Save changes done so far to any of the setup options
- **Discard Changes**
Discard changes done so far to any of the setup options
- **Restore Defaults**
Restore/Load default values for all the setup options
- **Save as User Defaults**
Save the changes done so far as user defaults
- **Restore User Defaults**
Restore the user default to all the setup options

Chapter 4

Chipset Software
Installation Utility

4.1 Before Beginning

To facilitate the installation of the enhanced display drivers and utility software, read the instructions in this chapter carefully. The drivers for the ASMB-920IR are located on the software installation CD.

Before beginning, it is important to note that most display drivers need to have the relevant software application already installed on the system prior to installing the enhanced display drivers. In addition, many of the installation procedures assume that you are familiar with both the relevant software applications and operating system commands. Review the relevant operating system commands and the pertinent sections of your application software's user manual before performing the installation.

4.2 Introduction

4.2.1 Main Menu

The Intel Chipset Software Installation (CSI) utility installs the Windows INF files that outline to the operating system how the chipset components will be configured. This is needed for the proper functioning of the following features:

- Core PCI PnP services
- Serial ATA interface support
- USB 1.1/2.0 support (USB 2.0 driver needs to be installed separately for Windows 98)
- Identification of Intel chipset components in the Device Manager

Note! *The files on the software installation CD are compressed. Do not attempt to install the drivers by copying the files manually. You must use the supplied SETUP program to install the drivers.*



Note! *The chipset driver is used for the following versions of Windows, and it has to be installed before installing all the other drivers:*




<i>Windows Server 2008 Enterprise Edition R2</i>	<i>x64</i>
<i>Windows Server 2008 Enterprise Edition</i>	<i>x86 & x64</i>
<i>Windows Server 2003 Enterprise Edition SP2</i>	<i>x86 & x64</i>
<i>Windows 7(Ultimate SP1)</i>	<i>x86 & x64</i>
<i>Windows Vista SP2</i>	<i>x86 & x64</i>
<i>Windows XP SP3 Professional*</i>	<i>x86 & x64</i>
<i>Windows XP Embedded SP3 (WES2009)</i>	<i>x86</i>

Note! *It is necessary to update all the latest Microsoft hotfix files when using this OS.*




4.3 Windows XP / Windows 2003 / Windows 2008 / Windows 7 Driver Setup

1. Insert the driver CD into your system's CD-ROM drive. When the folder is displayed, move the mouse cursor over the folder "01_Intel INF". Find the executable in the CSI folder, click to install the driver.



2. Click setup to execute program.



Chapter 5

VGA Setup


5.1 Introduction

Install the ASPEED VGA driver to enable this function, which includes the following features:

- 32bit 2D graphics engine on board for normal use.
- 64MB Ram for this chip, the highest resolution is 1920x1200.

5.2 Windows Series Driver Setup

Insert the driver CD into your system's CD-ROM drive. When the folder is displayed, navigate to the "02_Graphic chip" folder and click the executable file to complete the installation of the drivers for OS that you need.



Note! Please use Windows 2008 server R2(WinS08R2) VGA driver version for Windows 7 VGA driver



Chapter 6

Lan Configuration

6.1 Introduction

The ASMB-920IR has two Gigabit Ethernet LAN connections via dedicated PCI Express x1 lanes: GbE LAN1 - Intel 82579LM; GbE LAN2 - Intel 82574L. They offer bandwidth of up to 500 MB/sec, eliminating the bottleneck of network data flow and incorporating Gigabit Ethernet at 1000 Mbps.

6.2 Features


- 10/100/1000Base-T Ethernet controller
- 10/100/1000Base-T triple-speed MAC
- Full duplex at 10, 100, or 1000 Mbps and half duplex at 10 or 100 Mbps
- Wake-on-LAN (WOL) support
- PCIe x1 host interface


6.3 Installation

The integrated Intel gigabit Ethernet controller supports all major network operating systems. However, the installation procedure varies with different operating systems. In the following sections, refer to the one that provides the driver setup procedure for the operating system you are using.

6.4 Windows Series Driver Setup (LAN)

1. Insert the driver CD into your system's CD-ROM drive. Select folder "03_Lan chip" then click the proper Lan driver for the OS.





Appendix **A**

Programming the
Watchdog Timer

The ASMB-920IR's watchdog timer can be used to monitor system software operation and take corrective action if the software fails to function within the programmed period. This section describes the operation of the watchdog timer and how to program it.

A.1 Watchdog Timer Overview

The watchdog timer is built in to the super I/O controller NCT6776F. It provides the following functions for user programming:

- Can be enabled and disabled by user program
- Timer can be set from 1 to 255 seconds or 1 to 255 minutes
- Generates an interrupt or resets signal if the software fails to reset the timer before time-out

A.2 Programming the Watchdog Timer

The I/O port address of the watchdog timer is 2E (hex) and 2F (hex). 2E (hex) is the address port. 2F (hex) is the data port. You must first write an address value into address port 2E (hex), and then write/read data to/from the assigned register through data port 2F (hex).




Table A.1: Watchdog Timer Registers

Address of register (2E)	Read/Write	Value (2F) & description
87 (hex)	-	Write this address to I/O address port 2E (hex) twice to unlock the NCT6776F
07 (hex)	write	Write 08 (hex) to select register of watchdog timer.
30 (hex)	write	Write 01 (hex) to enable the function of the watchdog timer. Disabled is set as default.
F5 (hex)	write	Set seconds or minutes as units for the timer. Write 0 to bit 3: set seconds as counting unit. [default]. Write 1 to bit 3: set minutes as counting unit. Write 1 to bit 4: Watchdog timer count mode is 1000 times faster. If bit 3 is 0, the count mode is 1/1000 seconds mode. If bit 3 is 1, the count mode is 1/1000 minutes mode.
F6 (hex)	write	0: stop timer [default] 01 ~ FF (hex): The amount of the count, in seconds or minutes, depends on the value set in register F5 (hex). This number decides how long the watchdog timer waits for strobe before generating an interrupt or reset signal. Writing a new value to this register can reset the timer to count with the new value.
F7 (hex)	read/write	Bit 6: Write 1 to enable keyboard to reset the timer, 0 to disable.[default] Bit 5: Write 1 to generate a timeout signal immediately and automatically return to 0. [default=0] Bit 4: Read status of watchdog timer, 1 means timer is "timeout".
AA (hex)	-	Write this address to I/O port 2E (hex) to lock NCT6776F.

A.2.1 Example Programs

Enable watchdog timer and set 10 seconds as the timeout interval

```

;-----
Mov dx,2eh ; Unlock NCT6776F
Mov al,87h
Out dx,al
Out dx,al
;-----
Mov al,07h ; Select registers of watchdog timer
Out dx,al
Inc dx
In al,dx
Or al,08h
Out dx,al
;-----
Dec dx; Enable the function of watchdog timer
Mov al,30h
Out dx,al
Inc dx
Mov al,01h
Out dx,al
;-----

```



```

Dec dx ; Set second as counting unit
Mov al,0f5h
Out dx,al
Inc dx
In al,dx
And al,not 08h
Out dx,al
;-----
Dec dx ; Set timeout interval as 10 seconds and start counting
Mov al,0f6h
Out dx,al
Inc dx
Mov al,10; 10 minutes
Out dx,al
;-----
Dec dx ; lock NCT6776F
Mov al,0aah
Out dx,al
Enable watchdog timer and set 5 minutes as the timeout interval
;-----
Mov dx,2eh ; unlock NCT6776F
Mov al,87h
Out dx,al
Out dx,al
;-----
Mov al,07h ; Select registers of watchdog timer
Out dx,al
Inc dx
In al,dx
Or al,08h
Out dx,al
;-----
Dec dx ; Enable the function of watchdog timer
Mov al,30h
Out dx,al
Inc dx
Mov al,01h
Out dx,al
;-----
Dec dx ; Set minute as counting unit
Mov al,0f5h
Out dx, al
Inc dx
In al,dx
Or al, 08h

```

```

Out dx,al
;-----
Dec dx ; Set timeout interval as 5 minutes and start counting
Mov al,0f6h
Out dx,al
Inc dx
Mov al,5; 5 minutes
Out dx,al
;-----
Dec dx ; lock NCT6776F
Mov al,0aah
Out dx,al
Enable watchdog timer to be reset by mouse
;-----
Mov dx,2eh ; unlock NCT6776F
Mov al,87h
Out dx,al
Out dx,al
;-----
Mov al,07h ; Select registers of watchdog timer
Out dx,al
Inc dx
Mov al,08h
Out dx,al
;-----
Dec dx ; Enable the function of watchdog timer
Mov al,30h
Out dx,al
Inc dx
In al,dx
Or al,01h
Out dx,al
;-----
Dec dx ; Enable watchdog timer to be reset by mouse
Mov al,0f7h
Out dx,al
Inc dx
In al,dx
Or al,80h
Out dx,al
;-----
Dec dx ; lock NCT6776F
Mov al,0aah
Out dx,al
Enable watchdog timer to be reset by keyboard

```

```

;-----
Mov dx,2eh ; unlock NCT6776F
Mov al,87h
Out dx,al
Out dx,al
;-----
Mov al,07h ; Select registers of watchdog timer
Out dx,al
Inc dx
Mov al,08h
Out dx,al
;-----
Dec dx ; Enable the function of watchdog timer
Mov al,30h
Out dx,al
Inc dx
Mov al,01h
Out dx,al
;-----
Dec dx ; Enable watchdog timer to be strobed reset by keyboard
Mov al,0f7h
Out dx,al
Inc dx
In al,dx
Or al,40h
Out dx,al
;-----
Dec dx ; lock NCT6776F
Mov al,0aah
Out dx,al
Generate a time-out signal without timer counting
;-----
Mov dx,2eh ; unlock NCT6776F
Mov al,87h
Out dx,al
Out dx,al
;-----
Mov al,07h ; Select registers of watchdog timer
Out dx,al
Inc dx
Mov al,08h
Out dx,al
;-----
Dec dx ; Enable the function of watchdog timer
Mov al,30h

```

```
Out dx,al
Inc dx
In al,dx
Or al,01h
Out dx,al
;-----
Dec dx ; Generate a time-out signal
Mov al,0f7h
Out dx,al ;Write 1 to bit 5 of F7 register
Inc dx
In al,dx
Or al,20h
Out dx,al
;-----
Dec dx ; lock NCT6776F
Mov al,0aah
Out dx,al
```

Appendix **B**

I/O Pin Assignments

B.1 USB Header (USB45, USB67, USB89)




Table B.1: USB Header (USB45,USB67,USB89,USB1011)

Pin	Signal	Pin	Signal
1	USB_VCC5	2	USB_VCC5
3	USB_D-	4	USB_D-
5	USB_D+	6	USB_D+
7	GND	8	GND
9	Key	10	N/C

B.2 VGA Connector (VGA1)




Table B.2: VGA Connector (VGA1)

Pin	Signal	Pin	Signal
1	RED	9	VCC
2	GREEN	10	GND
3	BLUE	11	N/C
4	N/C	12	SDT
5	GND	13	H-SYNC
6	GND	14	V-SYNC
7	GND	15	SCK
8	GND		

B.3 RS-232 Interface (COM2)




Table B.3: RS-232 Interface (COM2)

Pin	Signal
1	DCD
2	RXD
3	TXD
4	DTR
5	GND
6	DSR
7	RTS
8	CTS
9	RI

B.4 PS/2 Keyboard and Mouse Connector (KBMS1)



Table B.4: Keyboard and Mouse Connector (KBMS1)

Pin	Signal
1	KB DATA
2	N/C
3	GND
4	KB VCC
5	KB CLK
6	N/C
7	M_DATA
8	N/C
9	GND
10	M_VCC
11	M_CLK
12	N/C

B.5 External Keyboard Connector (KBMS2)




Table B.5: External Keyboard Connector (KBMS2)

Pin	Signal
1	KB CLK
2	KB DATA
3	MS DATA
4	GND
5	VCC
6	MS CLK

B.6 System Fan Power Connector (SYSFAN0~2)




Table B.6: Fan Power Connector (SYSFAN0/SYSFAN1/SYSFAN2)

Pin	Signal
1	GND
2	+12 V
3	DETECT
4	PWM

B.7 Power LED (JFP1)




Table B.7: Power LED (JFP1)

Pin	Function
9	LED power (3.3 V)
11	NC
13	Ground

B.8 External Speaker Connector (JFP1)




Table B.8: External Speaker Connector (JFP1)

Pin	Function
10	SPK_VCC
12	SPK_OBS
14	SPK_BUZ
16	SPK_OUT

B.9 Reset Connector (JFP1)




Table B.9: Reset Connector (JFP1)

Pin	Signal
2	RESET
4	GND

B.10 HDD LED Connector (JFP1)




Table B.10: HDD LED Connector (JFP1)

Pin	Signal
5	HDD_LED+
7	HDD_LED-

B.11 ATX Soft Power Switch (JFP1)





Table B.11: ATX Soft Power Switch (JFP1)


Pin	Signal
1	PWR-BTN
3	GND

B.12 Front panel SMBus Connector (SMBUS1)



1	+3.3V_AUX
2	SMB_SCL_FRU
3	SMB_SDA_FRU
4	GND

B.13 USB/LAN Ports (LAN1_USB01 and LAN2_USB23)



LAN1_USB01 LAN2_USB23

Table B.12: USB Port

Pin	Signal	Pin	Signal
1	VCC_DUAL	3	Data0+
2	Data0-	4	GND

Table B.13: Giga LAN 10/100/1000 Base-T RJ-45 Port


Pin	Signal	Pin	Signal
1	MID0+	5	MID2+
2	MID0-	6	MID2+
3	MID1+	7	MID3+
4	MID1-	8	MID3+

B.14 Audio Connector (AUDIO1)

**Table B.14: Front Panel Audio Connector (FPAUD1)**

Pin	Signal	Pin	Signal
1	ACZ_VCC	2	GND
3	ACZ_SYNC	4	ACZ_BITCLK
5	ACZ_SDOUT	6	ACZ_SDIN0
7	ACZ_SDIN1	8	ACZ_RST
9	ACZ_12V	10	GND
11	GND	12	N/C

B.15 8-pin Alarm Board Connector (VOLT1)

**Table B.15: 8-pin Alarm Board Connector (VOLT1)**

Pin	Signal	Pin	Signal
1	5VSB	5	+5V
2	GND	6	+3.3V
3	GND	7	-12V
4	-5V	8	+12V

B.16 Case Open Connector (JFP1)



Table B.16: Case Open Connector (JFP1)

Pin	Signal
6	CASEOP
8	GND

B.17 Front Panel LAN LED Connector (LANLED1)




Table B.17: LAN LED Connector (LANLED1)

Pin	Signal	Pin	Signal
1	LAN1/3_LED0_ACT	2	LAN2/4_LED1_ACT
3	VCC3_LAN1LED	4	VCC3_LAN2LED
5	LAN1/3_LED1_1000M	6	LAN2/4_LED2_1000
7	LAN1/3_LED2_100M	8	LAN2/4_LED0_100
9	VCC3	10	N/C

ADVANTECH

Enabling an Intelligent Planet

www.advantech.com

Please verify specifications before quoting. This guide is intended for reference purposes only.

All product specifications are subject to change without notice.

No part of this publication may be reproduced in any form or by any means, electronic, photocopying, recording or otherwise, without prior written permission of the publisher.

All brand and product names are trademarks or registered trademarks of their respective companies.

© Advantech Co., Ltd. 2012