

SOM-2355 SOM-144 Module

**AMD Geode LX800 CPU Module
with CPU, VGA/LVD & LAN**

User Manual

Copyright Notice

This document is copyrighted, 2007, by Advantech Co., Ltd. All rights are reserved. The original manufacturer reserves the right to make improvements to the products described in this manual at any time without notice. No part of this manual may be reproduced, copied, translated or transmitted in any form or by any means without the prior written permission of the original manufacturer. Information provided in this manual is intended to be accurate and reliable. However, the original manufacturer assumes no responsibility for its use, nor for any infringements upon the rights of third parties which may result from its use.

Acknowledgements

SOM and DTOS are trademarks of Advantech Co., Ltd.

AMD is a trademark of Advanced Micro Devices, Inc.

Award is a trademark of Award Software International, Inc.

Cyrix is a trademark of Cyrix Corporation.

IBM, PC/AT, PS/2 and VGA are trademarks of International Business Machines Corporation.

Intel and Pentium are trademarks of Intel Corporation.

Microsoft Windows® is a registered trademark of Microsoft Corp.

RTL is a trademark of Realtek Semiconductor Co., Ltd.

C&T is a trademark of Chips and Technologies, Inc.

UMC is a trademark of United Microelectronics Corporation.

Winbond is a trademark of Winbond Electronics Corp.

STPC is a trademark of SGS Thomson Corp.

For more information on this and other Advantech products, please visit our website at:

<http://www.advantech.com>

For technical support and service, please visit our support website at:

<http://www.advantech.com/support>

This manual is for the SOM-2355

Part No. 2006235500

1st Edition

Printed in Taiwan

Mar. 2007

Packing List

Before you begin installing your card, please make sure that the following materials have been shipped:

- SOM-2355 System On Module CPU module
- CD-ROM or Disks for utility, drivers, and manual (in PDF format)

If any of these items are missing or damaged, contact your distributor or sales representative immediately.

Additional Information and Assistance

1. Visit the Advantech web site at www.advantech.com where you can find the latest information about the product.
2. Contact your distributor, sales representative, or Advantech's customer service center for technical support if you need additional assistance.

Please have the following information ready before you call:

- Product name and serial number
- Description of your peripheral attachments
- Description of your software (operating system, version, application software, etc.)
- A complete description of the problem
- The exact wording of any error messages

Declaration of Certification

CE

This product has passed the CE test for environmental specifications. Test conditions for passing included the equipment being operated within an industrial enclosure. In order to protect the product from being damaged by ESD (Electrostatic Discharge) and EMI leakage, we strongly recommend the use of CE-compliant industrial enclosure products.

FCC Class A

Note: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Caution! *There is a danger of a new battery exploding if it is incorrectly installed. Do not attempt to recharge, force open, or heat the battery. Replace the battery only with the same or equivalent type recommended by the manufacturer. Discard used batteries according to the manufacturer's instructions.*



Contents

Chapter 1	General Information	2
1.1	Introduction	2
1.2	Specifications	2
1.2.1	Standard System On Module functions	2
1.2.2	VGA/flat panel Interface	3
1.2.3	Audio function	3
1.2.4	Ethernet	3
1.2.5	Mechanical and environmental	3
Chapter 2	Mechanical Information	6
2.1	Board Connector	6
	Figure 2.1 SOM-144 Locating Connectors	6
2.2	Board Mechanical Drawing	7
2.2.1	Front Side	7
	Figure 2.2 SOM-2355 Front Side Drawing	7
2.2.2	Rear Side	8
	Figure 2.3 SOM-2355 Rear Side Drawing	8
Chapter 3	BIOS Setup Information	10
3.1	Introduction	10
3.2	Safety Precautions	10
3.3	BIOS Update	10
3.4	Basic BIOS Setup	12
3.4.1	Enter the BIOS setup screen	12
3.4.2	Main Setup Item	13
Chapter 4	Driver Installation	16
4.1	Driver Introduction	16
4.2	Driver Installation	17
4.2.1	Step 1- Install AES Driver for Windows XP	17
4.2.2	Step 2- Install AMD LX800 Graphic Driver for Windows XP	17
4.2.3	Step 3- Install Audio Driver for Windows XP	18
4.2.4	Step 4- Install Ethernet Driver for Windows XP	18
Appendix A	Watchdog Timer	20
A.1	Programming the Watchdog Timer	20
Appendix B	System Assignments	24
B.1	System I/O Ports	24
	Table B.1 System I/O ports	24
B.2	DMA Channel Assignments	26
	Table B.2 DMA Channel Assignments	26

B.3	Interrupt Assignments	27
	Table B.3 Interrupt Assignments.....	27
B.4	1st MB Memory Map.....	28
	Table B.4 1st MB Memory Map	28

General Information

This Chapter gives background information on the SOM-2355 CPU System on Module

Sections include:

- Introduction
- Specification

Chapter 1 General Information

1.1 Introduction

SOM-2355 is the latest low power consumption, high performance embedded SOM-144 CPU module that enables customers to extend their system to more applications than ever. This new CPU module adopts AMD's new generation Geode LX 800 series processor with integrated flexible display solution. The integrated graphic accelerator provides multiple display options: (CRT, LCD or CRT+LCD) without extra cost. For I/O there is USB 2.0 and two serial ports. The compact size makes it possible to make systems small and slim. All of these features make SOM-2355 the best choice for outdoor, factory automation and highly reliable demanding applications.

SOM-144 is a standard CPU module which has all the main components on board. Customers can make the necessary design on their own carrier board base. SOM-144 not only significantly reduces development time but also keeps maximum design flexibility satisfying different market demands.

1.2 Specifications

1.2.1 Standard System On Module functions

- **CPU:** On board AMD Geode LX800 CPU
(Detail CPU support information please contact your sales representative)
- **BIOS:** Award 4Mb Flash BIOS
- **Chipset:** AMD Geode LX800 + CS5536
- **Cache memory:** AMD Geode LX800 integrated L2 cache.
- **System memory:** One board 128MB Double Data Rate (DDR) memory.
- **Power management:** Supports power saving modes including Normal / Standby / Suspend modes; S3 mode mouse resume is not support
- **Enhanced IDE interface:** 1 EIDE channel for two devices. BIOS auto-detect up to UDMA -100

- **Watchdog timer:** 255 levels timer interval, from 1 to 255 sec or min setup by software, jumper less selection, generates system reset
- **USB interface:** Support 2 USB 2.0 ports
- **Expansion Interface:** PCI interface

1.2.2 VGA/flat panel Interface

- **Chipset:** AMD Geode LX800 integrated 2D graphic controller
- **Frame buffer:** Share system memory up to 32MB.
- **Display type:** Simultaneously supports CRT / LCD displays; Supports 18-bit TTL interface
- **Display mode:**
 CRT Mode: Support up to 1024 x 768 @ 32 bit
 LCD Mode: Support up to 1024 x 768 @ 18 bit (TTL)

1.2.3 Audio function

- **Audio interface:** Support AC-97 audio codec.

1.2.4 Ethernet

- **Chipset:** Realtek 8100CL Controller. Base on IEEE 10Base-T and 100Bast-TX standard

1.2.5 Mechanical and environmental

- **Dimensions:** SOM-144 form-factor, 100 mm x 68 mm (3.9" x 2.6")
- **Power supply voltage:** +5 V power only
- **Power requirement:**
 Typical: 5V @ 1.7A
 Max.:5V @ 2.2A
- **Operating temperature:** 0 ~ 60° C (32 ~ 140° F)
- **Operating humidity:** 0% ~ 90% relative humidity, non-condensing
- **Weight:** 0.007 Kg (weight of total package)

Mechanical Information

This Chapter gives mechanical and connector information on the SOM-2355 CPU System on Module

Sections include:

- Connector Information
- Mechanical Drawing

Chapter 2 Mechanical Information

2.1 Board Connector

There are four connectors at the rear side of SOM-2355 for connecting to carrier board.




Figure 2.1: SOM-144 Locating Connectors

2.2 Board Mechanical Drawing

2.2.1 Front Side




Figure 2.2: SOM-2355 Front Side Drawing

2.2.2 Rear Side




Figure 2.3: SOM-2355 Rear Side Drawing

BIOS Setup Information

This Chapter gives basic BIOS upgrade and Setup information on the SOM-2355 CPU System on Module

Sections include:

- Safety Precautions
- BIOS Update
- Basic BIOS Setup

Chapter 3 BIOS Setup Information

3.1 Introduction

The SOM-2355 system BIOS is located in Flash ROM. A Single Flash chip holds the system BIOS, VGA BIOS and network Boot ROM (optional). This method minimizes the number of chips and difficulty of configuration.

3.2 Safety Precautions

Warning!



Always completely disconnect the power cord from your board whenever you are working on it. Do not make connections while the power is on, because sensitive electronic components can be damaged by a sudden rush of power.

Caution!



Always ground yourself to remove any static charge before touching the board. Modern electronic devices are very sensitive to static electric charges. Use a grounding wrist strap at all times. Place all electronic components on a static-dissipative surface or in a static-shielded bag when they are not in use.

3.3 BIOS Update

The SOM-2355 is supplied with a software utility on CD-ROM. It contains the necessary file for updating the BIOS. If you cannot find the below files, visit the Advantech website at www.advantech.com.tw to download them or contact our technical support person for help.

There are two files required for BIOS updating as below.

AWDFLASH.EXE

This program allows you to update the BIOS Flash ROM.

2355V110.BIN (Example)


This binary file contains the system BIOS.

Follow the below process to complete BIOS updating.

1. Apply power to the SOM-2355 application. Make sure that the AWDFLASH.EXE and *.BIN files are located in the working drive.

Note: Make sure that you do not run AWDFLASH.EXE while your system is operating in EMM386 mode.

2. At the prompt, type AWDFLASH.EXE and press <Enter>. The BIOS configuration program will then display the following:



The above picture is just an example view, the real picture maybe different with different versions of the Awdflash.exe program.

3. At the prompt, type in the BIN file. When you are sure that you have entered the file name correctly press <Enter>. The screen will ask “Do you want to save?” If you wish to continue press Y. If you change your mind or have made a mistake press N.
4. If you decide to continue, the screen will issue a prompt which will then ask “Are you sure to program (Y/N)?” If you wish to continue, press Y. Press N to exit the program. The new BIOS configuration will then write to the ROM BIOS chip.

3.4 Basic BIOS Setup

Awards BIOS ROM has a built-in Setup program that allows users to modify the basic system configuration. This type of information is stored in battery-backed CMOS RAM so that it retains the Setup information when the power is turned off.

Note: Please do not change the setting unless the default values do not meet your requirements. Inappropriately reconfiguring the BIOS setting may cause the system to become unstable. If the system becomes unstable. Please reread the default values to ensure system stability.

3.4.1 Enter the BIOS setup screen

Power on the system and click key under the BIOS post screen, below BIOS setup screen will show up.



Press arrow key to select the item you would like to change the setting. Press "Enter" key to enter the sub-screen.

3.4.2 Main Setup Item

Standard CMOS Features

This item allows user to change the basic BIOS setting such as System Date, Time, FDD.....

Advanced BIOS Features

This item allows user to change the CPU and booting devices

Advanced Chipset Features

This item allows user to change the chipset and memory setting.

Integrated Peripherals

This item allows user to change the Integrated Peripherals setting such as HDD, on board LAN, USB.

Power Management Setup

This item allows user to change the system power management items, such as ACPI functions.

PnP/PCI Configurations

This item allows user to change the Plug and Play and PCI resource setting, such as IRQ for VGA and USB...

PC Health Status

This item allows user to monitor the system situation such as CPU & system temperature, and voltage....

Load Optimized Default

This item allows user to load the optimized BIOS setting to reach the best performance.

Set Password

This item allows user to set Supervisor/User Passwords.

Save & Exit Setup

This item help to save BIOS change you did and exit the setup screen.

Exit Without Saving

This item exit the BIOS setup screen without saving any change use made.

Driver Installation

This Chapter gives you the driver installation information on the SOM-2355 CPU System on Module

Sections include:

- Driver Information
- Driver Installation

Chapter 4 Driver Installation

4.1 Driver Introduction

The CD shipped with SOM-2355 should contain below drivers, please follow below sequence to complete the driver installation.

Step 1. Install AMD AES Driver for Windows XP

Step 2. Install AMD LX800 Graphic Driver for Windows XP

Step 3. Install Audio Driver for Windows XP

Step 4. Install Ethernet Driver for Windows XP

Note: For Windows XP Embedded support, please contact sales representative or technical person.

Note: Downloading the update for Windows XP or Windows 2000 may be required for enabling USB 2.0 function. For detailed information please refer to below web link.

<http://www.microsoft.com/whdc/system/bus/USB/USB2support.msp>

4.2 Driver Installation

Insert the SOM-2355 CD into the CD-ROM device, An auto run program should show up and please click SOM-2355, and follow below installation process from Step 1 to Step 4.

Note: If the auto-run program doesn't execute appropriately. You can find a related driver in CD-ROM:\SOM\SOM-ETX\SOM-2355

4.2.1 Step 1- Install AES Driver for Windows XP

1. Open Control Panel/System applet and Click "Hardware" tab.
2. Click "Device Manager" button.
3. Click "Other Devices" and right click "Entertainment Encryption/Decryption Device" then select "Update driver".
4. This will open up update driver wizard. Follow the wizard.
5. Select "Install from the list or specific location" and press next.
6. Select "Don't search I will choose the driver to install" and press next.
7. Select "Show all device" and press "Have Disk".
8. Selection the direction of the driver (CD-ROM:\Chipset\AES).
9. Press OK button. Follow the instruction and complete AES driver installation.

4.2.2 Step 2- Install AMD LX800 Graphic Driver for Windows XP

1. Open Control Panel/System applet and Click "Hardware" tab.
2. Click "Device Manager" button.
3. Click "Other Devices" and right click "Video Controller (VGA Compatible)" then select "Update driver".
4. This will open up update driver wizard. Follow the wizard.
5. Select "Install from the list or specific location" and press next.
6. Select "Don't search I will choose the driver to install" and press next.
7. Select "Display Adapters" and press next.
8. Press the "Disk" button.
9. Selection the direction of the driver (CD-ROM:\VGA).

10. Press OK button. Follow the instruction and complete VGA driver installation.

4.2.3 Step 3- Install Audio Driver for Windows XP

1. Enter the Control Panel\System\Hardware\Device Manager.
2. Delete "Multimedia Audio Controller" in the "Other Devices" and reboot the system.
3. At windows startup, Windows finds a "Multimedia Audio Controller" device, please click "Next".
4. Select the Option: "Search for a suitable driver for my device (Recommended)" and click on "Next".
5. Check the Specify location checkbox and enter the direction of CD-ROM:\Audio then click "Next".
6. Follow the instruction and complete Audio driver installation.

4.2.4 Step 4- Install Ethernet Driver for Windows XP

1. Click on the "LAN" folder and double click the "Setup.exe" file.
2. Follow the instructions that the driver installation wizard shows.
3. The system will help you to complete the driver installation.

System Assignments

This Appendix gives you the information about the watchdog timer programming on the SOM-2355 CPU System on Module.

Sections include:

- Watchdog Timer Programming

Appendix A Watchdog Timer

A.1 Programming the Watchdog Timer

Below is a sample of programming code for controlling the watchdog timer function.

Enter the extended function mode, interruptible double-write

```
MOV DX,2EH
MOV AL,87H
OUT DX,AL
OUT DX,AL
```

Configured logical device 8, configuration register CRF6

```
MOV DX,2EH
MOV AL,2BH
OUT DX,AL
MOV DX,2FH
IN AL,DX
AND AL,0EFH;Setbit 4=0 Pin 89=WDTO
OUT DX,AL
MOV DX,2EH
MOV AL,07H; point to Logical Device Number Reg.
OUT DX,AL
MOV DX,2FH
MOV AL,08H; select logical device 8
OUT DX,AL;
MOV DX,2EH
MOV AL,30H;Set watchdog activate or inactivate
OUT DX,AL
```

```

MOV DX,2FH
MOV AL,01H; 01:activate 00:inactivate
OUT DX,AL;
MOV DX,2EH
MOV AL,F5H; Setting counter unit is second
OUT DX,AL
MOV DX,2FH
MOV AL,00H
OUT DX,AL;
MOV DX,2EH
MOV AL,F6H
OUT DX,AL
MOV DX,2FH
MOV AL,05H; Set 5 seconds
OUT DX,AL
;-----
; Exit extended function mode |
;-----
MOV DX,2EH
MOV AL,AAH
OUT DX,AL

```


System Assignments

This Appendix gives you the information about the system resource allocation on the SOM-2355 CPU System on Module.

Sections include:

- System I/O ports
- DMA Channel Assignments
- Interrupt Assignments
- 1st MB Memory Map

Appendix B System Assignments

B.1 System I/O Ports

Table B.1: System I/O ports

Addr. range	
(Hex)	Device
000-00F	DMA controller
010-01F	Motherboard resources
020-021	Programmable interrupt controller
022-02D	Motherboard resources
030-03F	Motherboard resources
040-043	System timer
044-05F	Motherboard resources
060-060	Keyboard controller
061-061	System speaker
062-063	Motherboard resources
070-073	System CMOS/real time clock
074-07F	Motherboard resource
080-090	DMA controller
091-093	Motherboard resource
094-09F	DMA controller
0A0-0A1	Programmable interrupt controller
0A2-0BF	Motherboard resource
0C0-0DF	DMA controller
0E0-0EF	Motherboard resource
0F0-0FF	Numeric data processor

170-177	Secondary IDE Channel
1F0-1F7	Primary IDE Channel
274-277	ISAPNP Read DATA Port
279-279	ISAPNP Read DATA Port
2F8-2FF	Communications Port (COM2)
376-376	Secondary IDE Channel
378-37F	Printer Port (LPT1)
3B0-3BA	AMD WIN XP Graphic Driver
3C0-3DF	AMD WIN XP Graphic Driver
3F6-3F6	Primary IDE Channel
3F8-3FF	Communications Port (COM1)
4D0-4D1	Motherboard resource
778-77B	Printer Port (LPT1)
A78-A7B	Motherboard resource
B78-B7B	Motherboard resource
BBC-BBF	Motherboard resource

B.2 DMA Channel Assignments

Table B.2: DMA Channel Assignments

Channel	Functions
0	Available
1	Available
2	Floppy disk (8-bit transfer)
3	Parallel**
4	Cascade for DMA controller 1
5	Available
6	Available
7	Available

** Parallel port DMA default setting: DMA 3, Parallel port DMA selection: DMA 1 or 3

B.3 Interrupt Assignments

Table B.3: Interrupt Assignments

Interrupt#	Interrupt source
NMI	Parity error detected
IRQ 0	System timer
IRQ 1	Keyboard
IRQ 2	Interrupt from controller 2 (cascade)
IRQ 3	Serial communication port 2
IRQ 4	Serial communication port 1
IRQ 5	Available
IRQ 6	Diskette controller (FDC)
IRQ 7	Parallel port 1 (print port)
IRQ 8	Real-time clock
IRQ 9	Reserve
IRQ 10	Available
IRQ 11	Available
IRQ 12	PS/2 mouse
IRQ 13	Numeric data processor
IRQ 14	Preliminary IDE
IRQ 15	Available

USB and Ethernet IRQ is automatically set by the system

B.4 1st MB Memory Map

Table B.4: 1st MB Memory Map

Addr. range (Hex)	Device
E000h - FFFFh	System ROM
CC00h -DFFFh	Available
C000h - C7FFh	VGA BIOS
B800h - BFFFh	CGA/EGA/VGA text
B000h - B7FFh	Reserved for graphic mode usage
A000h - AFFFh	EGA/VGA graphics
0000h - 9FFFh	Base memory