

# **User Manual**

# WISE-M501

**Multifunction Power Meter** 



### Copyright

The documentation and the software included with this product are copyrighted 2016 by Advantech Co., Ltd. All rights are reserved. Advantech Co., Ltd. reserves the right to make improvements in the products described in this manual at any time without notice. No part of this manual may be reproduced, copied, translated or transmitted in any form or by any means without the prior written permission of Advantech Co., Ltd. Information provided in this manual is intended to be accurate and reliable. However, Advantech Co., Ltd. assumes no responsibility for its use, nor for any infringements of the rights of third parties, which may result from its use.

### **Acknowledgements**

Intel and Atom are trademarks of Intel Corporation.

Microsoft Windows is registered trademark of Microsoft Corp.

All other product names or trademarks are properties of their respective owners.

### **Product Warranty (2 years)**

Advantech warrants to you, the original purchaser, that each of its products will be free from defects in materials and workmanship for two years from the date of purchase.

This warranty does not apply to any products which have been repaired or altered by persons other than repair personnel authorized by Advantech, or which have been subject to misuse, abuse, accident or improper installation. Advantech assumes no liability under the terms of this warranty as a consequence of such events.

Because of Advantech's high quality-control standards and rigorous testing, most of our customers never need to use our repair service. If an Advantech product is defective, it will be repaired or replaced at no charge during the warranty period. For outof-warranty repairs, you will be billed according to the cost of replacement materials, service time and freight. Please consult your dealer for more details.

If you think you have a defective product, follow these steps:

- 1. Collect all the information about the problem encountered. (For example, CPU speed, Advantech products used, other hardware and software used, etc.) Note anything abnormal and list any onscreen messages you get when the problem occurs.
- 2. Call your dealer and describe the problem. Please have your manual, product, and any helpful information readily available.
- 3. If your product is diagnosed as defective, obtain an RMA (return merchandize authorization) number from your dealer. This allows us to process your return more quickly.
- 4. Carefully pack the defective product, a fully-completed Repair and Replacement Order Card and a photocopy proof of purchase date (such as your sales receipt) in a shippable container. A product returned without proof of the purchase date is not eligible for warranty service.
- 5. Write the RMA number visibly on the outside of the package and ship it prepaid to your dealer.

Part No. Printed in China Edition 1 June 2016

### **Declaration of Conformity**

#### CE

This product has passed the CE test for environmental specifications when shielded cables are used for external wiring. We recommend the use of shielded cables. This kind of cable is available from Advantech. Please contact your local supplier for ordering information.

#### CE

This product has passed the CE test for environmental specifications. Test conditions for passing included the equipment being operated within an industrial enclosure. In order to protect the product from being damaged by ESD (Electrostatic Discharge) and EMI leakage, we strongly recommend the use of CE-compliant industrial enclosure products.

### **Technical Support and Assistance**

- 1. Visit the Advantech web site at http://support.advantech.com where you can find the latest information about the product.
- 2. Contact your distributor, sales representative, or Advantech's customer service center for technical support if you need additional assistance. Please have the following information ready before you call:
  - Product name and serial number
  - Description of your peripheral attachments
  - Description of your software (operating system, version, application software, etc.)
  - A complete description of the problem
  - The exact wording of any error messages

### **Safety Instructions**

- 1. Read these safety instructions carefully.
- 2. Keep this User Manual for later reference.
- 3. Disconnect this equipment from any AC outlet before cleaning. Use a damp cloth. Do not use liquid or spray detergents for cleaning.
- 4. For plug-in equipment, the power outlet socket must be located near the equipment and must be easily accessible.
- 5. Keep this equipment away from humidity.
- 6. Put this equipment on a reliable surface during installation. Dropping it or letting it fall may cause damage.
- 7. The openings on the enclosure are for air convection. Protect the equipment from overheating. DO NOT COVER THE OPENINGS.
- 8. Make sure the voltage of the power source is correct before connecting the equipment to the power outlet.
- 9. Position the power cord so that people cannot step on it. Do not place anything over the power cord.
- 10. All cautions and warnings on the equipment should be noted.
- 11. If the equipment is not used for a long time, disconnect it from the power source to avoid damage by transient overvoltage.
- 12. Never pour any liquid into an opening. This may cause fire or electrical shock.
- 13. Never open the equipment. For safety reasons, the equipment should be opened only by qualified service personnel.
- 14. If one of the following situations arises, get the equipment checked by service personnel:
  - The power cord or plug is damaged.
  - Liquid has penetrated into the equipment.
  - The equipment has been exposed to moisture.
  - The equipment does not work well, or you cannot get it to work according to the user's manual.
  - The equipment has been dropped and damaged.
  - The equipment has obvious signs of breakage.
- 15. DO NOT LEAVE THIS EQUIPMENT IN AN ENVIRONMENT WHERE THE STORAGE TEMPERATURE MAY GO BELOW -40° C (-40° F) OR ABOVE 60° C (140° F). THIS COULD DAMAGE THE EQUIPMENT. THE EQUIPMENT SHOULD BE IN A CONTROLLED ENVIRONMENT.
- 16. CAUTION: DANGER OF EXPLOSION IF BATTERY IS INCORRECTLY REPLACED. REPLACE ONLY WITH THE SAME OR EQUIVALENT TYPE RECOMMENDED BY THE MANUFACTURER, DISCARD USED BATTERIES ACCORDING TO THE MANUFACTURER'S INSTRUCTIONS.

The sound pressure level at the operator's position according to IEC 704-1:1982 is no more than 70 dB (A).

DISCLAIMER: This set of instructions is given according to IEC 704-1. Advantech disclaims all responsibility for the accuracy of any statements contained herein.

### **Safety Precaution - Static Electricity**

Follow these simple precautions to protect yourself from harm and the products from damage.

- To avoid electrical shock, always disconnect the power from your PC chassis before you work on it. Don't touch any components on the CPU card or other cards while the PC is on.
- Disconnect power before making any configuration changes. The sudden rush of power as you connect a jumper or install a card may damage sensitive electronic components.

### **Battery Information**

Batteries, battery packs, and accumulators should not be disposed of as unsorted household waste. Please use the public collection system to return, recycle, or treat them in compliance with the local regulations.







### Manual Conventions



Warning! Warnings indicate conditions, which if not observed, can cause personal injury!



Caution! Cautions are included to help you avoid damaging hardware or losing data. e.g.

> There is a danger of a new battery exploding if it is incorrectly installed. Do not attempt to recharge, force open, or heat the battery. Replace the battery only with the same or equivalent type recommended by the manufacturer. Discard used batteries according to the manufacturer's instructions.



Notes provide optional additional information.



# Contents

Chapter	1	Product Overview	1
	1.1 1.2	Introduction Application	2
Chapter	2	Product Specifications	3
	2.1	Product Specifications Table 2.1: PARAMETERS Table 2.2: Accuracy & Resolutions	4 4 4
Chapter	3	Hardware Installation	7
	3.1 3.2 3.3	Dimensions Mounting Wiring & Connections	8 8 8
Chapter	4	System Configuration	11
	4.1 4.2	Operational Processes Setting & Display	12 13
Appendix	хА	I/O Modbus Mapping Table	19
	A.1 A.2	Modbus Function Code Introduction I/O Modbus Mapping Table Table A.1: RS485 communication parameters address ta (Function code: 03h, 06h, 10h)	



**Product Overview** 

### **1.1 Introduction**

The WISE-M501 series Multifunction Power Meter provide high accuracy measurement, display and communication (Modbus RTU) of all electrical and power quality parameters, including harmonic measurement THD (Total Harmonic distortion) Provides electricity bill ratio (Cost) and carbon dioxide ratio (Co2) set can show cumulative electricity bills and carbon emissions, and suitable for the installation in the power management of remote communication, such as the use of demand.

### **1.2 Application**

- Control panels and Motor
- Generator monitoring
- Switchgear distribution systems
- Energy Management
- Power quality analysis



**Product Specifications** 

## 2.1 Product Specifications

Table 2.1: PARAMETERS	
Voltage	$V_{12} V_{23} V_{31} V_{LL_{Avg}} V_1 V_2 V_3 V_{LN_{Avg}}$
Current	I <sub>1</sub> I <sub>2</sub> I <sub>3</sub> I <sub>Avg</sub> I <sub>N</sub>
Active Power	$P_1 P_2 P_3 \Sigma P$
Reactive Power	Q <sub>1</sub> Q <sub>2</sub> Q <sub>3</sub> ΣQ
Apparent Power	$S_1 S_2 S_3 \Sigma S$
Power factor	PF <sub>1</sub> PF <sub>2</sub> PF <sub>3</sub> PF <sub>Avg</sub>
Frequency	Hz
Active Energy	Wh <sub>Total</sub>
Reactive Energy	Varh <sub>Total</sub>
THD for voltage	$THD_{V12}THD_{V23}THD_{V31}THD_{V\_Avg}$
THD for current	THD <sub>I1</sub> THD <sub>I2</sub> THD <sub>I3</sub> THD <sub>I_Avg</sub>
RS485 Port	Modbus RTU mode
Cumulative electricity bills	Cost (Only a single rate)
CO2 emissions	CO <sub>2</sub>
Date time	Year, Month, Day, Hour, Min, Sec.

Table 2.2: Accuracy & Resolutions										
Parameters	Accuracy	Resolution								
Voltage	0.25%	0.1V								
Current	0.25%	0.001A								
Neutral Current	1.0%	0.001A								
Active Power	0.5%	1W								
Reactive Power	0.5%	1Var								
Apparent Power	0.5%	1VA								
Power factor	0.5%	0.001								
Frequency	0.2%	0.01Hz								
Active Energy	0.5%	0.1kWh								
Reactive Energy	0.5%	0.1kVarh								
THD	1.0%	0.1%								

	Programmable by front buttons (Actual wiring must be same)						
Input range:	Voltage: 40~400 V <sub>LN</sub> ; 60~600V <sub>LL</sub>						
	PT Primary range:100~500000V						
	PT Secondary range:100~600V						
	Current: 0~5A, (Optional:0~1A)						
	CT Primary range: 5~9999A						
	Frequency: 45~65Hz						
Max. Input over capabil	ity: Voltage:2 X rated continuous: 2500V, 1 sec						
	Current: 2 X rated continuous: 20 X rated 1 sec						
Input burden:	Voltage: < 0.2VA?Current: < 0.1VA						
Power Quality							
THD:	Total harmonic distortion for Voltage and Current						
RS485 communication	ı (standard)						
Protocol:	Modbus RTU mode						
Baud rate:	1200/2400/4800/9600/19200/38400						
Data bits:	8 bits						
Parity:	None / Even / Odd						
Stop bits:	1 or 2						
Address:	1~255						
Wiring:	1200M max,						
Termination Res.:	120~300Ω/0.25W (typical: 150Ω)						
Back up memory:	FRAM						
Digital Input:	2 DI; Opto couplers: 5Vdc, 20mA						
Digital input:	Reaction time:≤ 300ms; Isolation: 2000Vac						
	2 DQ: Onen collector: 40)/de E0mA						

Digital input.	Reaction time:≤ 300ms; Isolation: 2000Vac						
Digital Output	2 DO; Open collector: 40Vdc, 50mA						
	Reaction time:≤ 300ms; Isolation: 2000Vac						
Power							
Power supply:	AC 85~264V / DC 100~300V						
Power consumption:	AC:≤ 10W / DC:≤ 3W @ 230V						
Environmental							
Operating Temp.:	0~60 °C						
Operating Hum(%RH):	5~95 %RH, non-condensing						
Temp. Coefficient:	≤100 PPM/°C						
Storage Temperature:	-10~70 °C						
Enclosure:	Front panel: IEC 529 (IP50): Housing: IP20						
Input							
Measurement:	True RMS measurement						
Sampling:	128 point / Cycle						
Connection:	1P2W, 1P3W, 3P3W(2,3CT), 3P4W, Balanced/Unbalance						



Hardware Installation

### 3.1 Dimensions



### 3.2 Mounting



### 3.3 Wiring & Connections



#### RS-485/(Terminal Block 2)



#### 3P4W-3PT/3CT [SET: 3 P 4 9 ]







3P4W-Direct Voltage NOPT/3CT [SET: 3P49]



















System Configuration

### 4.1 Operational Processes



### 4.2 Setting & Display



	(3P3W/3P3W.B/3P3W3 No such function)
Press Shiftkey (Comprehensive scree	en) Press Provisiper Up κεγ(Power Parameters)
Normal screen 1 seconds, first showed off the voltage value As follows	Normal screen I seconds, first showed off the voltage value As follows
2012 <u>-07-03-13-50-40</u> Phase voltage and the Average Phase A voltage	Phase voltage and the Average Phase A voltage
Phase B voltage	Phase B voltage
C D D Phase C voltage Average Phase voltage	c $\prod_{k=1}^{c}$ Phase C voltage Average Phase voltage
Active energy	LI.LI: II INUM Active energy
Press 🙀 Key 📕	Press Rey
2012 <u>-07-03-13-50-40</u> 1.2.1- 3-phase integrated display. Average Phase voltage	1 2012_07-03-13-50-40 a n n n n n n n n n n n n n n n n n n n
Average current	□ <b>□ □ □ □ □ □ □</b> ■ □ Phase B active power
Total Active power	c Phase C active power
Average power factor Ω. Ι <sub>ΗμΗ</sub> Average power factor	D. D. D. LALLAR Total Active power Active energy
Press Key	Press 🔀 Key
2012 <u>-07-03-13-50-40</u> 1.2.2- 3-phase integrated display- Average Line voltage	2012 <u>-07-03-13-50-40</u> 1.3.2- Reactive power display Phase A reactive power
Average current	Phase B reactive power
Total Active power	Phase C reactive power
Average power factor	COODE: 3" Control of the sective power Reactive electricity
Press Key	Press
2012 -07-03-13-50-40 <b>3600</b> Total Apparent Power Total Apparent Power	-3 2012 -07-03-13-50-40 a D D D D D D D D D D D D D D D D D D D
Total Reactive Power	b D D D D D Phase B apparent power
Total Active power	C C C C C apparent power
Average power factor	LILIIII U. Iмин Д. Iмин
Press 📲 Key 📕	Press 🔤 Key 📕
2012 -07-03-13-50-40 1.2.4- 3-phase integrated display- Total Apparent Power	4 2012 <u>-07-03-13-50-40</u> a 1.3.4- Power Factor display Phase A power factor
Total Reactive Power	b
Total Aective power	Phase C power factor
Tow D. INAM	Average Power factor
Press Key To 1.2.1 Display Or Press Key1 Sec Back to Measurement screen	Press Key To 1.3.1 Display Or Press Key Key1 Sec Back to Measurement screen





#### \*Engineers set class, non-personnel do not arbitrarily enter the change, in order to avoid abnormal.





I/O Modbus Mapping Table

### A.1 Modbus Function Code Introduction

Code(Hex)	Name	Usage
03	Read Holding Registers	Read 16-bit register. Used to read integer or floating point process data.
06	Preset Single Register	Write data in 16-bit integer format
10	Preset Multiple Registers	Write multiple data in 16-bit integer format

### A.2 I/O Modbus Mapping Table

## Table A.1: RS485 communication parameters address table (Function code: 03h, 06h, 10h)

General class information									
Register Name	Register address	Data Format	Data Length	Measurement range	Unit	R/W	Default	Description	
Frequency	0000h	XXXX	2	45.00 ~65.00	H= /100	D		Frequency (high word)	
	0001h	XX.XX	2	43.00 -05.00	112 / 100	n		Frequency (low word)	
Average	0002h	XXXX				_		Average phase voltage (high word)	
phase voltage	0003h	XXX.X	2	0~500000.0	V/10	R		Average phase voltage (low word)	
	0004h	XXXX	0	0 500000 0	V//4.0	-		Average line voltage (high word)	
UTlavg	0005h	XXX.X	2	0~500000.0	V/10	ĸ		Average line voltage (low word)	
1	0006h	XXXX	0	0 40000 000	A /4000			Average current (high word)	
i avg	0007h	X.XXX	2	0~10000.000	A /1000	ĸ		Average current (low word)	
12	0008h	XXXX	2	0. 10000 000	A /1000	D		Neutral current (high word)	
In	0009h	X.XXX	2	0~10000.000	A/1000	ĸ		Neutral current (low word)	
Daum	000Ah	XXXX	2	-199999999	14/	D		Total effective power (high word)	
PSum	000Bh	XXXX	2	~9999999999	vv	ĸ		Total effective power (low word)	
Oaum	000Ch	XXXX	2	-199999999				Total reactive power (high word)	
Qsum	000Dh	XXXX	2	~9999999999	VAR	ĸ		Total reactive power (low word)	
Course	000Eh	XXXX	2	-199999999 ~9999999999	VA	D		Total apparent power (high word)	
Ssum	000Fh	XXXX				ĸ		Total apparent power (low word)	
	0010h	XXXX	0	-1.000 ~1.000	PF			Average power factor (high word)	
PF avg	0011h	X.XXX	2		/1000	ĸ		Average power factor (low word)	
<b>F</b> .	0012h	xxxx	2	0~99999999.9	kWh /10	R/W		Effective energy (high word), over 999999999.9 auto Zero	
Ea	0013h	XXX.X						Effective energy (low word), over 999999999.9 auto Zero	
<b>F</b> -	0014h	xxxx	2	0.0000000.0	kVARh	R/W	1	Invalid electricity (high word), over 999999999.9 auto Zero	
Er	0015h	XXX.X		0~999999999.9	/10			Invalid electricity (low word), over 999999999.9 auto Zero	
Cost	0016h	XXXX	2	0~99999999.9	\$/10	R		Total electricity bill (high word), over 999999999. 9 auto Zero	
COSI	0017h	XXX.X	2					Total electricity bill (low word), over 99999999.9 auto Zero	
CO 2	0018h	xxxx	2	0~0000000 0	ka/10	Б		The total carbon dioxide(high word),over 9999999999 auto Zero	
002	0019h	XXX.X	2	0-333333333.3	Kg/ TO			The total carbon dioxide (low word) over 999999999.9 auto Zero	
110	001Ah	XXXX	2	0 500000 0	V//10	Б		Phase A voltage (high word)	
UA	001Bh	XXX.X	2	0~500000.0	V/10	ĸ		Phase A voltage (low word)	
	001Ch	XXXX	2	0. 500000 0	V//10	D		Phase B voltage (high word)	
UB	001Dh	XXX.X	2	0~500000.0	V/10	ĸ		Phase B voltage (low word)	
	001Eh	XXXX	2	0 E00000-0	V//10	Б		Phase C voltage (high word)	
	001Fh	XXX.X	2	0~500000.0	V/10	к		Phase C voltage (low word)	
	0020h	XXXX	2	0 E00000 0	V//10	Б		AB line voltage (high word)	
UAD	0021h	XXX.X	2	0~500000.0	V/10	ĸ		AB line voltage (low word)	

UBC	0022h	XXXX	2	0. 500000 0	V//10	n		BC line voltage (high word)
UBC	0023h	XXX.X	12	0~500000.0	V/10	r.		BC line voltage (low word)
	0024h	XXXX	2 0~500000.0 V	V//10	D		CA line voltage (high word)	
UCA	0025h	XXX.X	2	0~500000.0	V/10	ĸ		CA line voltage (low word)
14	0025h XXX.X <sup>2</sup> 0026h XXXX <sub>2</sub>	0. 10000.000	A/1000	<b>D</b>		Phase A current (high word )		
IA	0027h	X.XXX	2	0~10000.000	A/1000	ĸ		Phase A current (ow word)
п	0028h	XXXX	2	0. 10000.000	A/1000	<b>D</b>		Phase B current (high word )
IB	0029h	X.XXX	12	0~10000.000	A/1000	к		Phase B current (low word)
10	002Ah	XXXX	0	0 40000 000	A /4 0 0 0	5		Phase C current (high word)
	002Bh	X.XXX	2	0~10000.000	A/1000	к		Phase C current (low word)
	002Ch	XXXX	2	-199999999	\A/	<b>D</b>		Phase A active power (high word )
PA	002Dh	XXXX	2	~999999999	vv	ĸ		Phase A active power (low word)
חח	002Eh	XXXX	2	-199999999	\A/	<b>D</b>		Phase B active power( high word)
РВ	002Fh	XXXX	2	~999999999	vv	ĸ		Phase B active power (low word)
	0030h	XXXX	2	-199999999	14/	<b>D</b>		Phase C active power (high word)
PC	0031h	XXXX	12	~999999999	vv	ĸ		Phase C active power (low word)
~	0032h	XXXX	2	-199999999		R		Phase A reactive power (high word)
QA	0033h	XXXX	12	~999999999	VAR			Phase A reactive power (low word)
	0034h	XXXX	2	-199999999		R		Phase B reactive power (high word)
QB	0035h	XXXX	~999999999	~999999999	VAR			Phase B reactive power (low word)
00	0036h XXXX	<u>_</u>	-199999999		P		Phase C reactive power(high word)	
QU	0037h	XXXX	12	~999999999	VAR	ĸ		Phase C reactive power (low word)
<b>SV</b>	0038h	XXXX	2	-199999999 ~9999999999	VA	<b>D</b>		Phase A apparent power (high word)
SA	0039h	XXXX	12			ĸ		Phase A apparent power (low word)
00	003Ah	XXXX	2	-199999999	VA	<b>D</b>		Phase B apparent power (high word)
38	003Bh	XXXX	12	~999999999		n		Phase B apparent power (low word)
80	003Ch	XXXX	2	-199999999	\/A	R		Phase C apparent power(high word)
30	003Dh	XXXX	2	~999999999	VA			Phase C apparent power (low word)
	003Eh	XXXX	2	4 000 4 000	PF/ 1000	Р		Phase A Power Factor (high word)
FFA	003Fh	X.XXX	2	-1.000 ~1.000		ĸ		Phase A Power Factor (low word)
	0040h	XXXX	2	1 000 . 1 000	PF/	<b>D</b>		Phase B Power Factor (high word)
PFD	0041h	X.XXX	12	-1.000 ~1.000	1000	ĸ		Phase B Power Factor (low word)
DEC	0042h	XXXX	2	1 000 - 1 000	PF/	Б		Phase C Power Factor (high word)
PFC	0043h	X.XXX	12	-1.000 ~1.000	1000	ĸ		Phase C Power Factor (low word)
LT	0044h	xx	1	82=R, 76=L, 67=C		R		R: Resistive, L: Inductive, C:Capacitive
THDUA	0045h	XXX.X	1	0~100.0	%/10	R		Phase A voltage total harmonic( 3P3W,THDUAB)
THDUB	0046h	XXX.X	1	0~100.0	%/10	R		Phase B voltage total harmonic (3P3W,THDUBC)
THDUC	0047h	XXX.X	1	0~100.0	%/10	R		Phase C voltage total harmonic (3P3W,THDUCA)
THDUavg	0048h	XXX.X	1	0~100.0	%/10	R		Average voltage total harmonic
THDIA	0049h	XXX.X	1	0~100.0	%/10	R		Phase A current total harmonic
THDIB	004Ah	XXX.X	1	0~100.0	%/10	R		Phase B current total harmonic
THDIC	004Bh	XXX.X	1	0~100.0	%/10	R		Phase C current total harmonic
THDlavg	004Ch	XXX.X	1	0~100.0	%/10	R		Average total harmonic current

Input group setting class									
Register Name	Register address	Data Format	Data Length	Measurement range	Unit	R/W	Default	Description	
Voltage wir- ing Wire-U	004Dh	x	1	0~6		R/W	5	0:1P2W4:3P3W.3 1:1P3W5:3P4W 2:3P3W6:3P4W.B 3:3P3W.B	
	004Eh	xxxx	2	100~500000	V	DAM	600	PT Primary side voltage setting( high word )	
P I- PII	004Fh	xxxx			v	K/W		PT Primary side voltage setting( low word )	
PT- Sec	0050h	XXXX	1	100~600	V	R/W	600	PT Secondary voltage settings	
CT- Pri	0051h	XXXXX	1	1~10000	А	R/W	5	CT Primary current setting	
P.code	0052h	XXXX	1	0000~9999		R/W	1000	Clearance password change	

RS485 communication group settings class										
Register Name	Register address	Data Format	Data Length	Measurement range	Unit	R/W	Default	Description		
Addr	0053h	xxx	1	1~247		R/W	1	The Communication Station No. set- ting		
Baud	0054h	х	1	0~5		R/W	3	0:1200, 1:2400, 2:4800, 3:9600, 4:19200, 5:38400		
Parity	0055h	х	1	0~3		R/W	1	0:N81, 1:N82, 2:O81, 3:E81		

Cost group setting class										
Register Name	Register address	Data Format	Data Length	Measurement range	Unit	R/W	Default	Description		
Cost	0056h	XX.XX	1	00.00~99.99		R/W	2.30	kWh the cost ratio setting		
CO2	0057h	X.XXX	1	0.000~9.999		R/W	0.638	kWh of CO2 ratio setting		

Time group setting class										
Register Name	Register address	Data Format	Data Length	Measurement range	Unit	R/W	Default	Description		
Back- Light	0058h	XX	1	0~15		R/W	1	0~15Minute, 0 is Steadily lit		
Year	0059h	XX	1	0~99		R/W		0~99 = 2000~2099		
Month	005Ah	XX	1	1~12		R/W				
Day	005Bh	XX	1	1~31		R/W				
Time	005Ch	XX	1	0~23		R/W				
Minute	005Dh	XX	1	0~59		R/W				
Second	005Eh	XX	1	0~59		R/W				

Permanent screen group setting class										
Register Name	Register address	Data Format	Data Length	Measurement range	Unit	R/W	Default	Description		
Def.Page	005Fh	x	1	1~4			1	1: 1.2.1: Average phase voltage (T/ L-n/V) / Average current (A)/Total active power (kW)Average power factor (PF/IND/Avg) /Total active energy (kWh)		
						R/W		2: 1.2.2: Average line voltage (T/L- L/V) / Average current (A)/Total active power (kW)Average power factor (PF/IND/Avg) /Total active energy (kWh)		
								3: 1.2.3: Total apparent power (T/ kVA) / Total reactive power (kvar)/ Total active power (kW)/Average power factor(PF/IND/Avg) / Total active energy(kWh)		
								4: 1.2.4: Total apparent power (T/ kVA) /Total reactive power (kvar)/ Total active power(kW)/Frequency (Hz) /Total active energy (kWh)		
INIT	0060h	XXXX	2	0000~9999		R/W	0	Set:7170,Restore Default		

$\sim$
$\overline{\mathbf{O}}$
Ā
V
5
$\mathbf{O}$
$\mathbf{X}$
()
$\bigcirc$
~
X
$\mathbf{O}$
07
$\sim$
0)
O
-
$\mathbf{\nabla}$
$( \cap$
0)
$\overline{\mathbf{O}}$

Client Custom class									
Register Name	Register address	Data Format	Data Length	Measurement range	Unit	R/W	Default	Description	
Client Custom1	5000h	хх	1	0~76(0x4c)		R/W	0x0000 h		
Client Cus- tom 2	5001h	xx	1	0~76(0x4c)		R/W	0x0001 h		
Client Cus- tom 3	5002h	xx	1	0~76(0x4c)		R/W	0x0002 h		
Client Cus- tom 4	5003h	xx	1	0~76(0x4c)		R/W	0x0003 h		
Client Cus- tom 5	5004h	xx	1	0~76(0x4c)		R/W	0x0004 h	This regional data to set the following	
Client Cus- tom 6	5005h	xx	1	0~76(0x4c)		R/W	0x0005 h	20 addresses (5014h~5027h) content of the information,	
Client Cus- tom 7	5006h	xx	1	0~76(0x4c)		R/W	0x0006 h	address information significance Address correspondence to: 5000h set	
Client Cus- tom 8	5007h	хх	1	0~76(0x4c)		R/W	0x0007 h	5014h corresponding address data content.	
Client Cus- tom 9	5008h	xx	1	0~76(0x4c)		R/W	0x0008 h	Address corresponding address data content. Address correspondence to: 5013h set 5027h address data corresponding to content. Example:	
Client Cus- tom 10	5009h	xx	1	0~76(0x4c)		R/W	0x0009 h		
Client Cus- tom 11	500Ah	xx	1	0~76(0x4c)		R/W	0x000A h		
Client Cus- tom 12	500Bh	xx	1	0~76(0x4c)		R/W	0x000B h	1: 5000h address data = 0000h, 5001h address data = 0001h. Then	
Client Cus- tom 13	500Ch	xx	1	0~76(0x4c)		R/W	0x000C h	,5015h addresses are mapped to the content of 0000h, 0001h, according	
Client Cus- tom 14	500Dh	xx	1	0~76(0x4c)		R/W	0x000D h	to the table, 5014h ,5015h address data for the frequency content birth bute and low bute	
Client Cus- tom 15	500Eh	xx	1	0~76(0x4c)		R/W	0x000E h	(Setting range 0 ~ 0x4c, read the corre- sponding region RS485 Data	
Client Cus- tom 16	500Fh	xx	1	0~76(0x4c)		R/W	0x000F h	Sheet)	
Client Cus- tom 17	5010h	xx	1	0~76(0x4c)		R/W	0x0010 h		
Client Cus- tom 18	5011h	xx	1	0~76(0x4c)		R/W	0x0011 h		
Client Cus- tom 19	5012h	xx	1	0~76(0x4c)		R/W	0x0012 h		
Client Cus- tom 20	5013h	xx	1	0~76(0x4c)		R/W	0x0013 h		

Custom the output 1	5014h	1		R		
Custom the output 2	5015h	1		R		
Custom the output 3	5016h	1		R		
Custom the output 4	5017h	1		R		
Custom the output 5	5018h	1		R		
Custom the output 6	5019h	1		R		
Custom the output 7	501Ah	1		R		
Custom the output 8	501Bh	1		R		
Custom the output 9	501Ch	1		R		
Custom the output 10	501Dh	1		R		Meaning of the data subject 5000h~5013h address control, data format and the unit and the actual out- put data format to match the format see the table RS485
Custom the output 11	501Eh	1		R		
Custom the output 12	501Fh	1		R		
Custom the output 13	5020h	1		R		
Custom the output 14	5021h	1		R		
Custom the output 15	5022h	1		R		
Custom the output 16	5023h	1		R		
Custom the output 17	5024h	1		R		
Custom the output 18	5025h	1		R		
Custom the output 19	5026h	1		R		
Custom the output 20	5027h	1		R		



### www.advantech.com

Please verify specifications before quoting. This guide is intended for reference purposes only.

All product specifications are subject to change without notice.

No part of this publication may be reproduced in any form or by any means, electronic, photocopying, recording or otherwise, without prior written permission of the publisher.

All brand and product names are trademarks or registered trademarks of their respective companies.

© Advantech Co., Ltd. 2016