

UNO-2053GL

**LX800 500MHz Automation
Computer with 2 x LAN, 2 x USB,
2 x RS-232, Audio**

User Manual

Copyright Notice

The documentation and the software included with this product are copyrighted 2010 by Advantech Co., Ltd. All rights are reserved. Advantech Co., Ltd. reserves the right to make improvements in the products described in this manual at any time without notice. No part of this manual may be reproduced, copied, translated or transmitted in any form or by any means without the prior written permission of Advantech Co., Ltd. Information provided in this manual is intended to be accurate and reliable. However, Advantech Co., Ltd. assumes no responsibility for its use, nor for any infringements of the rights of third parties, which may result from its use.

Acknowledgements

IBM, PC/AT, PS/2 and VGA are trademarks of International Business Machines Corporation.

Intel® and Pentium® are trademarks of Intel Corporation.

Microsoft Windows and MS-DOS are registered trademarks of Microsoft Corp.

C&T is a trademark of Chips and Technologies, Inc.

All other product names or trademarks are properties of their respective owners.

Part No. 2003205321

2nd Edition

Printed in Taiwan

October 2010

Product Warranty (2 years)

Advantech warrants to you, the original purchaser, that each of its products will be free from defects in materials and workmanship for two years from the date of purchase.

This warranty does not apply to any products which have been repaired or altered by persons other than repair personnel authorized by Advantech, or which have been subject to misuse, abuse, accident or improper installation. Advantech assumes no liability under the terms of this warranty as a consequence of such events.

Because of Advantech's high quality-control standards and rigorous testing, most of our customers never need to use our repair service. If an Advantech product is defective, it will be repaired or replaced at no charge during the warranty period. For out-of-warranty repairs, you will be billed according to the cost of replacement materials, service time and freight. Please consult your dealer for more details.

If you think you have a defective product, follow these steps:

1. Collect all the information about the problem encountered. (For example, CPU speed, Advantech products used, other hardware and software used, etc.) Note anything abnormal and list any onscreen messages you get when the problem occurs.
2. Call your dealer and describe the problem. Please have your manual, product, and any helpful information readily available.
3. If your product is diagnosed as defective, obtain an RMA (return merchandize authorization) number from your dealer. This allows us to process your return more quickly.
4. Carefully pack the defective product, a fully-completed Repair and Replacement Order Card and a photocopy proof of purchase date (such as your sales receipt) in a shippable container. A product returned without proof of the purchase date is not eligible for warranty service.
5. Write the RMA number visibly on the outside of the package and ship it prepaid to your dealer.

CE

This product has passed the CE test for environmental specifications when shielded cables are used for external wiring. We recommend the use of shielded cables. This kind of cable is available from Advantech.

FCC Class A

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Technical Support and Assistance

- Step 1. Visit the Advantech web site at **www.advantech.com/support** where you can find the latest information about the product.
- Step 2. Contact your distributor or Advantech's customer service center if you need additional assistance. Have the following info ready:
 - Product name and serial number
 - Description of your peripheral attachments
 - Description of your software (OS, version, software, etc.)
 - A complete description of the problem
 - The exact wording of any error messages

Packing List

Before setting up the system, check that the items listed below are included. If any item is not, please contact your dealer immediately.

The UNO-2053GL comes with the following items:

- Warranty certificate
- Software Supporting CD-ROM
- 6P-6P-6P 20cm KB and PS/2 Mouse Y cable (P/N: 1652002202)
- Phoenix power connector (P/N 1652002202)
- DIN-rail mounting accessory

Contents

Chapter	1	UNO-2053GL Overview	2
	1.1	Introduction	2
	1.2	Hardware Specifications	2
	1.3	Safety Precautions	4
	1.4	Packing List	5
	1.5	Chassis Dimensions	6
		Figure 1.1:Chassis Dimensions	6
Chapter	2	Hardware Functionality	8
	2.1	UNO-2053GL Peripherals.....	8
		Figure 2.1:UNO-2053GL Front Panel	8
		Figure 2.2:UNO-2053GL Rear Panel	8
	2.2	COM1~COM2: RS-232 Interfaces	8
	2.3	LAN: Ethernet Connector	8
	2.4	Power Connector	9
	2.5	LED Indicators	9
	2.6	PS/2 Keyboard and Mouse Connector	9
	2.7	Universal Serial Bus Connectors.....	9
	2.8	VGA: VGA Display Connector	9
	2.9	RESET: Reset Button.....	10
	2.10	Audio	10
Chapter	3	Initial Setup.....	12
	3.1	CompactFlash Card Installation	12
	3.2	Chassis Grounding	12
		Figure 3.1:Chassis Grounding Connection	12
	3.3	Power Connection	12
	3.4	BIOS Setup and System Assignments	12
Appendix	A	Pin Assignments	14
	A.1	Board Connectors and Jumpers.....	14
		Figure A.1:Connector & Jumper Locations (Top)	14
		Figure A.2:Connector & Jumper Locations (Bottom)	14
		Table A.1:UNO-2053GL Connectors & Jumpers	15
	A.2	RS-232 Serial Port 9C (COM1~COM2)(Male DB9)	16
		Table A.2:RS-232 Serial Port Pin Assignments	16
	A.3	Ethernet RJ-45 Connector (LAN1~LAN2).....	16
		Table A.3:Ethernet RJ-45 Connector Pin Assigns	16
	A.4	Phoenix Power Connector (C).....	17
		Table A.4:Phoenix Power Connector Pin Assigns	17
	A.5	PS/2 Keyboard and Mouse Connector (KM1)	17
		Table A.5:	17
		Table A.6:Keyboard & Mouse Connector Pin Assigns	17
	A.6	USB Connector (CON1, CON2).....	18
		Table A.7:USB Connector Pin Assignments	18
	A.7	VGA Display Connector (VGA1).....	18
		Table A.8:VGA Adaptor Cable Pin Assignments	18

A.8	CompactFlash Master/Slave Jumper Setting (JP2)	19
A.9	Enhanced IDE Connector (CN2)	20
	Table A.9:IDE Hard Drive Connector Pin Assigns	20

UNO-2053GL Overview

This chapter gives background information on the UNO-2053GL. It shows you the UNO-2053GL overview and specifications.

Sections include:

- Introduction
- Hardware Specifications
- Safety Precautions
- UNO-2053GL Series
- Chassis Dimensions

Chapter 1 UNO-2053GL Overview

1.1 Introduction

Are you looking forward to a suitable embedded Application Ready Platform (ARP) that could shorten your development time and offer rich networking interfaces to fulfill your extensive needs in different kind of projects? Advantech Universal Network Controller (UNO-2000 series) is your ANSWER concentrating the services on Network-enabled Application Ready Platform total solution.

Leveraging field-approved and worldwide-awareness real-time OS technology, Advantech UNO-2000 series provides Windows CE .NET ready solution and support several standard networking interfaces, such as Ethernet, Wireless LAN, RS-232/422/485 and so on. Because of its openness, great expansion capability and reliable design – fanless and diskless, Advantech UNO-2000 series becomes an ideal embedded platform to implement custom applications in diversified applications.

1.2 Hardware Specifications

- **CPU:** AMD Geode LX800 500MHz
- **Chipset:** AMD CS5536
- **BIOS:** AWARD 4Mbit FLASH BIOS
- **RAM:** 256MB DDRAM on board
- **VGA:** Supports VGA and VESA
 - Display memory: 1 ~ 16 MB share memory, set in BIOS
 - CRT display: Non-interlaced CRT monitors resolutions up to 1280 x 1024 @ 256 colors or 1024 x 768 @ 24 bpp
 - DB-15 VGA connector
- **Audio:**
 - Microphone
 - Line In
 - Line Out

- **Serial Port:** Two standard RS-232 ports
 - IRQ: All ports use the same IRQ assigned by BIOS
 - Data bits: 5, 6, 7, 8
 - Stop bits: 1, 1.5, 2
 - Parity: none, even, odd
 - Speed: 50~115.2 kbps
 - Data signals: TxD, RxD, RTS, CTS, DTR, DSR, DCD, RI, GND
 - Max data distance: 50 feet (15.2 meters)
- **USB interface:** USB EHCI, Rev. 2.0 compliant
- **Ethernet Port:** Dual 10/100Base-T Ethernet
 - LAN chip: Realtek 8139CL chipset supports
 - LED on the front side
- **SSD:** One Type I / Type II CompactFlash card slot inside the chassis
- **LED:** One power LED, one IDE LED
- **Keyboard/Mouse connector:** Mini-DIN connector supports PS/2 keyboard and a PS/2 mouse
- **Power Supply Voltage:** 10-30 VDC, reversed wiring protection
- **Power Consumption:** 15W (typical)
- **Power Requirement:** 24W
- **Operating Temperature:** -10 ~ 55° C (14 ~ 131° F)
- **Chassis Size (W x L x H):** 164.8 x 106.5 x 35.5 mm (6.5" x 4.2" x 1.4")
- **Weight:** 0.8 kg

1.3 Safety Precautions

The following sections tell how to make each connection. In most cases, you will simply need to connect a standard cable. All of the connector pin assignments are shown in Appendix A.

Warning!! *Always disconnect the power cord from your chassis when you are working on it. Do not connect while the power is on. A sudden rush of power can damage sensitive electronic components. Only experienced electronics personnel should open the chassis.*

Caution!! *Always ground yourself to remove any static electric charge before touching UNO-2053GL. Modern electronic devices are very sensitive to static electric charges. Use a grounding wrist strap at all times. Place all electronic components on a static-dissipative surface or in a static-shielded bag..*

1.4 Packing List

Before installing, make sure that you have the following materials:

- **UNO-2053GL:** UNO-2053GL hardware platform
- Warranty certificate
- Software CD-ROM
- 6P-6P-6P 20cm KB and PS/2 Mouse Y cable (P/N: 1652002202)
- Phoenix power connector (P/N 1652002202)
- DIN-rail mounting accessory (1997001110, 1997001120, 1997001130, 1997001140)

If any of these items are missing or damaged, contact your distributor or sales representative immediately.

1.5 Chassis Dimensions




Figure 1.1: Chassis Dimensions

Hardware Functionality

This chapter shows how to set up the UNO-2053GL's hardware functions, including connecting peripherals, switches and indicators.

Sections include:

- UNO-2053GL Peripherals
- COM1~COM2: RS-232 Interfaces
- LAN: Ethernet Connector
- Power Connector
- LED Indicators
- PS/2 Keyboard and Mouse Connector
- Universal Serial Bus Connectors
- VGA: VGA Display Connector
- RESET: Reset Button
- Audio

Chapter 2 Hardware Functionality

2.1 UNO-2053GL Peripherals

The following two figures show the connectors on UNO-2053GL. The following sections give you detail information about function of each peripheral.




Figure 2.1: UNO-2053GL Front Panel




Figure 2.2: UNO-2053GL Rear Panel

2.2 COM1~COM2: RS-232 Interfaces

The UNO-2053GL offers two standard RS-232 serial communication interface ports on COM1 and COM2. Please refer to A.2 for pin assignments.

2.3 LAN: Ethernet Connector

The UNO-2053GL is equipped with two Realtek RTL8139CL Ethernet LAN controllers that are fully compliant with IEEE 802.3u 10/100Base-T CSMA/CD standards. The Ethernet port provides a standard RJ-45 jack onboard, and LED indicators on the front side to show its Link (Yellow LED) and Active (Green LED) status. Please refer to A.3 for its pin assignments.

2.4 Power Connector

The UNO-2053GL comes with a Phoenix connector that carries 10~30 VDC external power input, and has reversed wiring protection. Therefore, it will not cause any damage to the system by reversed wiring of ground line and power line. Please refer to A.4 for its pin assignments.

2.5 LED Indicators

There are two LEDs on the UNO-2053GL front panel for indicating system status: PWR LED is for power status and IDE LED is for IDE bus status.

2.6 PS/2 Keyboard and Mouse Connector

The UNO-2053GL provides a PS/2 keyboard and PS/2 mouse connector. A 6-pin mini-DIN connector is located on the rear panel of the UNO-2053GL. The UNO-2053GL comes with an adapter to convert from the 6-pin mini-DIN connector to two 6-pin mini-DIN connectors for PS/2 keyboard and mouse connections. Please refer to Appendix A.5 for pin assignments.

2.7 Universal Serial Bus Connectors

The USB connector is used for connecting any device that conforms to the USB interface. Many recent digital devices conform to this standard. The USB interface supports Plug & Play, which enables you to connect or disconnect a device whenever you want without turning off the computer.

The UNO-2053GL provides two connectors with USB interfaces, which gives complete Plug & Play and hot swapping for up to 127 external devices. The USB interface complies with USB specification version 2.0 compliant. EHCI, Rev. 2.0. The USB interface can be disabled in the system BIOS setup. Please refer to Appendix A.6 for its pin assignments.

2.8 VGA: VGA Display Connector

The UNO-2053GL provides a VGA controller for a high resolution VGA interface. It supports VGA and VESA, up to 1280 x 1024 @ 256 color and 1024 x 768 @ 24bpp resolution and up to 16 MB share memory. The VGA interface is reserved for system testing and debugging.

2.9 RESET: Reset Button

Pressing the “RESET” button will reset UNO-2053GL.

2.10 Audio

UNO-2053GL supports audio function with

- Microphone
- Line In
- Line Out.

Initial Setup

This chapter shows how to initial the UNO-2053GL, sections include:

Sections include:

- Insert CompactFlash Card
- Chassis grounding
- Connect the Power
- BIOS Setup and System Assignments

Chapter 3 Initial Setup

3.1 CompactFlash Card Installation

The procedure for installing a CompactFlash card into the UNO-2053GL is as follows, please follows these steps carefully.

Step 1: Remove power cord.

Step 2: Unscrew four screws from the rear panel of the UNO-2053GL.

Step 3: Remove the rear panel.

Step 4: Plug a CompactFlash card with user's OS and application program into a CompactFlash card slot on board.

Step 5: Screw back the rear panel with four screws.

3.2 Chassis Grounding

Please connect the chassis ground of UNO-2053GL with "EARTH".




Figure 3.1: Chassis Grounding Connection

3.3 Power Connection

Connect the UNO-2053GL to a 10 ~ 30 VDC power source. The power source can either be from a power adapter or an in-house power source.

3.4 BIOS Setup and System Assignments

UNO-2053GL uses the Advantech SOM-2355 CPU module. For BIOS setup and system assignments, you can refer to SOM-2355's Chapter 4 "Award BIOS Setup" and Appendix A "System Assignments". The SOM-2355 user's manual is in the "Manual" folder on the CD-ROM.

Please note that you can try to "LOAD BIOS DEFAULTS" from the BIOS Setup manual if UNO-2053GL does not work properly.

Pin Assignments

This appendix shows the UNO-2053GL pin assignments

- Board Connectors and Jumpers
- RS-232 Serial Port
- Ethernet RJ-45 Connector
- Phoenix Power Connector
- PS/2 Keyboard and Mouse Connector
- USB Connector
- VGA Display Connector
- CompactFlash Master/Slave Jumper Setting
- Enhanced IDE connector

Appendix A Pin Assignments

A.1 Board Connectors and Jumpers

There are connectors and jumpers on the UNO-2053GL board. The following sections tell you how to configure the UNO-2053GL hardware setting. Figure A-1 and figure A-2 show the locations of UNO-2053GL connectors and jumpers.




Figure A.1: Connector & Jumper Locations (Top)




Figure A.2: Connector & Jumper Locations (Bottom)

Table A.1: UNO-2053GL Connectors & Jumpers

CN2	Internal IDE connector
CN3	Phoenix power connector
CN4	Internal CompactFlash card slot
COM1	COM1 standard RS-232 serial port
COM2	COM2 standard RS-232 serial port
CON1	USB1 Connector
CON2	USB2 Connector
D6	IDE LED
D7	Power LED
J1	Reset button
JP2	CompactFlash IDE Primary Master/Slave Jumper
KM1	PS/2 Keyboard and Mouse connector
LAN1	Ethernet 1 RJ-45 connector
LAN2	Ethernet 2 RJ-45 connector
VGA1	VGA DB-15 connector
CN21	Line out
CN22	Line in
CN23	Mic in

A.2 RS-232 Serial Port 9C (COM1~COM2)(Male DB9)




Table A.2: RS-232 Serial Port Pin Assignments

1	DCD
2	RxD
3	TxD
4	DTR
5	GND
6	DSR
7	RTS
8	CTS
9	RI

A.3 Ethernet RJ-45 Connector (LAN1~LAN2)

Table A.3: Ethernet RJ-45 Connector Pin Assigns

Pin	10/100Base-T Signal Name
1	XMT+
2	XMT-
3	RCV+
4	NC
5	NC
6	RCV-
7	NC
8	NC

A.4 Phoenix Power Connector (C)




Table A.4: Phoenix Power Connector Pin Assigns

Pin	Signal Name
1	+10~30 VDC
2	GND

A.5 PS/2 Keyboard and Mouse Connector (KM1)

PS/2 KB/MS Connector Pin Assignments




Table A.6: Keyboard & Mouse Connector Pin Assigns

Pin	Signal Name
1	KB DATA
2	MS DATA
3	GND
4	VCC
5	KB CLOCK
6	MS CLOCK

A.6 USB Connector (CON1, CON2)

Table A.7: USB Connector Pin Assignments

Pin	Signal Name	Cable Color
1	VCC	Red
2	DATA-	White
3	DATA+	Green
5	GND	Black

A.7 VGA Display Connector (VGA1)

Table A.8: VGA Adaptor Cable Pin Assignments

Pin	Signal Name	Pin	Signal Name
1	RED	9	NC
2	GREEN	10	GND
3	BLUE	11	NC
4	NC	12	NC
5	GND	13	H-SYNC
6	GND	14	V-SYNC
7	GND	15	NC
8	GND		

Chipset

The UNO-2053GL uses a AMD CS5536 chipset for its SVGA controller. It supports interlaced and non-interlaced analog monitors (color and monochrome VGA) in high-resolution modes while maintaining complete IBM VGA compatibility. Digital monitors (i.e. MDA, CGA and EGA) are NOT supported. Multiple frequency (multisync) monitors are handled as if they were analog monitors.


Display Memory

With 1 ~ 16 MB share memory, the VGA controller can drive CRT displays or color panel displays with resolutions up to 1024 * 768 at 24 bpp. For 1024 * 768 at 24 bpp resolution, display is expanded to 16 MB in BIOS.


A.8 CompactFlash Master/Slave Jumper Setting (JP2)

The CompactFlash interface uses a primary IDE channel, which can be set as the master or slave device by changing the setting of JP2.

Master Device: (Default)



Slave Device



UNO-2053GL has one internal CompactFlash card slot which supports CompactFlash type I (3mm thick) and type II (5 mm thick) cards.

Note: If you build up WinCE OS in CompactFlash card by yourself, we strongly recommend that JP2 should set up to close status (Master)

A.9 Enhanced IDE Connector (CN2)

Table A.9: IDE Hard Drive Connector Pin Assigns

Pin	Signal Name	Pin	Signal Name
1	IDE RESET	2	GND
3	DATA 7 (*2)	4	DATA 8 (*2)
5	DATA 6 (*2)	6	DATA 9 (*2)
7	DATA 5 (*2)	8	DATA 10 (*2)
9	DATA 4 (*2)	10	DATA 11 (*2)
11	DATA 3 (*2)	12	DATA 12 (*2)
13	DATA 2 (*2)	14	DATA 13 (*2)
15	DATA 1 (*2)	16	DATA 14 (*2)
17	DATA 0 (*2)	18	DATA 15 (*2)
19	SIGNAL GND	20	N/C
21	DMA REQUEST	22	GND
23	IO WRITE (*2)	24	GND
25	IO READ (*2)	26	GND
27	IO CHANNEL	28	GND (*1)
	READY		
29	HDACK	30	GND
31	IRQ	32	N/C
33	ADDR 1	34	N/C
35	ADDR 0	36	ADDR 2
37	HARD DISK	38	HARD DISK
	SELECT 0 (*2)		SELECT 1 (*2)
39	IDE ACTIVE	40	GND
41	VCC	42	VCC
43	GND	44	N/C