

ALL-100
Universal & Gang Programmer
User's Manual

Oct. 2003

© 2003 HI-LO SYSTEM RESEARCH CO., LTD.

Information provided in this document is proprietary to HI-LO System Research Co., Ltd.
(<http://www.hi-lo.com.tw>)

The information in this publication is believed to be accurate in all respects at the time of publication, but is subject to be changed without notice.

HI-LO Systems assumes no responsibility for any errors or omissions, and disclaims responsibility for any consequence resulting from the use of the information included herein.

Trademarks:

HI-LO is a trademark of HI-LO System Research Co., Ltd.

Windows 98/Me/2000/XP/Server 2003 are trademarks of Microsoft Corporation.

IBM is a trademark of IBM Corporation.

AMD is a trademark of Advanced Micro Devices Inc.

All other trademarks are the property of their respective owners.

Contents

1. Intruduction.....	1
1.1 Programmer and Accessories	1
1.2 PC System Requirements	3
1.3 ALL-100 Specification.....	4
2. Single ALL-100 Installation.....	5
2.1 Hardware Installation	5
2.2 USB Driver Installation	9
2.3 Software Installation	14
3. ALL-100 Basic Operation.....	17
3.1 Getting Started.....	17
3.1.1 Start with XACCESS.....	17
3.1.2 Select IC Manufacturer.....	18
3.1.3 Select IC Protect Group and Product Type.....	19
3.2 Load file to Programmer buffer.....	21
3.3 Read contents from Master IC to buffer	22
3.4 Program buffer contents to IC.....	24
3.5 ADAPTERs and CONVERTERs.....	25
3.5.1 ADAPTER and CONVERTER installation.....	26
4. Multiple ALL-100 Installation.....	27
4.1 Multiple ALL-100 Operation.....	28
4.2 Read/Compare on Multiple ALL-100s.....	30

5. ALL-100 Gang Option Installation.....	31
5.1 ALL-100 Gang Operation.....	32
5.2 Read/Compare on Multiple ALL-100 Gangs.....	33
6. ALL-100 Software Description.....	34
6.1 XACCESS User Interface.....	34
6.2 Utilities.....	35
6.2.1 Hex to Bin Converter.....	35
6.2.2 Bin to Hex Converter.....	36
6.2.3 2-way splitter.....	37
6.2.4 4-way splitter.....	38
6.2.5 2-way shuffler.....	39
6.2.6 4-way shuffler.....	40
6.2.7 Version List.....	41
6.2.8 Cross Reference.....	42
6.2.9 Device List.....	43
6.3 Programming Data /Function Description	44
6.3.1 File.....	45
6.3.2 Edit.....	50
6.3.3 Operation.....	64
6.3.4 USB Info.....	72
6.3.5 About.....	73

7. ALL-100 Troubleshooting.....	74
8. Glossary.....	75
8.1 EPROM, EEPROM, BPROM, and MPU.....	75
8.2 PLD, PAL, GAL, PEEL, CPLD, EPLD, and FPGA.....	79

1. Introduction

This manual describes how to install and operate ALL-100 Programmer under environment of PC Windows 98/Me/2000/XP/Server 2003. ALL-100 Programmer works with PC through USB 1.1/2.0 (Universal Serial Bus) to perform high speed data transmission. The high speed processor in programmer precisely controls programming timing and flow, this ensures accurate programming waveforms always generated on ALL-100.

ALL-100 is embeded with 4Mbit memory to support the programming capacity for most E(E)PROM, MCU/MPU, and PLD. The software automatically uses PC memory as buffer to support high density memory ICs.

1.1 Programmer and Accessories

Each ALL-100 package contains following standard accessories:

- Base Unit and single socket Programming Module (M1-UN-DP48).
- An AC power cable, 1.8 M in length.
- A USB cable (Type A to Type B), 1.0 M in length.
- A CD-ROM for Driver Files.
- User's Manual.

☆ Option 99

Price deduction for requesting another Programming Module to substitute M1-UN-DP48 as standard accessory.

☆ Optional Accessories:

M8-FLASH-TS48	8 sockets Programming Module dedicated for TSOP 48 PINs FLASH.
ADAPTER	Support high pincount devices from 48 to over 300 pins. See ADAPTER LIST on HI-LO Web site.
CONVERTER	Convert signals from DIP to different package types such as PLCC, QFP, SOP, TSOP, BGA,.... etc. See CONVERTER LIST on HI-LO Web site.

1.2 PC System Requirements

- PC/Pentium above.
- Microsoft compatible mouse.
- A hard disk with at least 20 Mbyte free space.
- A CD-ROM drive with speed x2 or above.
- At least one USB port (Version 1.1/2.0)
- Equip 64MB memory space or above.
- Operating System: Windows 98/Me/2000/XP/Server 2003.

1.3 ALL-100 Specification

Device Support	Pin Count : from 8 pins up to over 300 pins Device Type: EPROM,EEPROM,Serial PROM, FLASH, PLD/CPLD/FPGA, MPU/MCU, etc.
Device Contact	Default: DIP48,Textool Others: SOP,TSOP,PLCC,QFP,MLF,SDIP etc. through optional CONVERTERs or ADAPTERs
Max Sockets in parallel	8 sockets on optional GANG Programming Module
Controller	16 bits high-speed controller with big sized FPGA & CPLD
Interface Port	1 x USB port
Data Transfer Rate	USB 1.1 : 12 Mb/s USB 2.0 : 480 Mb/s
Max Sites in parallel	up to 8 via tiered star USB
Functions	Load file,Read Master,Program,Verify,Auto,ID Check, Checksum,Blank Check,Erase,Protect/Unprotect, Secure,Edit,Function Configuration,Self Test
Host Computer Requirements	<ul style="list-style-type: none"> • An Intel Pentium or compatible processor with 64MB of RAM • At least one USB port available (V 1.1/ 2.0) • 20 MB free hard disk space with Windows 98/Me/ 2000/XP/Server 2003 operating system • CD-ROM Drive
Power	AC voltage : 100-240 VAC Frequency : 50-60 Hz Power consumption : 50W
Dimension	L x W x H : 260mm x 150mm x 100mm
Weight	4 kg
Operating Temperature	0- 40 °C (32-105 °F)
Safety Standards	CE Approved

2. Single ALL-100 Installation

2.1 Hardware Installation

Before installation, make sure your PC has USB 1.1/2.0 port which can be connected to ALL-100 Programmer through USB cable. Suggest to use USB 2.0 for fast data transmission with ALL-100 Programmer.



USB 1.1 (Full Speed) : Transmission rate 12 Mb/s

USB 2.0 (High Speed) : Transmission rate 480 Mb/s

Step 1:


Make sure power of Base Unit is in “OFF” state and then positioning and connecting Programming Module onto Base Unit.

See figures below:




Step 2:

Connect programmer and PC as figures below.



Connect the Type B end of USB cable to the USB Type B connector at rear panel of programmer, connect the Type A end of USB cable to the USB Type A connector on the PC.




ALL-100 rear panel

Step 3:


Connect power cable to AC power socket of ALL-100 Programmer and plug in the other end to the outlet of power source (100-240VAC 50-60 Hz).

Power on the ALL-100 from the switch above the AC power socket on the rear panel.



2.2 USB Driver Installation


Insert the Driver Files CD into CD drive, connect USB cable between PC and ALL-100, power on ALL-100 Programmer, the PC will detect the new hardware and a window will open showing “Add New Hardware Wizard” with information “..... USB 2.0 Device”.



Click “Next” to continue.

☆ To do installation under Windows 2000/XP/Server 2003, user needs to change Log-in authority to “Administrator” or “Power-User” in order to install new software/hardware driver.

Select "Search for the best driver for your device"



Click "Next" to continue.

Select "CD-ROM drive" (Insert Driver Files CD into CD drive).




Click "Next" to continue.

PC will allocate files named “ALL100.INF” and “ALL100.SYS” for installation.



Click “Next” to continue.

Windows has finished the USB driver installation for ALL-100 Programmer.



Click "Finish" to complete USB driver installation.

2.3 Software Installation

Insert Driver Files CD to CD-ROM drive, go to directory of ALL-100 under File Manager to execute the SETUP.EXE file, or run the SETUP.EXE from START menu of WINDOWS and follow all steps accordingly as follows:



Check of installed software:


(1) Check if software is installed properly with File Manager, see if XACCESS.EXE, individual IC programming driver, and Utility files exist under C:\Program Files\ALL-100 directory. XACCESS.EXE is a system file which provides an easy way to select IC Manufacturer, Product Type, and the corresponding programming driver. All the programming drivers can also be executed without running XACCESS.EXE file. Each programming driver usually supports a series of relevant ICs. For instance, driver file W28F.EXE is able to program 27C128 ~ 27C512 EPROMs.

(2) When executing programming driver, software will automatically check if ALL-100 Programmer is properly connected. If software can not recognize the existence of ALL-100, the connection and/or installation might have problem and ALL-100 Programmer might not be able to be accessed.




(3) Methods to check if ALL-100 Programmer is properly connected/existed:

1. Run "USB Info." option under XACCESS menu.
2. Run programming driver file under XACCESS menu.



XACCESS.EXE Utility Dialog Box



XACCESS.EXE Information Box

3. ALL-100 Basic Operation

3.1 Getting Started

We will have a brief description of ALL-100 basic operation, introduce how to access the desired IC programming driver through XACCESS, the main system program. We will also introduce functions of Device, Load, Blank check, and Program by taking AMD AM29F200B as example.


☆ For best view of ALL-100 information displayed, user's screen should have resolution 800x600 pixels or above.

3.1.1 Start with XACCESS

Click the icon of XACCESS to activate XACCESS.EXE and get following display on the window.


3.1.2 Select IC Manufacturer

Click "Device" to display IC Manufacturer options. Select "AMD" and click "OK" to display Type List of the selected manufacturer.



3.1.3 Select IC Product Group and Product Type


Select "EEPROM" in Product Group at left side and select "AH29F200B" in Product Type at right side of Type List Dialogue Box and then click "Run".



Main Menu of the Driver File

Main Menu of the Driver File contains three major parts, the first row for menu of main fuctions, the second row for quick function keys, and the rest provides space for dialogue boxes of IC information like IC Manufacturer, Product Type, Adapter needed... etc.

The driver file can be executed without going through XACCESS. In main menu of the driver file, user can reselect IC Manufacturer and Product Type. For example, execute driver file "A28F.EXE" directly and click "Device" to select IC Manufacturer and Product Type to be programmed. See dialogue boxes below.




Remark:

When reselecting IC manufacturer and Product Type, information in dialog box will be updated accordingly and the driver file will be downloaded to ALL-100 Programmer. If message "File not found" appears, it means the driver file is not available in PC, check the attached Driver File CD or visit HI-LO web site at <http://www.hi-lo.com.tw> for S/W download. If a specific ADAPTER is needed, "File not found" might be due to the absence of the required ADAPTER S/W. Try to install the S/W again.

3.2 Load file to Programmer buffer


It is ready for IC programming after selecting IC Manufacturer and Product Type. In general, programming code is saved in a file in Bin/Hex format. This code needs to be loaded to programmer buffer and then programmed into Blank IC devices. To load file to programmer buffer, click “File” menu, select “Load file to Programmer buffer” option, following dialogue box will appear:




Function of file loading is similar to that under Windows environment. Enter the file name to be downloaded and click “Open”, the named file will be loaded to programmer buffer. **Note: Disk drive and file path must be correct.** Select and click the correct drive and folder that the file located to. If it can not be operated by mouse, apply <TAB>, <UP>, <DOWN>, and <ENTER> keys for selecting and confirming.

3.3 Read contents from Master IC to buffer

When programming code is stored in a Master IC, insert the Master IC onto socket, click “Read” button on screen or press “R” key on keyboard to read programming code from Master IC to programmer buffer.




When insert Master IC onto socket, make sure Pin 1 orientation and Pin count positioning is correct as diagram indicated.



☆ Caution! Incorrect IC positioning might cause IC damage or be programmed to an unknown state.

3.4 Program buffer contents to IC

Insert IC to be programmed onto socket, click “Auto” button on screen or press “A” key on keyboard, following dialogue box will appear.



Click “Run” button on screen or “Y” key on keyboard or “YES” on programmer to start programming buffer contents to blank IC.

After programming, system will automatically verify data read from programmed IC with data in programmer buffer. If both data match then the “GOOD” LED will be lit to show a successful programming.

For next IC programming, the “BUSY” LED needs to be off and then insert blank IC onto socket, click “Run” button on screen or “Y” on keyboard or “YES” on programmer to continue programming.

Click “Close” button on screen or <ESC> key on keyboard to go back to main menu.

3.5 ADAPTERs and CONVERTERs

Adequate ADAPTERs and CONVERTERs are available to support various IC types and packages in market such as PLCC, SOP, TSOP, QFP, PGA, ... etc.

■ **ADAPTER:**

Each ADAPTER has 40/48 gold plated pins in DIP layout which can be inserted onto 48 pins ZIF socket on the Programming Module. Each ADAPTER has one (or more) programming file(s) that needs to be loaded to the same directory as XACCESS.

■ **CONVERTER:**

CONVERTER is used to convert signals from DIP package to others like PLCC, SOP, TSOP, ...etc. No extra programming file is needed to work with CONVERTER.


3.5.1 ADAPTER and CONVERTER installation

- **S/W Installation:**

Copy the ADAPTER file(s) attached to the same directory as that for XACCESS file(s).

- **H/W Installation:**


Insert the DIP-layout 40/48 pins of ADAPTER or CONVERTER onto the 48 PIN DIP ZIF socket on the Programming Module and lock it. See diagram below:



4. Multiple ALL-100 Installation

USB interface provides functions like “Plug-and-Play”, auto detection, high expansibility, and high transmission rate (480 Mb/s for 2.0 version). By using these functions, ALL-100 can be installed up to 8 sets and running simultaneously.


After single ALL-100 installation, more ALL-100 Programmers can be installed through either extra USB ports of your PC or USB 2.0 Hub like following diagram.




Multiple ALL-100 installation through USB 2.0 Hub

4.1 Multiple ALL-100 Operation

Multiple ALL-100 operation can increase programming throughput. With Multi-Thread methodology, each programmer can operate independently. The diagram below shows there are two ALL-100 Programmers (Site #0 and Site #1) are running programming.



Site # setting switch is located on the rear panel of ALL-100 Programmer. Valid Site # for Multiple ALL-100 setup is 0-7 and can not have the same Site # in whole system.



When running ALL-100 programming software, system will automatically detect and load necessary driver S/W and also download programming code to ALL-100 through USB port. Operation of multiple ALL-100 is basically the same as that of single ALL-100. There are two operation modes for multiple ALL-100 programming, synchronous operation and asynchronous operation.

After entering programming mode on screen, user can choose either of following two operation modes depending on production needs:

■ **Synchronous operation:**


Run programming on all the ALL-100s at the same time. Put ICs onto socket of each ALL-100, press "Y" key on PC keyboard. All ALL-100s will start programming simultaneously.

■ **Asynchronous operation:**


Run programming on each ALL-100 one after another. Put IC on the 1st ALL-100, press <YES> on that programmer to start programming, then put another IC on the 2nd ALL-100, press <YES> on that programmer to start programming, then the 3rd one ... and so on.

4.2 Read/Compare on Multiple ALL-100s

To perform Read/Compare function under Multiple ALL-100 setup, only Site #0 is valid. This means that only IC on Site #0 can be read/Compared under Multiple ALL-100 setup.



Read Dialogue Box



Compare Dialogue Box

5. ALL-100 Gang Option Installation

For further speed up programming for volumes of ICs, 8 sockets Programming Module option is available. Contact your local HI-LO agent for ordering information.


ALL-100 Gang Programmer is an ALL-100 Base Unit with 8 sockets Programming Module put on the top. User can choose either Single ALL-100 Gang operation or Multiple ALL-100 Gang operation for mass programming. The S/W attached with 8 sockets Programming Module is used for ALL-100 Gang as well as Multiple ALL-100 Gang operation. The installation /operation is similar as what is stated above.

☆ Due to more information to be displayed on screen for Gang operation, user's screen resolution needs to be 1024x768 pixels (SVGA mode) or above.



5.1 ALL-100 Gang Operation

ALL-100 Gang Programmer ties IC pin count in parallel, drive programming and control signals through FPGA to program ICs on all sockets simultaneously. The diagram below shows there is one ALL-100 Gang Programmer (Site #0) is running programming.




Up to 8 sets of ALL-100 Gang Programmer can be connected to PC through USB interface, this is so call "Multiple ALL-100 Gang Setup". Each ALL-100 Gang can program 8 ICs. One PC with 8 sites of ALL-100 Gang setup can program $8 \times 8 = 64$ ICs.

5.2 Read/Compare on Multiple ALL-100 Gangs

To perform Read/Compare function under Multiple ALL-100 Gang operation, only IC on **MASTER** (Socket #1) of **Site #0** Gang programmer is valid. This means that only the 1st IC on **MASTER** (Socket #1) of the **1st site (Site #0)** Gang Programmer can be read/compared under Multiple ALL-100 Gang setup.

Put IC to be read/compared onto **MASTER** (Socket #1) of **Site #0** Gang Programmer and click Read/Compare keys on screen.


☆ Refer paragraph 4.1 for setting of Site # for Gang Programmer.



6. ALL-100 Software Description

6.1 XACCESS User Interface

System Software “XACCESS” is an interface guiding user to locate the driver software for product type to be programmed. XACCESS also provides File Management Utilities as well as Data Base of programmable IC products.




6.2 Utilities:

File Management Utilities includes Hex to Bin Converter, Bin to Hex Converter, 2-way splitter, 4-way splitter, 2-way shffler, and 4-way shuffler, ...etc.


6.2.1 Hex to Bin Converter

Convert data from Hex format to Binary format for programmer Read/Write.




6.2.2 Bin to Hex Converter

Convert data from Binary format to Hex format.



6.2.3 2-way splitter

Split one file into two output files. One file contains odd-byte data of the original file and the other file contains even-byte data of the original file.




Split Data Format:

Normally the split data is in Byte Wide, however, user can choose Word Wide (two bytes) or Double Word Wide (four bytes) as unit of data split.

6.2.4 4-way splitter

Split one file into four output files. The 1st file contains the 1st byte of every 4-byte data segment of the original file. The 2nd, 3rd, and 4th file contains the 2nd, 3rd, and 4th byte of every 4-byte data segment of the original file.




Split Data Format:

Normally the split data is in Byte Wide, however, user can choose Word Wide (two bytes) or Double Word Wide (four bytes) as unit of data split.

6.2.5 2-way shuffler

Combine two files into one. Insert data of Even file into even byte position of the combined file and insert data of Odd file into odd byte position of the combined file.




Shuffle Data Format:

Normally the shuffled data is in Byte Wide, however, user can choose Word Wide (two bytes) or Double Word Wide (four bytes) as unit of data shuffle.

6.2.6 4-way shuffler

Combine four files into one. Insert data of 1st file into the 1st byte of every 4-byte data segment of the combined file, insert data of 2nd, 3rd, and 4th file into the 2nd, 3rd, and 4th byte of every 4-byte data segment of the combined file.




Shuffle Data Format:

Normally the shuffled data is in Byte Wide, however, user can choose Word Wide (two bytes) or Double Word Wide (four bytes) as unit of data shuffle.

6.2.7 Version List

List version number of current programming software.



Version List

6.2.8 Cross Reference

List the Cross Reference of IC Mfr., Product Type, and the corresponding programming software.


The screenshot shows the 'Cross Reference' window in the ALL-100 Universal Programmer software. The window title is 'Cross Reference' and it has a menu bar with 'Print', 'Save', and 'Close'. The table below lists various IC manufacturers and their corresponding programming software files and adapters.

Mfr.	Type	File	Adaptor
ICT	PEEL22CV10A2+	WPLD1.EXE	
ICT	PEEL22CV10Z	WPLD1.EXE	
ICT	PEEL22CV8	WPLD1.EXE	
ICT	PEEL22LV10A2+	WPLD1.EXE	
ICT	PEEL253	WPLD1.EXE	
ICT	PEEL273	WPLD1.EXE	
IDT	78C16A	WMEM1.EXE	
IMT	IM29FD02B	WMEM1.EXE	
IMT	IM29FD02T	WMEM1.EXE	
IMT	IM29FD04B	WMEM1.EXE	
IMT	IM29FD04T	WMEM1.EXE	
INTEL	27010	WMEM1.EXE	
INTEL	27C010	WMEM1.EXE	
INTEL	27C010A	WMEM1.EXE	
INTEL	27C011	WMEM1.EXE	
INTEL	27C020	WMEM1.EXE	
INTEL	27C040	WMEM1.EXE	
INTEL	27C080	WMEM1.EXE	
INTEL	27C100	WMEM1.EXE	

Cross Reference


6.2.9 Device List

List all device types that are programmable at current version.




6.3 Programming Data/ Function Description

Programming software includes loading of programming driver, utilities of data management, and control of programming function/operation. Each programmable IC needs correct functional setup before programming. User needs to refer IC data sheet and/or application software for proper setup of programming function. See description below by taking AMD AM29F200B IC as example.





6.3.1 File


Load/Save of data file and configuration file. See dialogue boxes below.



(1) Dialogue boxes of load data file:




(2) Dialogue box of save data file:




(3) Dialogue boxes of load/save Programming Configuration file:

The Programming Configuration file contains all programming related data setup by user. It includes programming driver, data file, programming functional setting, and serial number setting. User can save Programming Configuration file for load it back next time for programming without re-setting of programming function and serial number.




Programming Configuration file to be loaded



Programming Configuration file to be saved


(4) Dialogue box of enable Job Function:

Once user enable Job Function and followed by loading Program Configuration file, system will enter <AUTO> programming mode and is ready for programming. User needs not re-do the programming functional setting and serial number setting.




6.3.2 Edit

Includes edit and address of programming data. See dialogue box below.




(1) Edit data:

Provide functions such as Fill, Jump, Swap, Calc, SUM, Search,... etc for user to edit programming data in Hex and ASC II expressions.




(2) Fill:

Specify start and end addresses and data to be filled in, then click "OK", data will be filled into the specified area.




(3) Jump:

Specify the start address to jump to, then click "OK", system will jump to the specified address with data displayed.




(4) Move:

Specify start and end addresses in which data to be moved, also specify the destination address to move to, then click "OK", system will move data between specified addresses to the destination area.




(5) Swap - Byte:

Specify start and end addresses in which data to be byte-swaped, then click "OK", system will swap byte for data between specified addresses.




(6) Swap - Nibble:

Specify start and end addresses in which data to be nibble-swaped, then click "OK", system wil swap Nibble for data between specified addresses.




(7) CalcSum:

Specify start and end addresses in which data to be calculated for checksum and then click "OK", system will calculate and display result (checksum) on screen.



(8) Search:



Two options available, search ASC II data or search Binary data.



The screenshot shows a hex editor window titled "WA20F EXE - Chen_ou.cab". The editor displays a list of memory addresses from 000000 to 0001E0. Each address is followed by its hexadecimal value and its corresponding ASCII character. The ASCII values are displayed in a monospaced font, with some characters appearing as symbols or control characters. The editor has a menu bar with options like File, Edit, Database, Operation, USB Info, and About. The status bar at the bottom shows the current address being viewed, which is 0001E0.


ADDR	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F	0123456789ABCDEF
000000	D4	35	34	64	00	00	00	00	BD	00	00	00	00	00	00	00	5d.....
000010	03	81	00	00	00	00	00	00	10	10	00	A2	00	40	00	000.....g.
000020	F5	47	00	00	00	81	00	00	1E	70	03	28	70	DD	00	00p.(p.
000030	20	10	00	13	C0	03	A0	60	A2	68	84	68	7F	D0	20	00h.h.
000040	50	03	04	60	A0	B2	60	10	A0	28	73	20	10	40	00	00g.(s.g.
000050	23	03	03	C0	60	A0	B2	60	10	40	10	28	73	20	10	H.....g.(s.	
000060	91	03	02	03	C0	60	A0	B2	68	84	68	7F	D0	20	50	50h.h..PP
000070	00	40	01	4B	78	AC	94	8E	64	7F	B6	8B	F7	AE	86	6Cg.Kx...d....I
000080	C8	46	80	04	20	60	40	03	20	10	AC	03	20	10	47	00g.....G.
000090	30	20	10	20	20	01	60	73	C6	00	AA	00	46	A8	11	FCe.....F...
0000A0	8B	4D	AA	C5	53	4F	03	D0	60	90	A2	68	84	68	7F	D0H..50.....h.h.
0000B0	10	10	40	50	00	03	61	13	41	02	21	60	30	55	40	30BP...a.A...00B0
0000C0	31	80	25	F6	F6	47	02	14	76	56	E6	36	37	03	E1	71G...u.G...q
0000D0	D0	93	63	03	53	23	83	23	23	03	23	53	93	A5	71	D0c.S.H.H.S...q.
0000E0	33	93	13	23	33	13	23	33	53	93	53	A5	03	61	13	3.#3.#3S...a.
0000F0	41	03	21	60	30	55	40	30	21	B0	25	F6	F6	47	02	1400B01.Z...G.
000100	76	56	E6	36	37	03	53	03	D0	60	90	A2	68	84	68	7Fu.G...h.h.
000110	D0	10	10	10	50	00	30	A4	00	03	74	20	04	18	55	22P...t...U"
000120	9B	A8	4A	F6	DE	6D	7E	9D	66	F0	55	CB	7D	DC	5D	CBJ...m".f.U.).
000130	E4	04	20	12	2A	1B	7F	78	03	58	E5	2D	2F	44	98	CDx.X.../D...
000140	89	57	6B	8F	64	F5	24	6B	D9	32	63	80	ED	45	F0	DCk..d.\$k.Ze...E...
000150	D8	F1	99	A2	01	85	11	BC	04	BC	5B	74	14	20	30	10[.Z..0.
000160	00	10	3A	18	E9	03	18	B9	03	05	60	30	55	40	30	4000B00
000170	94	31	74	64	F6	27	02	A5	56	37	47	36	E6	76	02	05	1td...EUTG...U...
000180	57	27	07	F6	37	56	37	02	F4	E6	C6	97	02	35	16	06W...TUF...S.
000190	07	C6	56	02	35	F6	66	47	77	16	27	56	02	05	57	26U.S.fgw...U..M2
0001A0	C6	96	37	86	96	E6	76	02	34	27	56	46	56	E6	47	36u.u'UFU.G.
0001B0	16	C6	37	02	14	76	56	E6	36	97	03	74	60	30	55	01T..uU.G...t'0U.
0001C0	10	40	04	03	E3	05	01	21	HE	30	D2	60	D1	D1	F4	00g.....W.....
0001D0	D8	16	12	CD	61	46	36	1A	81	03	61	13	41	03	21	60af6...a.A...f
0001E0	30	55	40	30	31	B0	25	F6	F6	47	02	14	76	56	E6	36	00B01.Z...G...uU.G.

Specify start/end addresses and data to be searched, then click "OK", system will search data between specified addresses and list all addresses that match data to be searched.





(9) Print:

Two options available, print to printer or output to file.




```
WAZBF EXE - Chiter_nw.cab
File Edit Services View Window Help
+ Editor
Fill Jump Move Snap CalcSum Search Dnd Edit
ADDR 0 1 2 3 4 5 6 7 8 9 A B C D E F 0123456789ABCDEF
000140 B9 57 6B BF 64 F5 24 6B 1 To Printer ED 45 F0 DC .Mk.d.$k.Zc...E..
000150 DB F1 99 A2 01 85 11 8C 04 BC 5B 7A 14 20 30 10 ..... [Z 0
000160 00 10 3A 18 E3 03 18 89 03 05 60 30 55 40 30 40 ..... 0UB0B
000170 94 31 74 64 F6 27 02 05 56 37 47 96 E6 76 02 05 ...1td...EUTG...U...
000180 57 27 07 F6 37 56 37 02 F4 E6 C6 97 02 35 16 D6 M...7U7...S...
000190 07 C6 56 02 35 F6 66 47 77 16 27 56 02 09 57 26 ...U.S.FGw...U...M8
0001A0 C6 96 37 66 96 E6 76 02 34 27 56 46 56 E6 47 96 ...7...4UFU.G.
0001B0 16 C6 37 02 14 76 56 E6 36 97 03 74 60 30 55 01 ...7...U6...T...OU...
0001C0 10 40 04 03 E3 08 01 21 4E 90 D2 60 D1 D1 F4 00 ...0...IN...
0001D0 D8 16 12 CD 61 46 36 1A 81 03 61 13 41 03 21 60 ...aF6...a...A...F...
0001E0 30 55 40 30 31 80 25 F6 F6 47 02 14 76 56 E6 36 0UB01 7...E...U...6
0001F0 97 28 01 60 73 C6 00 AA 00 46 A8 11 FC 88 4D AA (...e...F...M...
000200 C5 53 4F 03 D0 60 90 A2 68 84 68 7F D0 10 10 40 ...S0...h...h...
000210 50 00 30 14 00 D2 E2 E3 B7 98 24 98 F3 8A 12 71 P.0...$...q...
000220 AF 0F 5F 3C 58 80 26 96 05 9C CD 1C 3B AF 0F 4C ...V.8...L...
000230 F6 F6 46 A9 DB 7E D1 52 86 27 38 76 DB 65 0B D8 ...F...R...8u...e...
000240 10 DB A2 7F CC B4 DB 78 5A AB 78 02 C4 24 11 14 ...x2...x...$...
000250 DA 01 71 83 C8 03 28 10 0F 03 28 10 A9 0A 30 20 ...q... (...0
000260 10 20 20 01 75 14 50 9C 0A 00 40 90 11 00 C6 32 ...u.P...8...
000270 24 A8 F9 2F 03 D0 60 90 A2 68 84 68 7F D0 10 10 $.../.h...h...
000280 40 50 00 03 61 13 41 03 21 60 30 55 40 30 31 80 0P...a...A...f...0u001...
000290 25 F6 F6 47 02 14 76 56 E6 36 97 03 E1 71 D0 93 %...G...U...6...q...
0002A0 73 03 13 13 23 03 33 03 93 23 83 A5 71 D0 33 93 9...M.S...H...q...3...
0002B0 13 23 33 13 23 33 53 93 53 93 A5 03 72 13 52 03 .H3.H35.S...P...R...
0002C0 32 60 30 55 40 30 31 C1 94 54 02 24 54 45 14 02 2'0UB01...T...STE...
0002D0 34 56 27 47 96 66 97 96 E6 76 02 14 57 47 86 F6 4U'G.F...U...MG...
0002E0 27 96 47 97 03 85 03 00 60 90 A2 68 84 68 7F D0 ...G...h...h...
0002F0 10 10 10 50 00 30 A4 00 03 74 20 04 16 AF 3C 2B ...P.O...t...<+...
000300 2A ED 30 83 F1 60 9F 60 5A B8 2B 1C E3 51 51 F7 M.O...Z...+...00...
000310 CA C0 9B 46 06 AD 0D 5F 1E F9 CE A0 E0 A5 12 9F ...F...
000320 EB 69 C1 3F 75 55 65 23 E2 49 E2 3E A1 68 F6 59 ...i...puUeH.I...>...h...V
```

Specify start/end addresses and then click "OK", system will print/save data between specified addresses to printer/output file.




(10) Modify Programmer Buffer Mapping:



Example:


Program data from Buffer address \$00000 - \$0FFFF to Device address \$10000 - \$1FFFF.

	Start....End	
Device :	<input type="text" value="10000"/>	<input type="text" value="1FFFF"/>
Buffer :	<input type="text" value="00000"/>	<input type="text" value="0FFFF"/>



6.3.3 Operation

Different IC product type might have different options of programming functions. Basically, programming functions include options of Erase, Blank, Program, Verify, Lock, Auto, ...etc.



Functional options for Device AM29F200B

User can also click <Fast Key> to execute program functions. See <Fast Key> indicated below:




Fast key for Device AM29F200B

(1) Read:

Read contents in IC memory. Read function is only valid for IC on following position.


- Single ALL-100 setup: The IC on the socket.
- Multiple ALL-100 setup: The IC on socket of Site #0 programmer
- Single ALL-100 Gang setup: The IC on Socket #1 of Gang programmer.
- Multiple ALL-100 Gang setup: The IC on the 1st Socket (Socket #1) of the 1st Site (Site #0) Gang programmers.



☆ After Read operation, suggest user to double-check to confirm checksum and the data read are all correct.


(2) Auto:

Enter programming mode with all programming functions activated.




☆ Different IC product type might have different programming functional setting and parameter setting. User needs to refer IC data sheet for proper settings of programming functions and programming parameters.


- Parameter: Special setting for programming if needed.




- Result button: Button to display programming result and elapsed time.



-
-
- (3) Erase : Enter programming mode with Erase function activated.
Blank : Enter programming mode with Blank check activated.
Program : Enter programming mode with Program function activated.
Verify : Enter programming mode with Verify function activated.
Protect : Enter programming mode with Protect function activated.






Program & Verify options

ID Check option


6.3.4 USB Info.

Display current ALL-100 connection status through USB interface.



6.3.5 About

Display model number of current programmer and version number of programming driver.



7. ALL-100 Troubleshooting

After power on, ALL-100 will run self diagnostics and USB connection check. Green/Red LED will display test result. Table listed below summarize test result with possible causes/dispositions for troubleshooting.

Condition	Possible cause/Dispositions
After power on, Green and Red LED off.	Poor contact / operation abnormal: 1. Check power cable connection. 2. Need troubleshooting. Contact your local dealer for service.
After power on, Green and Red LED flash.	Fail self diagnostic test: 1. Check if there is IC on socket (Should be removed). 2. Need troubleshooting. Contact your local dealer for service.
After power on, Green LED off but Red LED flash.	Fail ALL-100 memory diagnostic test: 1. Try to power on again. 2. Need troubleshooting. Contact your local dealer for service.
After power on or during programming, Green LED flash but Red LED off.	Fail USB connection check: 1. Check USB cable connection. 2. Check PC BIOS setup to see if USB is disabled (Should be enabled). 3. Need troubleshooting. Contact your local dealer for service.
During programming, Green LED on but Red LED flash.	USB communication error: 1. Check USB cable connection. 2. Need troubleshooting. Contact your local dealer for service.
During programming, Green LED on but Red LED become orange color.	USB data transmission interrupted: 1. Check USB cable connection. 2. Check if PC is interrupted. 3. Need troubleshooting. Contact your local dealer for service.

8. Glossary

8.1 EPROM, EEPROM, BPROM, and MPU

Programmable device: An integrated circuit (IC) that can be programmed.

■ Bit, Nibble, Byte, Word, Double Word

Bit : A basic unit of binary data.

Nibble : A group of 4-bit binary data. A nibble ranges from 0H to FH.

Byte : A group of 8-bit binary data. A byte ranges from 0H to FFH.

Word : A group of 16-bit binary data. A word ranges from 0H to FFFFH.

Double word : A group of 32-bit binary data. A double word ranges from 0H to FFFFFFFFH.

■ Buffer

There is 4 Mbit memory buffer in ALL-100 Programmer. IC driver file can automatically allocate/arrange these 4Mbit memory space for programming depending on IC memory size and read/write needs.

When data needs to be programmed to IC, data needs to be loaded to programmer buffer first and then program to IC.

When data is read from Master IC, the data is also stored in programmer buffer, it can then be edited or saved to disk for future use.

- **Buffer Start and Buffer End Address**

It specifies the start and end addresses in programmer buffer in which data is to be programmed to IC in sequence. This is also the area that data is used for Checksum calculation.

- **Checksum**

This is the SUM of all data contents between buffer start and buffer end addresses. All data are added and the least significant 16 bits (4 HEX) are displayed as the Checksum. (Some data in some ICs might not be covered in Checksum calculation.) Checksum will be calculated after IC reading, file loading, type changing, or buffer editing.

- **Bit Count of data**

A NIBBLE contains 4-bit data.

A BYTE contains 8-bit data.

A WORD contains 16-bit data.

MPU is normally in 8 or 16 bit width, but still have some in 12 or 14 bit width.

- **Device Start and Device End address**

It specifies the start and end addresses inside IC device. During IC programming, data stored in programmer buffer will be written to this specified area.

- **USB interface**

USB, Universal Serial Bus, is a high speed data transmission bus initiated by Intel and then supported by NEC, IBM, MicroSoft, Compaq,...etc. It is now a data transmission standard between PC and peripheral devices.

V1.0 / 1.1 USB Low-Speed : 1.5 Mb/s

V1.0 / 1.1 USB Full-Speed : 12 Mb/s

V2.0 USB High-Speed : 480 Mb/s

- **Security fuse**

Security fuse is available in most of programmable ICs. Once the Security fuse has been blown, the data stored in IC can not be read out correctly and IC can not be programmed either. However, IC can still operate functionally no matter the Security fuse has been blown or not.

Note: Once the Security fuse has been blown. IC data can no longer be read out or programmed correctly, please double-check before programming Security fuse.

- **Lock bits**

Some MCU/MPU use Lock bits to protect data programmed. Normally user has options to select individual Lock bit to protect different area of memory data. Please refer IC data sheet for definition of Lock bits.

- **Encryption**

Some MCU/MPU use Encryption code for data protection. If an IC has been programmed with Encryption code, then a correct decryption code must be given to read the correct data.

- **Protection Fuse**

Some FLASH memory use Protection fuse for data protection. It can prevent data change from accident programming. The Protection fuse must be reset to Unprotection state, if the programmed data need to be changed. The default state of Protection fuse is Unprotection.

8.2 PLD, PAL, GAL, PEEL, CPLD, EPLD, and FPGA

■ Programmable Logic Device (PLD)

PLDs are usually grouped into following five categories:

PLD : A one time Programmable Logic Device such as PAL.

EPLD : A UV Erasable PLD such as EPLD, CPLD, and FPGA.

These devices have transparent window on top of package for UV light exposure.

EEPLD : An Electrically Erasable PLD such as GAL, PEEL, CPLD, and FPGA.

CPLD : A more complex PLD device.

FPGA : Field Programmable Gate Array.

■ JEDEC fuse map file of PLD

JEDEC fuse map file is a standard format used for PLD programming. It contains fuse information and functional test vectors of PLD to be programmed. Most PLD assemblers or compilers such as PALASM, OPAL, CUPL, ABEL, AMAZE, and PDK-1, can create JEDEC fuse map file.

■ POF fuse map file of PLD

POF fuse map file is a format used for ALTERA PLD programming. POF file can store more programming data than JEDEC file.

- **Fuse blown and intact**

Most of unprogrammed (blank) PLD have fuses in intact (connect) state. After programming, PLD fuses are blown to open state. For one time programmable PLD, once fuses are blown (opened), they can not be changed back to intact (connect) state. However, the UV erasable PLD can be erased to change fuses back to intact (connect) state by UV light exposure and the electrically erasable PLD can be electrically erased to change fuses back to intact (connect) state by using Erase function on this Programmer.

- **Array fuse, Configuration fuse**

Array fuses are the main logic fuses in a PLD. Different types of PLD have different logic function arrangement. Configuration fuses define the I/O architecture of a PLD such as Combinatorial/Registered, Output feedback/Output enable, and so on. Generally, user do not have to understand the details of these fuses because logic compiler will automatically translate logic statements and equations into JEDEC format file.

- **Security fuse**

Most of PLD have Security fuse. Once Security fuse is blown, data in PLD can no longer be read out correctly. Generally, the PLD will be read as blank if Security fuse is blown.

Note: