

## **User's Note** **For the *MIC-3318 series*** ***CompactPCI CPU Modules***

1<sup>st</sup> Ed.

February, 2004

P/N: 2003331801


This document is an addendum for the *User's Manual of the MIC-3318* (P/N: 2003331800) that has some supplementary recommendations for the usage of RS-485 transmission mode and CompactFlash slot.

### **Use RS-485 Mode with Serial ports**

The RS-485 transmission mode of the serial ports only supports the RTS control. If an Auto Flow Control is needed, please consider to use the RS-232 mode with an external communication module like ADAM-4520, or use an add-on CompactPCI communication module like MIC-3612. For more detailed information regarding the ADAM-4520 and MIC-3612, please refer to the Advantech website: <http://www.advantech.com>.

### **Remove the CompactFlash Card**

MIC-3318 is equipped with a CompactFlash slot on the component side of the mainboard (1F-CN2). In order to remove the CompactFlash card from the mainboard smoothly, it is recommended that you use a tool such as a tweezers or a nippers to help removing the card.



*CompactFlash slot of MIC-3318*