




***DATA TRANSLATION***

*UM-23654-D*

***User's Manual  
for USB Measurement  
Instruments***

***(TEMPpoint™, VOLTpoint™,  
and MEASURpoint™)***



**Fourth Edition**  
**May, 2010**

**Copyright © 2009 - 2010 by Data Translation, Inc.**  
All rights reserved.

Information furnished by Data Translation, Inc. is believed to be accurate and reliable; however, no responsibility is assumed by Data Translation, Inc. for its use; nor for any infringements of patents or other rights of third parties which may result from its use. No license is granted by implication or otherwise under any patent rights of Data Translation, Inc.

Use, duplication, or disclosure by the United States Government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer software clause at 48 C.F.R, 252.227-7013, or in subparagraph (c)(2) of the Commercial Computer Software - Registered Rights clause at 48 C.F.R., 52-227-19 as applicable. Data Translation, Inc., 100 Locke Drive, Marlboro, MA 01752.

Data Translation, Inc.  
100 Locke Drive  
Marlboro, MA 01752-1192  
(508) 481-3700  
[www.datatranslation.com](http://www.datatranslation.com)  
Fax: (508) 481-8620  
E-mail: [info@datx.com](mailto:info@datx.com)

Data Translation® is a registered trademark of Data Translation, Inc. MEASURpoint™, TEMPpoint™, VOLTpoint™, ISO-Channel™, and Measure Foundry™ are trademarks of Data Translation, Inc.

All other brand and product names are trademarks or registered trademarks of their respective companies.

## Radio and Television Interference

This equipment has been tested and found to comply with CISPR EN55022 Class A and EN61000-6-1 requirements and also with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at his own expense.

Changes or modifications to this equipment not expressly approved by Data Translation could void your authority to operate the equipment under Part 15 of the FCC Rules.

---

**Note:** This product was verified to meet FCC requirements under test conditions that included use of shielded cables and connectors between system components. It is important that you use shielded cables and connectors to reduce the possibility of causing interference to radio, television, and other electronic devices.

---

## Canadian Department of Communications Statement

This digital apparatus does not exceed the Class A limits for radio noise emissions from digital apparatus set out in the Radio Interference Regulations of the Canadian Department of Communications.

Le présent appareil numérique n'émet pas de bruits radioélectriques dépassant les limites applicables aux appareils numériques de la class A prescrites dans le Règlement sur le brouillage radioélectrique édicté par le Ministère des Communications du Canada.



---

# Table of Contents

<b>About this Manual</b> .....	<b>9</b>
Intended Audience .....	9
How this Manual is Organized .....	9
Conventions Used in this Manual .....	10
Related Information .....	10
Where To Get Help .....	11
<b>Chapter 1: Overview</b> .....	<b>13</b>
Hardware Features .....	14
TEMPpoint Features .....	14
VOLTpoint Features .....	15
MEASURpoint Features .....	16
Supported Software .....	18
Accessories .....	19
Getting Started Procedure .....	20
<b>Part 1: Getting Started</b> .....	<b>21</b>
<b>Chapter 2: Preparing to Use the Instrument</b> .....	<b>23</b>
Unpacking .....	25
Checking the System Requirements .....	26
Installing the Software .....	27
Viewing the Documentation .....	28
<b>Chapter 3: Setting Up and Installing the Instrument</b> .....	<b>29</b>
Applying Power .....	31
Attaching the Instrument to the Computer .....	33
Connecting Directly to the USB Ports .....	33
Connecting to an Expansion Hub .....	35
Configuring the Device Driver .....	37
<b>Chapter 4: Wiring Signals</b> .....	<b>39</b>
General Wiring Recommendations .....	41
Warm-Up Time .....	42
Connecting Thermocouple Inputs .....	43
Connecting RTD Inputs .....	45
4-Wire RTD Connections .....	46
3-Wire RTD Connections .....	46
2-Wire RTD Connections .....	47
Connecting Voltage Inputs .....	49

Connecting Voltage Inputs to Thermocouple Channels . . . . .	49
Connecting Voltage Inputs to RTD Channels . . . . .	50
Connecting Voltage Inputs to High Voltage Channels . . . . .	50
Connecting Current Loop Inputs . . . . .	53
Connecting Current Loop Inputs to Thermocouple Channels . . . . .	53
Connecting Current Loop Inputs to RTD Channels . . . . .	54
Connecting Current Loop Inputs to High Voltage Channels . . . . .	56
Connecting Digital I/O Signals . . . . .	58
Connecting Digital Input Signals . . . . .	59
Connecting Digital Output Signals . . . . .	60
<b>Chapter 5: Verifying the Operation of Your Instrument . . . . .</b>	<b>61</b>
Overview . . . . .	63
Running the Measurement Application . . . . .	64
Changing the Configuration of Your Instrument . . . . .	67
Defining Alarm Limits . . . . .	69
Logging Data to Disk . . . . .	71
Viewing a Data File . . . . .	73
Reading Digital Input Values . . . . .	74
Exiting from the Measurement Application . . . . .	75
<b>Part 2: Using Your Instrument . . . . .</b>	<b>77</b>
<b>Chapter 6: Principles of Operation . . . . .</b>	<b>79</b>
Block Diagrams . . . . .	80
DT9871U Block Diagram . . . . .	80
DT9871 Block Diagram . . . . .	81
DT9872 Block Diagram . . . . .	82
DT9873 Block Diagram . . . . .	83
DT9874 Block Diagram . . . . .	84
Analog Input Features . . . . .	85
Analog Input Channels . . . . .	85
Thermocouple Input Channels . . . . .	86
Cold Junction Compensation . . . . .	87
Open Thermocouple Detection . . . . .	87
RTD Channels . . . . .	88
Input Ranges . . . . .	88
Out of Range Data for Thermocouple Channels . . . . .	89
Out of Range Data for RTD Channels . . . . .	90
Out of Range Data for High Voltage Channels . . . . .	90
Resolution . . . . .	90
Calibration . . . . .	90

Sample Clock Source .....	91
Trigger Source .....	91
Conversion Modes .....	92
Specifying Analog Input Channels .....	92
How Continuous Scan Works .....	92
Filtering.....	93
Data Format .....	93
Data Format for Thermocouple Channels .....	94
Data Format for RTD Channels .....	94
Data Format for High Voltage Channels .....	94
Error Conditions .....	94
Digital I/O Features.....	96
Digital Input Lines .....	96
Digital Output Lines.....	97
Channel-to-Channel Isolation.....	97
Resolution.....	97
Operation Modes.....	97
<b>Chapter 7: Troubleshooting .....</b>	<b>99</b>
General Checklist .....	100
Technical Support .....	102
If Your Instrument Needs Factory Service .....	103
<b>Appendix A: Specifications .....</b>	<b>105</b>
Basic Instrument Specifications .....	106
Thermocouple Specifications .....	107
System Temperature Error for the DT9871U and DT9874 .....	108
System Temperature Error for the DT9871 .....	109
RTD Specifications .....	111
Isolation and Protection Specifications .....	112
Memory Specifications .....	113
Temperature Stability Specifications .....	114
Voltage Measurement Specifications .....	115
Digital I/O Specifications .....	117
Power, Physical, and Environmental Specifications .....	118
Regulatory Specifications .....	119
Connector Specifications.....	120
Thermocouple Connectors.....	120
RTD Connectors .....	120
High Voltage Connectors .....	120
<b>Appendix B: Connector Pin Assignments .....</b>	<b>121</b>

**Appendix C: About ISO-Channel Technology . . . . . 123**

ISO-Channel Technology . . . . . 124

Why ISO-Channel Technology is Your Best Return on Investment . . . . . 125

    Understanding Ground Loops . . . . . 125

    ISO-Channel Eliminates Ground Loops and Increases Common-Mode Rejection . . 126

        Floating, Differential Signals . . . . . 127

        Simultaneous Architecture . . . . . 128

        Channel-to-Channel Isolation . . . . . 129

    Summary . . . . . 130

Floating Signal Inputs Offer New Application Advantages . . . . . 131

    Isolating Each Input . . . . . 132

    New Application Derived from Isolated Channels . . . . . 135

    Summary . . . . . 136

**Index . . . . . 137**

# About this Manual

TEMPpoint™ is a family of temperature measurement instruments that includes the DT9871U, DT9871, DT8871U, DT8871, DT9872, and DT8872. This manual describes the DT9871U, DT9871, and DT9872 USB models.

VOLTpoint™ is a family of voltage measurement instruments that includes the DT9873 and DT8873. This manual describes the DT9873 USB model.

MEASURpoint™ a family of mixed temperature and voltage measurement instruments that includes the DT9874 and DT8874. This manual describes the DT9874 USB model.

---

**Note:** For information on the LXI models of TEMPpoint, VOLTpoint, and MEASURpoint, refer to the *User's Manual for LXI Measurement Instruments*.

---

The first part of this manual describes how to install and set up your instrument, and verify that the instrument is working properly.

The second part of this manual describes the features and capabilities of your instrument using the IVI-COM instrument driver software. Troubleshooting information is also provided.

---

**Note:** If you are programming the instrument using the IVI-COM driver, refer to the DtxMeasurement IVI-COM driver online help for more information.

If you are using Measure Foundry to program your instrument, refer to the *Measure Foundry User's Manual* and online help for more information.

---

## Intended Audience

This document is intended for engineers, scientists, technicians, or others responsible for using and/or programming a TEMPpoint, VOLTpoint, or MEASURpoint instrument in the Microsoft® Windows® XP, Windows Vista®, or Windows 7 operating system. It is assumed that you have some familiarity with thermocouples, RTDs, and/or voltages and that you understand your application.

## How this Manual is Organized

This manual is organized as follows:

- [Chapter 1, "Overview,"](#) summarizes the major features of the TEMPpoint, VOLTpoint, and MEASURpoint instruments, as well as the supported software and accessories.
- [Chapter 2, "Preparing to Use the Instrument,"](#) describes how to unpack the instrument, check the system requirements, install the software, and view the documentation online.

- [Chapter 3, “Setting Up and Installing the Instrument,”](#) describes how to apply power to the instrument and connect the instrument to the network.
- [Chapter 4, “Wiring Signals,”](#) describes how to wire signals to the instrument.
- [Chapter 5, “Verifying the Operation of Your Instrument,”](#) describes how to verify the operation of the instrument using the Measurement Application.
- [Chapter 6, “Principles of Operation,”](#) describes the analog input and digital I/O features of the TEMPpoint, VOLTpoint, and MEASURpoint instruments in detail.
- [Chapter 7, “Troubleshooting,”](#) provides information that you can use to resolve problems with your instrument, should they occur.
- [Appendix A, “Specifications,”](#) lists the specifications of the TEMPpoint, VOLTpoint, and MEASURpoint instruments.
- [Appendix B, “Connector Pin Assignments,”](#) describes the pin assignments of the digital I/O connector on the TEMPpoint, VOLTpoint, and MEASURpoint instruments.
- [Appendix C, “About ISO-Channel Technology,”](#) describes the benefits of ISO-Channel™ technology.
- An index completes this manual.

## Conventions Used in this Manual

The following conventions are used in this manual:

- Notes provide useful information or information that requires special emphasis, cautions provide information to help you avoid losing data or damaging your equipment, and warnings provide information to help you avoid catastrophic damage to yourself or your equipment.
- Items that you select or type are shown in **bold**.

## Related Information

Refer to the following documents for more information on using a TEMPpoint, VOLTpoint, or MEASURpoint instrument:

- DtxMeasurement IVI-COM Driver online help. For programmers who are developing their own application programs using a tool other than Measure Foundry, this document describes how to use the IVI-COM driver to access the capabilities of a TEMPpoint, VOLTpoint, or MEASURpoint instrument.

The IVI-COM driver works with any development environment that supports COM programming, including MATLAB® from The MathWorks™, Microsoft® Visual C#®.NET or Visual Basic®.NET, Agilent® VEE Pro, National Instruments™ LabVIEW™ or LabWindows™, and so on.

- Measure Foundry manual and online help. For programmers who purchase Measure Foundry to easily create custom applications for a TEMPpoint, VOLTpoint, or MEASURpoint instrument, these documents describe the functions and capabilities of the Measure Foundry software.

- IVI foundation ([www.ivifoundation.org](http://www.ivifoundation.org))
- *Omega Complete Temperature Measurement Handbook and Encyclopedia*® or the Omega Engineering web site: <http://www.omega.com>. Both resources provide valuable information on thermocouple types, RTD types, standards, and linearization.

## **Where To Get Help**

Should you run into problems installing or using a TEMPpoint, VOLTpoint, or MEASURpoint instrument, the Data Translation Technical Support Department is available to provide technical assistance. Refer to [Chapter 7](#) for more information. If you are outside the United States or Canada, call your local distributor, whose number is listed on our web site ([www.datatranslation.com](http://www.datatranslation.com)).





# ***Overview***

Hardware Features.....	14
Supported Software.....	18
Accessories .....	19
Getting Started Procedure.....	20

## Hardware Features

Data Translation provides a number of USB instruments to meet your measurement needs, including the following:

- TEMPpoint – a family of temperature measurement instruments
- VOLTpoint – a family of voltage measurement instruments
- MEASURpoint – a family of mixed temperature and voltage measurement instruments

All of these instruments support Version 2.0 and 1.1 of the USB bus.

The following sections summarize the features of the TEMPpoint, VOLTpoint, and MEASURpoint USB instruments.

### TEMPpoint Features

TEMPpoint instruments include the following models: DT9871U, DT9871, and DT9872.

The key features of TEMPpoint instruments are as follows:

- *DT9871U and DT9871:*
  - Configurable analog input channels for thermocouple or differential voltage inputs; easy-access jacks for each channel for quick wiring
  - One CJC (cold junction compensation) input for each thermocouple channel
  - B, E, J, K, N, R, S, and T thermocouple types supported; the instrument automatically linearizes the measurements and returns the data as a 32-bit, floating-point temperature values
  - Input range of  $\pm 0.075$  V for the DT9871U (with  $0.25$   $\mu$ V RMS A/D noise using no software filtering) and  $\pm 1.25$  V for the DT9871 (with  $5$   $\mu$ V RMS A/D noise using no software filtering)
  - Break-detection circuitry to detect open thermocouple inputs
- *DT9872:*
  - Configurable analog input channels for RTDs and differential voltage inputs; easy-access jacks for each channel for quick wiring
  - $100\ \Omega$ ,  $500\ \Omega$ , and  $1000\ \Omega$  platinum RTD types supported using alpha curves of  $0.00385$  (European) or  $0.00392$  (American)
  - 4-wire, 3-wire, or 2-wire configurations; the DT9872 automatically linearizes the measurements and returns the data as 32-bit, floating-point temperature, resistance, or voltage values
  - Input range of  $\pm 1.25$  V
- One 24-bit, Delta-Sigma A/D converter per channel for simultaneous, high-resolution measurements
- $\pm 500$  V galvanic isolation channel-to-channel and to the host computer to protect signal integrity

- Throughput rate of up to 10 Samples/s for all channels.
- Software or external, digital trigger on digital input line 0 starts acquisition
- Auto-calibrating front-end resets the zero point on each power-up; in addition, the instrument supports anytime calibration, performing an auto-calibration function on software command
- Measurement Calibration Utility allows you to calibrate the instrument in the field (see [page 18](#) for more information on this utility)
- 8 opto-isolated digital input lines; you can read the digital input port through the analog input data stream for correlating analog and digital measurements
- 8 opto-isolated digital output lines; the outputs are solid-state relays that operate from  $\pm 30$  V at currents up to 400 mA (peak) AC or DC

## VOLTpoint Features

The key features of VOLTpoint (DT9873) instruments are as follows:

- Direct connection of analog input channels for differential voltage inputs; removable screw terminal blocks for each channel for quick wiring
- One 24-bit, Delta-Sigma A/D converter per channel for simultaneous, high-resolution measurements
- $\pm 500$  V galvanic isolation channel-to-channel and to the host computer to protect signal integrity
- Software-selectable input range of  $\pm 10$  V,  $\pm 100$  V, or  $\pm 400$  V per channel
- Throughput rate of up to 10 Samples/s for all channels
- Software or external, digital trigger on digital input line 0 starts acquisition
- Auto-calibrating front-end resets the zero point on each power-up; in addition, the instrument supports anytime calibration, performing an auto-calibration function on software command
- Measurement Calibration Utility allows you to calibrate the instrument in the field (see [page 18](#) for more information on this utility)
- 8 opto-isolated digital input lines; you can read the digital input port through the analog input data stream for correlating analog and digital measurements
- 8 opto-isolated digital output lines; the outputs are solid-state relays that operate from  $\pm 30$  V at currents up to 400 mA (peak) AC or DC

## MEASURpoint Features

The standard MEASURpoint (DT9874) instrument provides 16 thermocouple channels, 16 RTD channels, and 16 high voltage channels.

The key features of MEASURpoint instruments are as follows:

- *Analog Input Channels 0 to 15:*
  - Configurable channels for thermocouple or differential voltage inputs; easy-access jacks for each channel for quick wiring
  - One CJC (cold junction compensation) input for each thermocouple channel
  - B, E, J, K, N, R, S, and T thermocouple types supported; the instrument automatically linearizes the measurements and returns the data as a 32-bit, floating-point temperature values
  - Input range of  $\pm 0.075$  V (with  $0.25$   $\mu$ V RMS A/D noise using no software filtering)
  - Break-detection circuitry to detect open thermocouple inputs
- *Analog Input Channels 16 to 31:*
  - Configurable analog input channels for RTDs and differential voltage inputs; easy-access jacks for each channel for quick wiring
  - $100\ \Omega$ ,  $500\ \Omega$  and  $1000\ \Omega$  platinum RTD types supported using alpha curves of 0.00385 (European) or 0.00392 (American)
  - 4-wire, 3-wire, or 2-wire configurations; the DT9872 automatically linearizes the measurements and returns the data as 32-bit, floating-point temperature, resistance, or voltage values
  - Input range of  $\pm 1.25$  V
- *Analog Input Channels 31 to 48:*
  - Direct connection of analog input channels for differential voltage inputs; removable screw terminal blocks for each channel for quick wiring
  - Software-selectable input range of  $\pm 10$  V,  $\pm 100$  V, or  $\pm 400$  V per channel
- One 24-bit, Delta-Sigma A/D converter per channel for simultaneous, high-resolution measurements
- $\pm 500$  V galvanic isolation channel-to-channel and to the host computer to protect signal integrity
- Throughput rate of up to 10 Samples/s for all channels
- Software or external, digital trigger on digital input line 0 starts acquisition
- Auto-calibrating front-end resets the zero point on each power-up; in addition, the instrument supports anytime calibration, performing an auto-calibration function on software command
- Measurement Calibration Utility allows you to calibrate the instrument in the field (see [page 18](#) for more information on this utility)

- 8 opto-isolated digital input lines; you can read the digital input port through the analog input data stream for correlating analog and digital measurements
- 8 opto-isolated digital output lines; the outputs are solid-state relays that operate from  $\pm 30$  V at currents up to 400 mA (peak) AC or DC

## Supported Software

The following software is available for use with the TEMPpoint, VOLTpoint, and MEASURpoint USB instruments:

- **Measurement Application** – This application, developed using Measure Foundry, lets you do the following:
  - Configure your instrument
  - Acquire temperature, voltage, or resistance data from up to 48 analog input channels
  - Display acquired temperature, voltage, or resistance data during acquisition
  - Set alarm limits for each channel
  - Update the value of the digital output lines based on alarm conditions
  - Use a chart recorder to display data over time and log it to an .hpf file for later analysis
  - Open the last recorded .hpf data file in Microsoft Excel
  - View any .hpf data file in a file viewer

You can customize this application to suit your needs using Measure Foundry Professional with the Instrument Pak; the source code for this application is included with instrument.

- **Measure Foundry** – An evaluation version of this software is available for developing applications for TEMPpoint, VOLTpoint, or MEASURpoint instruments. Measure Foundry is a rapid application development package that provides a system solution for all types of measurement instruments. Using Measure Foundry, you can develop complex test and measurement applications easily without writing code. Simply drag and drop components on a form and configure their property pages to access all elements of your system.

Order the Instrument Pak for Measure Foundry (SP1309-CD) to build your own application for your instrument.

- **DtxMeasurement IVI-COM driver** – This driver provides access to the instrument's functions through a COM server. The IVI-COM driver works in any development environment that supports COM programming, including Measure Foundry, MATLAB, Visual Basic.NET, Visual C#.NET, Agilent VEE Pro, LabVIEW, LabWindows, and others.
- **Measurement Calibration Utility** – Users can calibrate a TEMPpoint, VOLTpoint, or MEASURpoint instrument in the field using precise calibration equipment and the Measurement Calibration Utility. Since each instrument consists of up to 48 individual channels, great care must be taken to ensure that proper warm-up times are followed and precise calibration equipment is used.

The calibration utility ships with a comprehensive help file that describes the required equipment and calibration procedure, including warm-up times, for each instrument.

The calibration utility allows you to revert to the factory calibration for any or all channels, or revert back to the last user calibration values, if desired. In addition, this utility generates a report that lists the starting and ending calibration values for each channel, allowing traceability.

Refer to the Data Translation web site ([www.datatranslation.com](http://www.datatranslation.com)) for information about selecting the right software package for your needs.

---

# Accessories


The following optional accessories are available for TEMPpoint, VOLTpoint, or MEASURpoint instruments:

- **STP37 screw terminal panel** – The STP37 permits easy screw terminal connections for accessing the digital I/O signals of a TEMPpoint, VOLTpoint, or MEASURpoint instrument.
- **EP333 cable** – The EP333 is a 2-meter shielded cable with two 37-pin connectors that connects the STP37 screw terminal panel to the digital I/O connector of the instrument.
- **Rack-mount kits** – To rack mount a single instrument, order a single rack-mount kit (Data Translation part number 22927).

To rack mount two instruments side by side, order a dual rack-mount kit (Data Translation part number 22735).

## Getting Started Procedure

The flow diagram shown in [Figure 1](#) illustrates the steps needed to get started using a TEMPpoint, VOLTpoint, or MEASURpoint instrument. This diagram is repeated in each Getting Started chapter; the shaded area in the diagram shows you where you are in the getting started procedure.



**Figure 1: Getting Started Flow Diagram**


# ***Part 1: Getting Started***





## ***Preparing to Use the Instrument***

Unpacking .....	25
Checking the System Requirements .....	26
Installing the Software .....	27
Viewing the Documentation .....	28



## **Unpacking**

Open the shipping box and verify that the following items are present:

- TEMPpoint, VOLTpoint, or MEASURpoint instrument
- USB cable
- EP361 +5V power supply and cable
- Instrument OMNI CD-ROM
- For DT9872, DT9874, and DT9874 instruments, a bag of pluggable screw terminable blocks and a screwdriver.

If an item is missing or damaged, contact Data Translation. If you are in the United States, call the Customer Service Department at (508) 481-3700, ext. 1323. An application engineer will guide you through the appropriate steps for replacing missing or damaged items. If you are located outside the United States, call your local distributor, listed on Data Translation's web site ([www.datatranslation.com](http://www.datatranslation.com)).

Once you have unpacked your instrument, check the system requirements, as described in the next section.

## Checking the System Requirements

For reliable operation, your instrument requires the following:

- PC with Pentium 233 MHz (or higher) processor
- Windows XP, Windows Vista, or Windows 7 documentation.

For USB Ver. 2.0 support, make sure that you install the appropriate Service Pack, if needed (version 2 for Windows XP). In addition, for some systems, you may have to disable standby mode. If you are not sure whether you are using USB Ver. 1.1 or Ver. 2.0, run the Open Layers Control Panel applet, described on [page 37](#).

- One or more USB ports (Ver. 2.0 or Ver. 1.1). USB Ver. 2.0 is strongly recommended; USB Ver. 1.1 will severely degrade performance
- 64 MB (or more) of RAM; 128 MB (or more) recommended
- One or more CD-ROM drives
- Super VGA (800 x 600 or higher resolution) display monitor

Once you have verified that your system meets the system requirements, install the software, as described in the next section.

## Installing the Software

The Measurement Application, developed using Measure Foundry, provides a quick way to verify that your instrument is working properly. To install the Measurement Application and all the components necessary to use the Measurement Application with the instrument, including the IVI-COM driver, perform the following steps:

1. Insert the Instrument OMNI CD into your CD-ROM or DVD drive.  
*The installation program should start automatically, and the Instrument OMNI installation program should appear.*
2. If the installation program does not start automatically, double-click **Setup.exe** from the CD.  
*The installation program appears.*
3. Click **Install from Web (recommended)** to get the latest version of the software from the web or **Install from CD** to install the software from the CD.
4. If you are installing from the web, perform these steps:
  - a. Click **Measurement Instrument Software** and follow the prompts to install the software (including the Measurement Application and IVI-COM driver) and related documentation.
  - b. If you wish to install the evaluation version of Measure Foundry, click **Measure Foundry (Evaluation)** from the MEASURpoint Installation web site, and follow the prompts to install the software and related documentation.

**Note:** To use Measure Foundry with TEMPpoint, VOLTpoint, or MEASURpoint instruments, select the evaluation version of **Measure Foundry Pro + Instruments Pak**.

5. If you are installing from the Instrument OMNI CD, perform these steps:
  - a. Click **Install Measurement Software**.
  - b. Ensure that **Measurement (Software & Application)** is selected.
  - c. If you wish to install the evaluation version of Measure Foundry in addition to the Measurement application, also select **Measure Foundry (EVAL)**.

**Note:** To use Measure Foundry with TEMPpoint, VOLTpoint, or MEASURpoint instruments, select the evaluation version of **Measure Foundry Pro + Instruments Pak**.

- d. Click **Install Selected Features** and follow the prompts to install the software.
- e. When you are finished with the Instrument OMNI CD, click **Quit Installer**.

For information on using the Measurement Application to verify the operation of your instrument, refer to [Chapter 5](#) starting on [page 61](#).

## Viewing the Documentation

---

**Note:** To view the documentation, you must have Adobe Reader 5.0 or greater installed on your system. Adobe Reader is provided on the Instrument OMNI CD. If you install Adobe Reader from this CD, make sure that you open Adobe Reader and accept the license agreement before viewing the documentation.

---

You can access the documentation for your instrument from the Windows Start menu as follows:

- For documentation about the TEMPpoint, VOLTpoint, or MEASURpoint instrument, click **Programs -> Data Translation, Inc -> Hardware Documentation -> Measurement User's Manual for USB Instruments**.
- For documentation on the DtxMeasurement IVI-COM driver, click **Programs -> IVI -> DtxMeasurement -> Documentation**.
- For documentation about Measure Foundry, click **Programs -> Data Translation, Inc -> Measure Foundry -> 5.1. -> Measure Foundry User Manual**


The following may be helpful when using Adobe Reader:

- To navigate to a specific section of the document, click a heading from the table of contents on the left side of the document.
- Within the document, click the text shown in blue to jump to the appropriate reference (the pointer changes from a hand to an index finger).
- To go back to the page from which the jump was made, click the right mouse button and **Go Back**, or from the main menu, click **Document**, and then **Go Back**.
- To increase or decrease the size of the displayed document, from the main menu, click **View**, and then **Zoom**.
- By default, Adobe Reader smooths text and monochrome images, sometimes resulting in blurry images. If you wish, you can turn smoothing off by clicking **File**, and then **Preferences/General**, and unchecking **Smooth Text and Images**.



## ***Setting Up and Installing the Instrument***

Applying Power .....	31
Attaching the Instrument to the Computer .....	33
Configuring the Device Driver.....	37



---


**Note:** Your TEMPpoint, VOLTpoint, and MEASURpoint instruments are factory-calibrated. Thereafter, yearly recalibration is recommended. Refer to [page 90](#) for more information on calibration.

---

## Applying Power

TEMPpoint, VOLTpoint, and MEASURpoint instruments are shipped with an EP361 +5V power supply and cable. To apply power to the instrument, do the following:

1. Connect the +5 V power supply to the power connector on the rear panel of the instrument. Refer to [Figure 2](#).



**Figure 2: Attaching a +5 V Power Supply to the Instrument**

2. Plug the power supply into a wall outlet.


---

**IMPORTANT:** For proper grounding of your measurement instrument, ensure that you use the power supply and cable (EP361) that is provided with the instrument and that you use all three prongs of the cable when connecting it to your wall outlet.

---

3. Press the Power Switch to turn on the instrument.  
*The Power LED on the front panel lights to indicate that power is on.*

[Figure 3](#) shows the front panel of the instrument, including the location of the Power LED.



**Figure 3: Front Panel of the Instrument**

## Attaching the Instrument to the Computer

This section describes how to attach a TEMPpoint, VOLTpoint, or MEASURpoint instrument to the host computer.

---

**Notes:** Most computers have several USB ports that allow direct connection to USB devices. If your application requires more TEMPpoint, VOLTpoint, or MEASURpoint instruments than you have USB ports for, you can expand the number of USB devices attached to a single USB port by using expansion hubs. For more information, refer to [page 35](#).

You can unplug a USB instrument, then plug it in again, if you wish, without causing damage. This process is called hot-swapping. Your application may take a few seconds to recognize an instrument once it is plugged back in.

---


You must install the device driver before connecting your instrument to the host computer. See [page 27](#) for more information.

### Connecting Directly to the USB Ports

To connect a TEMPpoint, VOLTpoint, or MEASURpoint instrument directly to a USB port on your computer, do the following:


1. Make sure that you have attached a power supply to the instrument.
2. Attach one end of the USB cable to the USB port on the rear panel of the instrument.
3. Attach the other end of the USB cable to one of the USB ports on the host computer, as shown in [Figure 4](#).

*The operating system automatically detects the instrument and starts the Found New Hardware wizard.*



**Figure 4: Attaching the Instrument to the Host Computer**

4. Click **Next** and/or **Finish** in the wizard. Once the firmware is loaded, the wizard restarts to initiate the firmware to accept commands. Click **Next** and/or **Finish** again. *If the power supply and the instrument are attached correctly, the USB LED on the rear panel, shown in [Figure 5](#), turns green.*



**Figure 5: Rear Panel of the Instrument**

5. Repeat the steps to attach another TEMPpoint, VOLTpoint, or MEASURpoint instrument to the host computer, if desired.

## Connecting to an Expansion Hub

Expansion hubs are powered by their own external power supply. Theoretically, you can connect up to five expansion hubs to a USB port on the host computer. However, the practical number of instruments that you can connect to a single USB port depends on the throughput you want to achieve. Each of the hubs supports up to four instruments.

To connect multiple TEMPpoint, VOLTpoint, or MEASURpoint instruments to an expansion hub, do the following:

1. Make sure that you have attached a power supply to the instrument.
2. Attach one end of the USB cable to the instrument and the other end of the USB cable to an expansion hub.
3. Connect the power supply for the expansion hub to an external power supply.
4. Connect the expansion hub to the USB port on the host computer using another USB cable.  
*The operating system automatically detects the instrument and starts the Found New Hardware wizard.*
5. Click **Next** and/or **Finish** in the wizard. Once the firmware is loaded, the wizard restarts to initiate the firmware to accept commands. Click **Next** and/or **Finish** again.  
*If the power supply and the instrument are attached correctly, the USB LED, shown in [Figure 5 on page 34](#), turns green.*
6. Repeat these steps until you have attached the number of expansion hubs (up to five) and instruments (up to four per hub) that you require. Refer to [Figure 6](#).  
*The operating system automatically detects the instruments as they are installed.*




Figure 6: Attaching Multiple Instruments Using Expansion Hubs

## Configuring the Device Driver

To configure the device driver for a TEMPpoint, VOLTpoint, or MEASURpoint instrument, do the following:

1. If you have not already done so, power up the host computer and all peripherals.
2. From the Windows Start menu, select **Settings -> Control Panel**.
3. From the Control Panel, double-click **Open Layers Control Panel**.  
*The Data Acquisition Control Panel dialog box appears.*
4. Click the name of the instrument that you want to configure, and then click **Advanced**.  
*The Configurable Board Options dialog box appears.*
5. For each channel, set the **Channel Configuration** as voltage (the default) or one of the supported sensor types for that channel.

---

**Note:** If you wish, you can overwrite these channel input types programmatically using your software development environment or application.

---

6. Click **OK**.
7. If you want to rename the instrument, click **Edit Name**, enter a new name for the instrument, and then click **OK**. The name is used to identify the instrument in all subsequent applications.
8. Repeat steps 4 to 7 for the other instrument that you want to configure.
9. When you are finished configuring the instrument, click **Close**.


Continue with the instructions on wiring in [Chapter 4](#) starting on [page 39](#).





## ***Wiring Signals***

General Wiring Recommendations .....	41
Warm-Up Time .....	42
Connecting Thermocouple Inputs .....	43
Connecting RTD Inputs .....	45
Connecting Voltage Inputs .....	49
Connecting Current Loop Inputs .....	53
Connecting Digital I/O Signals .....	58



---

## **General Wiring Recommendations**

Keep the following recommendations in mind when wiring signals to a TEMPpoint, VOLTpoint, or MEASURpoint instrument:

- Separate power and signal lines by using physically different wiring paths or conduits.
- To avoid noise, do not locate the instrument and cabling next to sources that produce high electromagnetic fields, such as large electric motors, power lines, solenoids, and electric arcs, unless the signals are enclosed in a mumetal shield.
- Locate the instrument's front panel as far away as possible from sources of high or low temperatures or strong air currents, such as fans.
- Prevent electrostatic discharge to the I/O while the instrument is operational.
- When wiring thermocouples, select an appropriate wire length and gauge for each thermocouple; in general, use the shortest wire length and largest gauge for the application to yield best results.
- Use shielded wire for maximum rejection of electrical interference.

## ***Warm-Up Time***

For accurate thermocouple measurements, DT9871U and DT9871 TEMPpoint instruments and thermocouple channels on the DT9874 MEASURpoint instruments require a warm-up time of 45 minutes for the analog circuitry to stabilize.

For accurate high voltage measurements, the DT9873 VOLTpoint instruments and high voltage channels on the DT9874 MEASURpoint instruments require a warm-up time of 1 hour for the analog circuitry to stabilize.

For accurate RTD measurements, the DT9872 TEMPpoint instruments and RTD channels on the DT9874 MEASURpoint instruments require a warm-up time of 1 minute for the analog circuitry to stabilize.

## Connecting Thermocouple Inputs

The DT9871U, DT9871, and DT9874 instruments contain Cu-Cu thermocouple jacks for connecting thermocouple inputs.

---

**Note:** On the standard DT9874 instrument, channels 0 to 15 correspond to the thermocouple input channels.

---

Internally, these signals are connected in differential mode. You can mix and match the following thermocouple types across channels: B, E, J, K, N, R, S, and/or T.

Each Cu-Cu thermocouple input jack is polarized and accepts a mating Cu-Cu plug in the appropriate orientation. [Table 1](#) lists the color designations for the + and – polarities of the supported thermocouple types for both the ANSI (American) and IEC (International) standards.

**Table 1: Thermocouple Color Designation Standards**

Thermocouple Standard	Thermocouple Type	Wire Color Coding + Polarity	Wire Color Coding – Polarity
ANSI	Type J	White	Red
	Type K	Yellow	Red
	Type T	Blue	Red
	Type E	Violet	Red
	Type S	Black	Red
	Type R	Black	Red
	Type B	Gray	Red
	Type N	Orange	Red
IEC	Type J	Black	White
	Type K	Green	White
	Type T	Brown	White
	Type E	Violet	White
	Type S	Orange	White
	Type R	Orange	White
	Type B	Gray	White
	Type N	Pink	White

For more information on thermocouple standards, refer to the following web site:  
<http://www.omega.com/thermocouples.html>.

Figure 7 shows how to connect a thermocouple input to a thermocouple channel.




Figure 7: Connecting Thermocouple Inputs

## Connecting RTD Inputs


Each DT9872 and DT9874 contains pluggable screw terminals for connecting RTD inputs.

---

**Note:** On the standard DT9874 instrument, channels 16 to 31 correspond to the RTD input channels.

---

Internally, these signals are connected in differential mode. [Figure 8](#) shows the numbering of the screw terminal blocks for RTD connections.



**Figure 8: Screw Terminal Block Numbering for RTD Connections**

---

**Note:** To make wiring easier, use the supplied screwdriver to attach your signals to the screw terminal blocks. When you are finished, plug the screw terminal block into the screw terminal header that corresponds to the channel to which you are wiring.

---

The DT9872 supplies each RTD channel with 425  $\mu\text{A}$  of excitation current to prevent self-heating. The resistance of the RTD circuit increases gradually, repeatably, and linearly with temperature. As the resistance increases, the voltage drop across the RTD also increases. The DT9872 reads this voltage drop and automatically converts the voltage to the appropriate temperature based on the RTD type.

The DT9872 and DT9874 support Pt100 (100  $\Omega$  Platinum), Pt500 (500  $\Omega$  Platinum), and Pt1000 (1000  $\Omega$  Platinum) RTD types using Alpha coefficients of 0.00385 and 0.00392; you can mix and match RTD types across RTD channels. Refer to the following web site for more information on RTD types: <http://www.omega.com>.

To connect an RTD input, you can use a 4-wire, 3-wire, or 2-wire connection scheme, described in the following subsections. For the best accuracy, use 4-wire RTD connections; this connection scheme enables Kelvin sensing to minimize errors due to lead wire resistance.

## 4-Wire RTD Connections

The 4-wire configuration offers the best accuracy with long connection wires, compared to the 3- and 2-wire configurations. The 4-wire connection scheme eliminates errors due to lead wire resistance ( $R_L$ ) and thermal heating. Wire impedance of up to  $100\ \Omega$  anywhere in the hookup is automatically cancelled as long as the sense wires are connected.

Figure 9 shows a 4-wire RTD connection.




Figure 9: 4-Wire RTD Connection

## 3-Wire RTD Connections

The 3-wire configuration eliminates one wire from the 4-wire RTD connection. Lead wire resistance ( $R_L$ ) errors in the return wire from -Sense may be introduced unless the voltage drop is essentially equal and opposite to the voltage drop across +Sense.

Figure 10 shows a 3-wire RTD connection.




Figure 10: 3-Wire RTD Connection

## 2-Wire RTD Connections

The 2-wire configuration is the least accurate of the RTD wiring configurations because the lead wire resistance ( $R_L$ ) and its variation with temperature contribute significant measurement errors, particularly if the lead wire is long. If you decide to use the 2-wire connection scheme, ensure that you use short lead wire connections.

For example, if the lead resistance is  $0.5 \Omega$  in each wire, the lead resistance adds a  $1 \Omega$  of error to the resistance measurement. Using a  $100 \Omega$  RTD (Pt100) with a  $0.00385/^\circ\text{C}$  European curve coefficient, the resistance represents an initial error of  $1 \Omega / (0.385 \Omega / ^\circ\text{C})$  or  $2.6^\circ\text{C}$ . Since the lead wire resistance changes with ambient temperature, additional errors are also introduced in the measurement.

Figure 11 shows a 2-wire RTD connection.




Figure 11: 2-Wire RTD Connection

## Connecting Voltage Inputs

The way you connect voltage inputs depends on the channel type you are using. This section describes how to connect voltage inputs to thermocouple input channels, RTD input channels, and high voltage input channels.

### Connecting Voltage Inputs to Thermocouple Channels

Figure 12 shows how to connect a differential voltage input to a thermocouple input channel on the DT9871U, DT9871, or DT9874 instrument.

**Note:** On the standard DT9874 instrument, channels 0 to 15 correspond to the thermocouple input channels.




Figure 12: Connecting Voltage Inputs to a Thermocouple Channel


## Connecting Voltage Inputs to RTD Channels

Figure 13 shows how to connect a voltage input to an RTD channel on a DT9872 or DT9874 instrument.

---

**Note:** On the standard DT9874 instrument, channels 16 to 31 correspond to the RTD input channels.

---



**Figure 13: Connecting Voltage Inputs to an RTD Channel**

The input impedance is well over 100 M $\Omega$  using the voltage -Sense and +Sense inputs.

For best accuracy when connecting voltage inputs, use twisted-pair wires with a dead-ended shield connected to pin 4 of the screw terminal block.

## Connecting Voltage Inputs to High Voltage Channels

Each DT9873 and DT9874 contains pluggable screw terminals for connecting high voltage inputs.

---

**Note:** On the standard DT9874 instrument, channels 32 to 47 correspond to the high voltage input channels.

---

Figure 14 shows the numbering of the screw terminal blocks for high voltage connections.



The input impedance is well over 100 M $\Omega$  using the voltage –Sense and +Sense inputs.

---

**Note:** For best accuracy when connecting voltage inputs, use twisted-pair wires with a dead-ended shield connected to pin 4 of the screw terminal block.

---

---

## Connecting Current Loop Inputs

In some applications, such as solar cell, fuel cell, and car battery testing applications, you may want to accurately sense and measure current in a high voltage loop.

TEMPpoint, VOLTpoint, and MEASURpoint instruments provide channel-to-channel isolation of  $\pm 500$  V, meaning that each input can be referenced to  $\pm 500$  V.

The way you connect current loop inputs depends on the channel type you are using. This section describes how to connect current loop inputs to thermocouple input channels, RTD input channels, and high voltage input channels.

### Connecting Current Loop Inputs to Thermocouple Channels

Thermocouple input channels on the DT9871U and DT9874 have an input range of  $\pm 0.075$  V. Therefore, you can use a  $1\ \Omega$  series resistor to measure  $\pm 0.075$  A. Similarly, you can use a  $0.1\ \Omega$  series resistor to measure  $\pm 0.75$  A.


Thermocouple input channels on the DT9871 have an input range of  $\pm 1.25$  V. Therefore, you can use a  $1\ \Omega$  series resistor to measure  $\pm 1.25$  A. Similarly, you can use a  $0.1\ \Omega$  series resistor to measure  $\pm 12.5$  A or a  $10\ \Omega$  series resistor to measure  $\pm 0.125$  A.

[Figure 16](#) shows how to wire your signals to measure a current loop. In this example, the input is referenced to  $\pm 80$  V.

---

**Note:** On the standard DT9874 instrument, channels 0 to 15 correspond to the thermocouple input channels.

---



Use a 1  $\Omega$  series resistor to convert current to voltage.

For thermocouple channels on the DT9871U and DT9874, 1  $\Omega = 0.075 \text{ A} = 0.075 \text{ V}$ .  
 For thermocouple channels on the DT9871, 1  $\Omega = 1.25 \text{ A} = 1.25 \text{ V}$ .

Figure 16: Connecting Current Loop Inputs to Thermocouple Channels

## Connecting Current Loop Inputs to RTD Channels


RTD channels on the DT9872 and DT9874 instruments have an input range of  $\pm 1.25 \text{ V}$ . Therefore, you can use a 1  $\Omega$  shunt resistor to measure  $\pm 1.25 \text{ A}$ . Similarly, you can use a 0.1  $\Omega$  shunt resistor to measure  $\pm 12.5 \text{ A}$  or a 10  $\Omega$  shunt resistor to measure  $\pm 0.125 \text{ A}$ .

Figure 17 shows how to wire your signals to measure a current loop. In this example, the input is referenced to  $\pm 80 \text{ V}$ .

---

**Note:** On the standard DT9874 instrument, channels 16 to 31 correspond to the RTD input channels.

---



Use a 1 Ω shunt resistor to convert current to voltage:  $1 \Omega = 1.25 \text{ A} = 1.25 \text{ V}$ .

**Figure 17: Connecting Current Loop Inputs to RTD Channels**

## Connecting Current Loop Inputs to High Voltage Channels

High voltage channels on the DT9873 and DT9874 instruments have an input range of  $\pm 10$  V,  $\pm 100$  V, or  $\pm 400$  V. You select the input range for each channel using software.

---

**Note:** On older versions of the instrument, the input range was fixed and depended on the model you purchased.

---

With the 24-bit A/D converter, high current, high side current shunts can be used for resolutions of less than 0.01 A on a 100 A range.

Typical Shunts:

- Vishay WSMS5515  
.2 m $\Omega$  - 2W - 100A - 20mV
- Vishay CSM2512S  
10 m $\Omega$  - 1W - 10A - 100mV
- Deltec MUB-500-50  
.1 m $\Omega$  - 25W - 500A - 50mV

---

**Notes:** The resolution is  $\pm 2$  mV on a  $\pm 100$  V range and  $\pm 0.3$  mV on the  $\pm 10$  V range. Since the resolution of the  $\pm 400$  V range is  $\pm 8$  mV, using current loop inputs with this range is impractical in most applications.

On the standard DT9874 instrument, channels 32 to 47 correspond to the high voltage input channels.

---

Figure 18 shows an example of wiring signals to measure  $\pm 20$  mA using the  $\pm 10$  V input range.





Figure 18: Connecting a Current Loop Input to a High Voltage Channel to Measure  $\pm 20$  mA

## Connecting Digital I/O Signals

To make digital I/O connections easier, you can use the optional STP37 screw terminal panel and EP333 cable with your TEMPpoint, VOLTpoint, or MEASURpoint instrument. Connect the STP37 to the digital I/O connector of the instrument as shown in [Figure 19](#):



**Figure 19: Connecting the Instrument to the STP37**

[Figure 20](#) shows the layout of the STP37 screw terminal panel and lists the assignments of each screw terminal.





Figure 20: STP37 Screw Terminal Panel

## Connecting Digital Input Signals

Figure 21 shows how to connect digital input signals (lines 0 and 1, in this case) to the digital I/O connector on the TEMPpoint, VOLTpoint, or MEASURpoint instrument.



\*1 kΩ pull-up to +5 V required for TTL outputs.

Figure 21: Connecting Digital Inputs

## Connecting Digital Output Signals

The digital output lines of a TEMPpoint, VOLTpoint, or MEASURpoint instrument act as solid-state relays. The customer-supplied signal can be  $\pm 30$  V at up to 400 mA (peak) AC or DC.

You can use the digital output lines of the instrument to control solid-state or mechanical relays or high-current electric motors. Figure 22 shows how to connect digital output signals to line 0 of the instrument to control a motor relay.





Figure 22: Switching up to 30 V at 400 mA



## ***Verifying the Operation of Your Instrument***

Overview .....	63
Running the Measurement Application .....	64
Changing the Configuration of Your Instrument .....	67
Defining Alarm Limits .....	69
Logging Data to Disk .....	71
Viewing a Data File .....	73
Reading Digital Input Values .....	74
Exiting from the Measurement Application .....	75



## Overview

You can verify the operation of your TEMPpoint, VOLTpoint, or MEASURpoint instrument using the Measurement Application that is provided with the instrument. The Measurement Application, developed using Measure Foundry, lets you perform the following functions:

- Configure your instrument
- Acquire temperature, resistance, and/or voltage data from up to 48 analog input channels
- Display temperature, resistance, and/or voltage data during acquisition
- Use a Chart Recorder to display and log data to an.hpf file for later analysis
- View any .hpf file, and view the last recorded .hpf data file in Microsoft Excel®
- Set minimum and maximum alarm limits for each channel
- Set the state of the digital output lines based on alarm limits
- Read the state of the digital input port

If desired, you can use Measure Foundry to customize this application.


Refer to [page 27](#) for information on installing the Measurement Application.

## Running the Measurement Application

To run the Measurement Application, perform the following steps:


1. Click **Start -> Programs -> Data Translation, Inc -> Measurement -> Measurement Application**

*The Device Selection screen is displayed:*



2. By default, the application "discovers" all TEMPpoint, VOLTpoint, and MEASURpoint instruments that are available and displays them in the list of Available Instruments. If you want to refresh this list to determine if other TEMPpoint, VOLTpoint, or MEASURpoint instruments are available, click **Refresh list**.
3. If your instrument is included in the list of Available Instruments and you want to connect to it, select the connect string for the instrument that you want to use from the list of Available Instruments, and then go to step 6.  
*Information about the instrument, including the scanning status, model number, firmware version, and serial number, is displayed.*
4. If you do not have a TEMPpoint, VOLTpoint, or MEASURpoint instrument connected or if you want to simulate the operation of an instrument, click one of the following selections, and then go to step 6:
  - **Device Simulation Mode - MEASURpoint** – Simulates the operation of a MEASURpoint instrument.
  - **Device Simulation Mode - VOLTpoint** – Simulates the operation of a VOLTpoint instrument.

- **Device Simulation Mode - TEMPpoint RTD** – Simulates the operation of a DT9872 or DT8872 TEMPpoint instrument.
  - **Device Simulation Mode - TEMPpoint TC** – Simulates the operation of a DT9871, DT9871U, DT8871, or DT8871U TEMPpoint instrument.  
*When selected, the button indicator turns green.*
5. If your instrument is not included in the list of Available instruments, but you want to manually connect to it, do the following:
- a. Click **Advanced**.  
*The following screen is displayed:*



- b. Determine and optionally edit the name of your USB instrument, by clicking **Start -> Settings -> Control Panel -> Open Layers Control Panel**.  
*The name of your device is listed.*
  - c. Enter the Open Layers name of your instrument, such as **USB::DT9871(01)**, as the VISA Connect String for your device and click **Set**.
  - d. If you want to simulate the operation of an instrument, enter the string **simulate=true,model=xxxxxx** in the VISA Option String text box and click **Set**, where *xxxxxx* is the model number of the instrument you want to simulate (DT9871, DT8871, DT9872, and DT8872 for TEMPpoint instruments, DT9873 and DT8873 for VOLTpoint instruments, and DT987x and DT887x for MEASURpoint instruments).
6. (Optional) If you previously used the Measurement Application, and you want to overwrite the configuration of the last session (which was automatically saved) with the default configuration for the selected instrument, click the **Reset to Default Config** button.
7. (Optional) If you previously used the Measurement Application, and you want to overwrite the names of the channels (which were automatically saved) with the default channel names for the selected instrument, click the **Reset Channel Names** button. Note that this step is useful especially when changing between instrument types.

8. Click **Continue**.

The latest state is saved and used when the application is next run, and the Channel Overview screen of the Measurement Application is displayed. Note that data acquisition is started automatically and temperature values are displayed (in degrees C), by default.

Channel Type	Ch40	Ch41	Ch42	Ch43	Ch44	Ch45	Ch46	Ch47
Volts	7.70 V	8.10 V	8.30 V	7.90 V	8.00 V	7.60 V	7.60 V	8.10 V
Volts	7.50 V	7.60 V	8.40 V	7.50 V	7.60 V	8.40 V	7.90 V	8.10 V
RTD	48.00 C	50.03 C	52.02 C	54.02 C	56.02 C	58.01 C	60.03 C	62.02 C
RTD	32.03 C	34.00 C	36.01 C	38.01 C	40.02 C	42.02 C	44.03 C	46.00 C
TC	16.01 C	18.02 C	20.02 C	22.03 C	24.03 C	26.03 C	28.00 C	30.02 C
TC	0.02 C	2.02 C	4.01 C	6.01 C	8.00 C	10.03 C	12.03 C	14.01 C

**Figure 23: Channel Overview Screen of the Measurement Application**


Note that the **Channel Type** field on the left of the screen indicates the type of sensor that is used for the corresponding row of measurement values. For example,

- *TC* represents the values for thermocouple channels
- *RTD* represents the values for RTD channels
- *Volts* represents the values for voltage input channels

## Changing the Configuration of Your Instrument


To change the configuration of your instrument, follow these steps:

1. Stop acquisition by clicking the **Start/Stop** button from the main window or by clicking **Stop Acquisition** from the **Acquisition** menu.
2. Click the **Configuration** menu, and then click **Change Configuration**.  
The *Change Configuration* screen is displayed:



3. Under **Unit**, select the temperature units in which to display temperature data: °C (Celsius), °F (Fahrenheit), or °K (Kelvin).
4. Under **Sensor Type**, select the input type for each of the channels.

For channels that support programmable voltage ranges, the following drop-down box is displayed; select the voltage range that you want to use for the channel:



---

**Note:** If you want to set all the channels to the same configuration at once, select the configuration to apply using the **Set all to** combo box.

If you select a voltage sensor type for a channel, the data is displayed in voltage. The sensor type setting is ignored for the digital input port.

---

5. Under **Filter Type**, select *Moving Average* if you want to filter the data or *Raw* if you do not want to filter the data.
6. Under **Log Channels to Disk**, check the channels that you want to log to disk when you use the Chart Recorder (described on [page 71](#)). The first time you use the Measurement Application, all channels are selected for data logging.
7. Under **External Trigger Enable**, select *True* if you want to start acquisition using an external trigger signal connected to digital input line 0; otherwise, select *False*.
8. Under **Channel Names**, specify a meaningful name to represent each channel.
9. Under **Acquisition Frequency**, click the frequency (10 Hz, 5 Hz, 2 Hz, Every 2 s, Every 5 s, Every 10 s, Every Minute, Every 2 Minutes, Every 5 Minutes) at which to simultaneously sample all channels.
10. When you are finished configuring the Measurement Application, click **OK**.
11. To save the configuration settings, click the **Configuration** menu, and then click **Save Configuration File**.
12. Enter a name for the configuration file, select the directory in which to save the file, and then click **Save**.  
*This file has the extension (\*.Measurement).*

---

**Note:** You can save numerous configuration settings, if desired. To load a previously saved configuration, click the **Configuration** menu, and then click **Load Configuration File**.

---

13. Restart acquisition by clicking **Start Acquisition** from the **Acquisition** menu or by clicking **Start/Stop** from the main window.

## Defining Alarm Limits

When you start the Measurement Application for the first time, the following alarm limits are defined for each channel:


- Minimum alarm limit = 0
- Maximum alarm limit = 100

If the acquired value for a channel is between the defined minimum and maximum alarm limits, the value is within range and is displayed in black. If the acquired value for a channel is below the minimum or above the maximum alarm limit, the value is out of range and is displayed in red.

To change the alarm limits, do the following:


1. From the **Windows** menu, select **Limit Definition**.

*A screen similar to the following is displayed:*



2. If you want to change the minimum alarm limit for a channel, enter a value in the **Min** field for that channel, and then click **Set** next to the value that you entered.
3. If you want to change the maximum alarm limit for a channel, enter a value in the **Max** field for that channel, and then click **Set** next to the value that you entered.
4. If you want to set a digital output line when the alarm limits for a channel are exceeded, click the **Open Digital Output Definition Window** button from the **Limit Definition** screen.

*The following screen appears:*



- For each channel, select the digital output line (bit) that you want to turn on when the limits for a channel are exceeded. If you do not want to set a digital output line when the alarm limits are exceeded, choose **none**.


---

**Note:** You can assign the same digital output line to multiple channels. The digital output line is turned on (1) when any of the alarm limits are exceeded on the channels that were assigned to that digital output line.

If alarm limits are not exceeded, the digital output line is turned off (0).

---

- To see the state of the digital output lines, click the **OUT** button from main window, or from the **Windows** menu, select **Digital Output Panel**.  
*A screen similar to the following appears:*




## Logging Data to Disk

To log data to disk, perform the following steps:

1. Ensure that you configured the channels that you want to log to disk (see [page 68](#)).
2. Start acquisition by clicking the **Start/Stop** button from the main window or, from the **Acquisition** menu, by selecting **Start Acquisition**.
3. Click the **Chart Recorder** button on the main window, or from the **Windows** menu, select **Chart Recorder**.

A screen similar to the following appears:



4. Under **Channel Visibility**, select the channels that you want to be visible on the display.

---


**Note:** The first time that you run the Measurement Application, all the channels are visible.

---

5. From the **Time Axis Length** drop-down list, select the time (10 Seconds, 1 Minute, 5 Minutes, 10 Minutes, 30 Minutes, 1 Hour, 2 Hours, 4 Hours) to use for the time axis.
6. If you want to display all the data on a single band, leave the **Single Band/Multiple Band** button untouched (the button indicator is green).

If you want to display the data for each channel on a separate band, click the **Single Band/Multiple Band** button so that the button indicator turns gray.

7. To begin recording data, click the **Start Recording** button.  
*You are prompted to name the file in which to store the recorded data. The data file has an .hpf extension.*
8. Enter a name for the data file, and then click **Save**.  
*The data for each channel is then displayed on the screen and logged to disk:*



9. When you have finished recording, click the **Stop Recording** button.
10. If you want to view this data in Microsoft Excel, click the button called **Open Last Recording in Excel**.

---

**Note:** The Chart Recorder has other features, such as scrolling, autoscaling, printing, and so on. Refer to the online help provided with the Measurement Application for more information on these features.

---

## Viewing a Data File

To view the data that you recorded in an .hpf file with the Chart Recorder, perform the following steps:


1. Click the **Load Data File** button from the main window, or from the **File** menu, select **Load Data File**.  
*You are prompted to select the name of the data file to view.*
2. Select the name of the data file to view, and then click **Open**.  
*The data file is displayed in the File Viewer window.*
3. You can then scroll through the data, change the scale of the display, print the data, and so on. Refer to the online help provided with the Measurement Application for more information about these features.
4. When you are finished viewing the data file, click **Close**.

## Reading Digital Input Values

To read the state of the digital input port, perform the following steps:

1. Click the **Digital In** button from the main window, or from the **Windows** menu, select **Digital Input Panel**,

*A screen similar to the following appears:*



---

**Note:** The LED indicator turns green when a value of 1 is detected on the digital input line and turns gray when a value of 0 is detected on the digital input line.

---

## ***Exiting from the Measurement Application***

When you finished using the Measurement Application, exit from the application by selecting the **File** menu and clicking **Quit**.



# ***Part 2: Using Your Instrument***





## ***Principles of Operation***

Block Diagrams .....	80
Analog Input Features .....	85
Digital I/O Features .....	96

## Block Diagrams

This section includes the block diagrams for the DT9871U, DT9871, and DT9872 TEMPpoint instruments, DT9873 VOLTpoint instrument, and DT9874 MEASURpoint instruments.

### DT9871U Block Diagram

Figure 24 shows the block diagram of the DT9871U TEMPpoint instrument.




Figure 24: Block Diagram of the DT9871U TEMPpoint Instrument

## DT9871 Block Diagram

Figure 25 shows the block diagram of the DT9871 instrument.




Figure 25: Block Diagram of the DT9871 TEMPpoint Instrument

## DT9872 Block Diagram

Figure 26 shows the block diagram of the DT9872 TEMPpoint instrument.




Figure 26: Block Diagram of the DT9872 TEMPpoint Instrument

## DT9873 Block Diagram

Figure 27 shows the block diagram of the DT9873 VOLTpoint instrument.




Figure 27: Block Diagram of the DT9873 VOLTpoint Instrument

## DT9874 Block Diagram

Figure 28 shows the block diagram of the DT9874 MEASURpoint instrument.




Figure 28: Block Diagram of the DT9874 MEASURpoint Instrument

## Analog Input Features

This section describes the following features of the analog input (A/D) subsystem on TEMPpoint, VOLTpoint, and MEASURpoint instruments:

- Analog input channels, described on this page
- Input ranges, described on [page 88](#)
- Resolution, described on [page 90](#)
- Calibration, described on [page 90](#)
- Sample clock, described on [page 91](#)
- Trigger source, described on [page 91](#)
- Conversion modes, described on [page 92](#)
- Filtering, described on [page 93](#)
- Data format, described on [page 93](#)
- Error conditions, described on [page 94](#)

### Analog Input Channels

TEMPpoint, VOLTpoint, and MEASURpoint instruments provide up to 48 analog input channels. The number of channels and the channel types supported (thermocouple, RTD, or voltage input) depend on the specific instrument model you purchased, as shown in [Table 2](#).

**Table 2: Number and Type of Analog Input Channels**

Instrument Type	Models	# of Analog Input Channels	Channel Types
TEMPpoint	DT9871U-8 and DT9871-8	8	8 thermocouple inputs (numbered 0 to 7)
	DT9871U-16 and DT9871-16	16	16 thermocouple inputs (numbered 0 to 15)
	DT9871U-24 and DT9871-24	24	24 thermocouple inputs (numbered 0 to 23)
	DT9871U-32 and DT9871-32	32	32 thermocouple inputs (numbered 0 to 31)
	DT9871U-40 and DT9871-40	40	40 thermocouple inputs (numbered 0 to 39)
	DT9871U-48 and DT9871-48	48	48 thermocouple inputs (numbered 0 to 47)
	DT9872-8	8	8 RTD inputs (numbered 0 to 7)
	DT9872-16	16	16 RTD inputs (numbered 0 to 15)
	DT9872-24	24	24 RTD inputs (numbered 0 to 23)
	DT9872-32	32	32 RTD inputs (numbered 0 to 31)
	DT9872-40	40	40 RTD inputs (numbered 0 to 39)
	DT9872-48	48	48 RTD inputs (numbered 0 to 47)

**Table 2: Number and Type of Analog Input Channels (cont.)**

Instrument Type	Models	# of Analog Input Channels	Channel Types
VOLTpoint	DT9873-8	8	8 high voltage inputs (numbered 0 to 7)
	DT9873-16	16	16 high voltage inputs (numbered 0 to 15)
	DT9873-24	24	24 high voltage inputs (numbered 0 to 23)
	DT9873-32	32	32 high voltage inputs (numbered 0 to 31)
	DT9873-40	40	40 high voltage inputs (numbered 0 to 39)
	DT9873-48	48	48 high voltage inputs (numbered 0 to 47)
MEASURpoint	DT9874-16T-16R-16V	48	16 thermocouple inputs (numbered 0 to 15)
			16 RTD inputs (numbered 16 to 31)
			16 high voltage inputs (numbered 32 to 47)

### ***Thermocouple Input Channels***

For channels that support thermocouples, you can attach a voltage input or any of the following thermocouple types in a mix and match fashion: B, E, J, K, N, R, S, and/or T.

By default, these channels are configured for voltage inputs. You can specify the thermocouple types for channels using the DT-Open Layers Control Panel applet, described on [page 37](#), the Change Configuration dialog in the supplied Measurement Application, described on [page 67](#), or by using an API call in your application program.

---

**Note:** In a mix-and-match system, it is easy to accidentally mismatch the software and hardware configuration for a channel. Therefore, it is recommended that you pay particular attention when configuring channels, since the resultant errors may be not large enough to notice initially, but may be significantly larger than the accuracy specification for the instrument.

---

Since each channel has its own 24-bit A/D, analog inputs are measured simultaneously. Refer to [page 92](#) for more information on specifying the channels for a scan.

[Table 3](#) lists the supported measurement range for each thermocouple type. (Refer to [page 88](#) for information on the supported input range for voltage measurements.)

**Table 3: Supported Measurement Range for Each Thermocouple Type**

Thermocouple Type	Supported Measurement Range	
	Minimum	Maximum
B	0° C (32° F)	1820° C (3308° F)
E	-200° C (-328° F)	1000° C (1832° F)
J	-210° C (-346° F)	1200° C (2192° F)
K	-200° C (-328° F)	1370° C (2498° F)
N	-200° C (-328° F)	1300° C (2372° F)
R	-50° C (-58° F)	1750° C (3182° F)
S	-50° C (-58° F)	1750° C (3182° F)
T	-200° C (-328° F)	400° C (752° F)

Refer to [Appendix A](#) for the thermocouple accuracy of thermocouple channels over the dynamic range of the instrument.

### Cold Junction Compensation

Each thermocouple channel has its own cold-junction compensation (CJC) at the input. The software reads the value of the CJC input along with the value of the analog input channel and automatically corrects for errors based on the specified thermocouple type and the thermocouple linearization data stored in onboard ROM.

A separate multiplexed A/D is used to acquire all the CJC input values. The software takes care of correlating the CJC measurements with the analog input measurements.

---

**Note:** The software provides the option of returning CJC values in the data stream. This option is seldom used, but is provided if you want to implement your own temperature conversion algorithms in software when using continuous operations. Refer to [page 93](#) for more information on this feature.

---

### Open Thermocouple Detection

Break detection circuitry (+10 nA on the DT9871U and DT9874; +100 nA on the DT9871) is provided for thermocouple channels to ensure that open thermocouples are detected. The Open (OPN) LED on the rear panel lights when this condition occurs; see [Figure 5 on page 34](#) for the location of this LED.

In addition, the software returns the value `SENSOR_IS_OPEN` (99999 decimal) for any channel that was configured for a thermocouple input and has either an open thermocouple or no thermocouple connected to it. This value is returned anytime a voltage greater than 100 mV is measure on the input, since this value is greater than any legitimate thermocouple voltage.

If the channel is configured for a voltage input (not a thermocouple type), the Open (OPN) LED never lights and the `SENSOR_IS_OPEN` value is not returned. Instead, the voltage value is returned. If no input is connected to the channel, the software returns a value of approximately 0.7 V due to the open thermocouple detection pull-up circuit.

## **RTD Channels**

For channels that support RTDs, you can attach a voltage input or any of the following RTD types in a mix and match fashion: Platinum 100  $\Omega$  (Pt100), Platinum 500  $\Omega$  (Pt500), or Platinum 1000  $\Omega$  (Pt1000) RTD using an European alpha curve of 0.00385 or an American alpha curve of 0.00392. The supported temperature measurement range for these RTD types is  $-200^{\circ}\text{C}$  ( $-328^{\circ}\text{F}$ ) to  $850^{\circ}\text{C}$  ( $1562^{\circ}\text{F}$ ). You can also measure a resistance value between 0 and 4k Ohms, if desired. (Refer to [page 88](#) for information on the supported input range for voltage measurements.)

By default, all channels are configured for voltage inputs. You can specify the RTD types for channels using the DT-Open Layers Control Panel applet, described on [page 37](#), the Change Configuration dialog in the supplied Measurement Application, described on [page 67](#), or by using an API call in your application program

---

**Notes:** In a mix-and-match system, it is easy to accidentally mismatch the software and hardware configuration for a channel. Therefore, it is recommended that you pay particular attention when configuring channels, since the resultant errors may be not large enough to notice initially, but may be significantly larger than the accuracy specification for the instrument.

---

Since each channel has its own 24-bit A/D, analog inputs are measured simultaneously. Refer to [page 92](#) for more information on specifying the channels for a scan.

## **Input Ranges**

The input voltage range that is supported by your `TEMPpoint`, `VOLTpoint`, or `MEASURpoint` instrument depends on the specific instrument model that you purchased, as shown in [Table 4](#).

**Table 4: Supported Input Ranges**

Instrument Type	Models	Input Range
TEMPpoint	DT9871U	$\pm 0.75$ V for all channels
	DT9871	$\pm 1.25$ V for all channels
	DT9872	$\pm 1.25$ V for all channels
VOLTpoint	DT9873	$\pm 10$ V, $\pm 100$ V, or $\pm 400$ V (software-selectable for each channel) <sup>a</sup>
MEASURpoint	DT9874-16T-16R-16V	$\pm 0.75$ V for channels 0 to 15; $\pm 1.25$ V for channels 15 to 31; $\pm 10$ V, $\pm 100$ V, or $\pm 400$ V for channels 32 to 47 (software-selectable for each channel)

a. Older versions of this instrument had fixed input ranges of  $\pm 10$  V,  $\pm 100$  V, or  $\pm 400$  V, depending on the model purchased.

### ***Out of Range Data for Thermocouple Channels***

Each thermocouple type corresponds to an allowable voltage range. If a voltage is measured on the input that is outside of the legal range for the selected thermocouple type, the channel may be configured for the wrong type of thermocouple or something other than a thermocouple may be connected to the channel.

For channels configured with a thermocouple type of None (voltage), the Limit (LMT) LED on the rear panel of the instrument lights to alert you when the voltage is out of range; see [Figure 5 on page 34](#) for the location of this LED.

For channels configured with a thermocouple type other than None (voltage), the LMT LED lights when the temperature limit is out of range for the specified thermocouple type.

In addition, if the input voltage is less than the legal voltage range for the selected thermocouple type, the software returns the value TEMP\_OUT\_OF\_RANGE\_LOW (-88888 decimal). If the input voltage is greater than the legal voltage range for the selected thermocouple type, the software returns the value TEMP\_OUT\_OF\_RANGE\_HIGH (88888 decimal).

---

**Note:** If you are continuously measuring from a properly configured thermocouple input channel and the thermocouple opens or becomes disconnected, the open thermocouple pull-up circuit causes the input voltage to rise to approximately 0.7 V over a few seconds.

In this case, the temperature value rises very quickly, and you will receive the TEMP\_OUT\_OF\_RANGE\_HIGH (88888 decimal) value followed by the OPEN\_SENSOR (99999 decimal) value. In this case, the OPN LED lights when the open thermocouple is detected and the LMT LED lights when the temperature limit is out of range for the thermocouple type.

---

## Out of Range Data for RTD Channels

Each RTD type corresponds to an allowable voltage range. If a voltage is measured on the input that is outside of the legal range for the selected RTD type, the channel may be configured for the wrong type of RTD or something other than an RTD may be connected to the channel.

For channels configured with a RTD type of voltage, the Limit (LMT) LED on the rear panel of the instrument lights to alert you when the voltage is out of range (greater than +1.25 V or less than -1.25 V); see [Figure 5 on page 34](#) for the location of this LED. For channels configured with an RTD type other than voltage, the LMT LED lights when the temperature limit is out of range for the specified RTD type.

In addition, if the input voltage is less than the legal voltage range for the selected RTD type, the software returns the value TEMP\_OUT\_OF\_RANGE\_LOW (-88888.0 decimal). If the input voltage is greater than the legal voltage range for the selected RTD type, the software returns the value TEMP\_OUT\_OF\_RANGE\_HIGH (88888.0 decimal).

## Out of Range Data for High Voltage Channels

Each voltage input channel has an allowable voltage range ( $\pm 10$  V,  $\pm 100$  V, or  $\pm 400$  V). You configure the input range for each channel using software. If a voltage is measured on the input that is outside of the legal range for that channel, the Limit (LMT) LED on the rear panel of the instrument lights to alert you; see [Figure 5 on page 34](#) for the location of this LED.

## Resolution

TEMPpoint, VOLTpoint, and MEASURpoint instruments support a resolution of 24 bits for the analog input subsystem; you cannot specify the resolution in software.

## Calibration

Each TEMPpoint, VOLTpoint, and MEASURpoint instrument is factory-calibrated to meet or exceed its published specifications using standards traceable to NIST.

The calibration process includes multiple steps. First, the A/D on each channel is calibrated for offset and gain; these values (including the zero point) are stored in ROM. Then, each CJC circuit is calibrated for thermocouple input channels, and the reference current is characterized for RTD channels.

While each instrument was designed to preserve high accuracy measurements over time, it is recommended that your instrument be recalibrated every year to ensure that it meets or exceeds specifications.

You can calibrate your instrument in the field using precise calibration equipment and the Measurement Calibration Utility, described on [page 15](#). Optionally, you can return your instrument to Data Translation for recalibration. For information on factory recalibration, contact Data Translation at 508-481-3700, ext. 1323 (if you are in the USA) or call your local distributor (if you are located outside the USA); see our web site ([www.datatranslation.com](http://www.datatranslation.com)) for the name and telephone number of your nearest distributor.

In addition, each instrument auto-calibrates on each power-up cycle to guarantee high-accuracy measurements. This process, also known as auto-zeroing, resets the zero point of each A/D. You can also auto-calibrate the instrument at any time (as long as acquisition is not in progress) using a software command. Refer to your software documentation for more information on the auto-calibration feature.

## Sample Clock Source

TEMPpoint, VOLTpoint, and MEASURpoint instruments support an internal clock with a maximum sampling rate of 10 Samples/s.

Use software to specify an internal clock source and a clock frequency between 0.000152590219 Hz and 10.0 Hz.

---

**Note:** The clock frequency that you specify is rounded to the closest "correct" value that the instrument can accept without error. Internally, the 10 Hz clock is divided by an integer in the range of 1 to 65535 (the internal clock divider) to determine the closest value. Using software, you can query this setting to determine the actual clock frequency that is used.

---

When the continuous operation is started, all the channels specified in the channel list are read simultaneously at the specified clock frequency.

## Trigger Source

A trigger is an event that occurs based on a specified set of conditions. Acquisition starts when the instrument detects the initial trigger event and stops when you stop the operation.

TEMPpoint, VOLTpoint, and MEASURpoint instruments support the following trigger sources for starting analog input operations:

- **Software trigger** – A software trigger event occurs when you start the analog input operation (the computer issues a write to the instrument to begin conversions).
- **External digital trigger** – An external digital trigger event occurs when the instrument detects a voltage from +3 V to +28 V DC on digital input line 0. Initially, the external signal must be low and then go high for at least 100 ms to be detected as a trigger. Once triggered, the state of digital input 0 is ignored.

## Conversion Modes

TEMPpoint, VOLTpoint, and MEASURpoint instruments support continuous scan conversion modes for reading input measurements.

Continuous scan mode takes full advantage of the capabilities of the TEMPpoint, VOLTpoint, and MEASURpoint instruments. Use continuous scan mode if you want to accurately control the period between successive simultaneous conversions of specific channels.

In addition to the analog input channels, this conversion mode allows you to read the digital input port (all 8 digital input lines) as part of the analog input data stream. This feature is particularly useful when you want to correlate the timing of analog and digital events.

### ***Specifying Analog Input Channels***

Using software, enable the analog input channels that you want to sample by specifying the channel numbers in the channel list. You can also read the value of the digital input port through the analog input data stream by specifying the digital input channel in the channel list; the number of the digital input channel depends on how many channels the TEMPpoint, VOLTpoint, or MEASURpoint instrument provides, as shown in [Table 5](#).

**Table 5: Supported Channels for Continuous Operations**

Total Number of Analog Input Channels	Channel for Reading the Digital Input Port
0 to 7	8
0 to 15	16
0 to 23	24
0 to 31	32
0 to 39	40
0 to 47	48

The channels are read in order from the lowest channel number to the highest channel number in the list of enabled channels; this process is known as a scan.


### ***How Continuous Scan Works***

When you issue a command to start the scan, the instrument simultaneously samples all the analog input channels, CJC inputs (if applicable), and the digital input port, and converts the analog inputs to temperature, resistance, or voltage based on the sensor type. If the channel is enabled, the sampled data is placed in the FIFO on the instrument.

The FIFO on the instrument is used as a circular buffer. Acquisition continues indefinitely until you stop the operation. When the FIFO is full, the operation wraps to the beginning of the FIFO; values are overwritten starting at the first location in the FIFO. It is up to your application to retrieve the data from the FIFO; refer to your software documentation for more information.

The conversion rate is determined by the frequency of the input sample clock; refer to [page 91](#) for more information about the input sample clock. The sample rate, which is the rate at which a single entry in the channel list is sampled, is the same as the conversion rate due to the simultaneous nature of the MEASURpoint instrument.

[Figure 29](#) illustrates scanning a list of three enabled channels: channel 0, channel 1, and channel 2. In this example, analog input data is acquired simultaneously on each clock pulse of the input sample clock. Data is acquired continuously.



**Figure 29: Continuous Scan Mode**

## Filtering

TEMPpoint, VOLTpoint, and MEASURpoint instruments use a Delta-Sigma analog-to-digital converter (ADC) for each analog input channel to provide simultaneous sampling of all inputs. The Delta-Sigma converter operates at 10 Hz effectively providing a filter that rejects 50 Hz and 60 Hz power line frequency components and that removes *aliasing*, a condition where high frequency input components erroneously appear as lower frequencies after sampling.

In addition to the filter provided in hardware, you can further reduce noise by selecting one of the following filter options in software: Moving Average or Raw. Refer to [page 67](#) and to your software documentation for more information on selecting a filter type.

## Data Format

TEMPpoint, VOLTpoint, and MEASURpoint instruments return data as 32-bit floating-point values. How the data is returned depends on the channel type, as described in the following subsections.

### **Data Format for Thermocouple Channels**

If you specify a thermocouple type of None for a thermocouple input channel, a voltage measurement is selected and the instrument returns a voltage value. For the DT9871U and DT9874 instruments, the value is in the range of  $\pm 0.075$  V; for the DT9872 instrument, the value is in the range of  $\pm 1.25$  V. For all other thermocouple types, a temperature value, in degrees C, or one of the error constants, described on [page 95](#), is returned.

In normal operation, one floating-point value is returned for each enabled channel (including the digital input port). If you enable the capability of returning CJC data in the data stream, described on [page 87](#), two floating-point values are returned in the data stream for each enabled analog input channel. The first value in the pair represents the temperature (or voltage) of the channel; the second value in the pair represents the CJC temperature (in degrees C) for that channel.

### **Data Format for RTD Channels**

If you specify an RTD type of None for an RTD input channel, a voltage measurement is selected and the instrument returns a voltage value in the range of  $\pm 1.25$  V. If you specify an RTD type of Ohms, a resistance value is returned. For all other RTD types, a temperature value, in degrees C, or one of the error constants, described on [page 95](#), is returned.

One floating-point value is returned for each enabled channel (including the digital input port).

### **Data Format for High Voltage Channels**

For high voltage channels, a voltage value in the range of  $\pm 10$  V,  $\pm 100$  V, or  $\pm 400$  V is returned for each channel, depending on how the channel was configured.

One floating-point value is returned for each enabled channel (including the digital input port).

## **Error Conditions**

TEMPpoint, VOLTpoint, and MEASURpoint instruments report overrun errors by sending an overrun event to the application program. If this error condition occurs, the instrument stops acquiring and transferring data to the host computer. To avoid this error, try one or more of the following:

- Reduce the sample rate
- Close any other applications that are running
- Run the program on a faster computer

Additionally, the following constants may be reported to the host:

- 99999.0 – SENSOR\_IS\_OPEN, described on [page 87](#)
- 88888.0 – TEMP\_OUT\_OF\_RANGE\_HIGH, described on [page 89](#) and [page 90](#)
- -88888.0 – TEMP\_OUT\_OF\_RANGE\_LOW, described on [page 89](#) and [page 90](#)

If any of these constants is reported, the A/D subsystem continues to acquire data; the error condition is cleared when the data falls within range.

## Digital I/O Features

TEMPpoint, VOLTpoint, and MEASURpoint instruments provide 8 digital input lines and 8 digital output lines that you can use to control external equipment, including solid-state or mechanical relays.


This section describes the following digital I/O features:

- Digital input lines, described below
- Digital output lines, described on [page 97](#)
- Channel-to-channel isolation, described on [page 97](#)
- Resolution, described on [page 97](#)
- Operation modes, described on [page 97](#)

### Digital Input Lines

TEMPpoint, VOLTpoint, and MEASURpoint instruments feature eight, isolated, digital input lines.

Digital inputs operate from +3 to +28 V DC, with a switching time of 2 ms maximum. [Figure 30](#) shows the digital input circuitry; a 2.2 k $\Omega$  resistor is used in series with the LED in the opto-isolator input.



**1 of 8 Opto-Isolators**


**Figure 30: Digital Input Circuitry**

A digital line is high (switch is closed) if its value is 1; a digital line is low (switch is open) if its value is 0.

## Digital Output Lines

TEMPpoint, VOLTpoint, and MEASURpoint instruments feature eight, latched and isolated digital output lines. The outputs are solid-state relays that operate at  $\pm 30$  V and 400 mA peak (AC or DC). Switching time is 2 ms maximum.

Figure 31 shows the digital output circuitry.



1 of 8 Solid State Relays

Figure 31: Digital Output Circuitry

Digital outputs resemble a switch; the switch is closed if the state of the digital output line is 1, and the switch is open if the state of the digital output line is 0. On power up or reset, the digital outputs are disabled.

## Channel-to-Channel Isolation

Each TEMPpoint, VOLTpoint, and MEASURpoint instrument includes channel-to-channel isolation of up to 250 V between digital I/O lines. If you require greater channel-to-channel isolation, use every other digital line. This reduces the number of digital I/O lines, but provides channel-to-channel isolation of 500 V (one channel can be +250 V while the adjacent channel can be -250 V).

## Resolution

Each TEMPpoint, VOLTpoint, and MEASURpoint instrument provides 8 bits of resolution for the digital input port to accommodate the 8 digital input lines and 8 bits of resolution for the digital output port to accommodate the 8 digital output lines. These lines are organized as isolated, dedicated ports. You cannot configure port resolution through software.

## Operation Modes

Using software, you can read from a single digital input line or the entire digital input port, or write to a single digital output line or the entire digital output port. You can also return the value of the entire digital input port in the analog input data stream if you want to correlate analog input data with digital events; refer to [page 92](#) for more information.





## ***Troubleshooting***

General Checklist .....	100
Technical Support .....	102
If Your Instrument Needs Factory Service .....	103

## General Checklist

Should you experience problems using a TEMPpoint, VOLTpoint, or MEASURpoint instrument, do the following:

1. Read all the documentation provided for your product. Make sure that you have added any “Read This First” information to your manual and that you have used this information.
2. Check the Instrument OMNI CD for any README files and ensure that you have used the latest installation and configuration information available.
3. Check that your system meets the requirements stated in [Chapter 2](#).
4. Check that you have installed your hardware properly using the instructions in [Chapter 3](#).
5. Check that you have wired your signals properly using the instructions in [Chapter 4](#).
6. Search the DT Knowledgebase in the Support section of the Data Translation web site (at [www.datatranslation.com](http://www.datatranslation.com)) for an answer to your problem.

If you still experience problems, try using the information in [Table 6](#) to isolate and solve the problem. If you cannot identify the problem, refer to [page 102](#).

**Table 6: Troubleshooting Problems**

Symptom	Possible Cause	Possible Solution
Instrument is not recognized	You plugged the instrument into your computer before installing the device driver.	From the Control Panel > System > Hardware > Device Manager, uninstall any unknown devices (showing a yellow question mark). Then, run the setup program on your Instrument OMNI CD to install the USB device drivers, and reconnect your USB instruments to the computer.
Instrument does not respond.	The instrument configuration is incorrect.	Check the configuration of your device driver; see the instructions in <a href="#">Chapter 3</a> .
	The instrument is damaged.	Contact Data Translation for technical support; refer to <a href="#">page 102</a> .
Intermittent operation.	Loose connections or vibrations exist.	Check your wiring and tighten any loose connections or cushion vibration sources; see the instructions in <a href="#">Chapter 4</a> .
	The instrument is overheating.	Check environmental and ambient temperature; consult the specifications on <a href="#">page 118</a> of this manual and the documentation provided by your computer manufacturer for more information.
	Electrical noise exists.	Check your wiring and either provide better shielding or reroute unshielded wiring; see the instructions in <a href="#">Chapter 4</a> .

**Table 6: Troubleshooting Problems (cont.)**

Symptom	Possible Cause	Possible Solution
Device failure error reported.	The instrument cannot communicate with the Microsoft bus driver or a problem with the bus driver exists.	Check your cabling and wiring and tighten any loose connections; see the instructions in <a href="#">Chapter 4</a> .
	The instrument was removed while an operation was being performed.	Ensure that your instrument is properly connected; see the instructions in <a href="#">Chapter 3</a> .
Data appears to be invalid.	An open connection exists.	Check your wiring and fix any open connections; see the instructions in <a href="#">Chapter 4</a> .
	A transducer is not connected to the channel being read.	Check the transducer connections; see the instructions in <a href="#">Chapter 4</a> .
	The thermocouple, RTD, or voltage input that you connected to the channel does not match the software configuration for that channel.	Check your wiring and ensure that what you specify in software matches your hardware configuration; see the instructions in <a href="#">Chapter 4</a> .
	Your instrument may need recalibration.	<p>The instrument is calibrated at the factory. Thereafter, yearly calibration is recommended. Use the Measurement Calibration Utility, described on <a href="#">page 15</a>, or return your instrument to Data Translation for recalibration.</p> <p>For information on factory recalibration, contact Data Translation at 508-481-3700, ext. 1323 (if you are in the USA) or call your local distributor (if you are located outside the USA); see our web site (<a href="http://www.datatranslation.com">www.datatranslation.com</a>) for the name and telephone number of your nearest distributor.</p>
USB 2.0 is not recognized.	Your operating system does not have the appropriate Service Pack installed.	Ensure that you load the appropriate Windows Service Pack (version 2 for Windows XP). If you are unsure of whether you are using USB 2.0 or USB 1.1, run the Open Layers Control Panel applet, described in <a href="#">Chapter 3</a> .
	Standby mode is enabled on your PC.	For some PCs, you may need to disable standby mode on your system for proper USB 2.0 operation. Consult Microsoft for more information.

## **Technical Support**

If you have difficulty using your TEMPpoint, VOLTpoint, or MEASURpoint instrument, Data Translation's Technical Support Department is available to provide technical assistance.

To request technical support, go to our web site at <http://www.datatranslation.com> and click on the Support link.

When requesting technical support, be prepared to provide the following information:

- Your product serial number
- The hardware/software product you need help on
- The version of the Instrument OMNI CD you are using
- Your contract number, if applicable

If you are located outside the USA, contact your local distributor; see our web site ([www.datatranslation.com](http://www.datatranslation.com)) for the name and telephone number of your nearest distributor.

## ***If Your Instrument Needs Factory Service***

If your MEASURpoint instrument must be returned to Data Translation, do the following:

1. Record the instrument's serial number, and then contact the Customer Service Department at (508) 481-3700, ext. 1323 (if you are in the USA) and obtain a Return Material Authorization (RMA).

If you are located outside the USA, call your local distributor for authorization and shipping instructions; see our web site ([www.datatranslation.com](http://www.datatranslation.com)) for the name and telephone number of your nearest distributor. All return shipments to Data Translation must be marked with the correct RMA number to ensure proper processing.

2. Using the original packing materials, if available, package the instrument as follows:
  - Wrap the instrument in an electrically conductive plastic material. Handle with ground protection. A static discharge can destroy components on the instrument.
  - Place in a secure shipping container.
3. Return the instrument to the following address, making sure the RMA number is visible on the outside of the box.

Customer Service Dept.  
Data Translation, Inc.  
100 Locke Drive  
Marlboro, MA 01752-1192





# *Specifications*

Basic Instrument Specifications .....	106
Thermocouple Specifications .....	107
RTD Specifications .....	111
Isolation and Protection Specifications .....	112
Memory Specifications .....	113
Temperature Stability Specifications .....	114
Voltage Measurement Specifications .....	115
Digital I/O Specifications .....	117
Digital I/O Specifications .....	117
Power, Physical, and Environmental Specifications .....	118
Regulatory Specifications .....	119
Connector Specifications .....	120

---

**Note:** All analog input specifications are based on the Moving Average filter type; see [page 93](#) for more information on filter types.

---

## Basic Instrument Specifications

Table 7 lists the basic instrument specifications for TEMPpoint, VOLTpoint, and MEASURpoint instruments.

**Table 7: Basic Instrument Specifications**

Feature	Specifications
Number of channels in channel list	Up to 48 analog input channels and one digital input port
A/D converter type	24-bit Sigma-Delta

## Thermocouple Specifications

[Table 8](#) lists the thermocouple specifications for thermocouple channels on the TEMPpoint and MEASURpoint instruments.

**Table 8: Thermocouple Specifications**

Feature	Specifications
Thermocouple types (software-selectable)	B, E, J, K, N, R, S, T
A/D resolution	24-bits
Sample rate	10 Samples/s <sup>a</sup>
Thermal disturbance channel-to-channel	None
Upscale break detection current DT9871U and DT9874: DT9871:	+10 nA +100 nA
System temperature error DT9871U and DT9874: DT9871:	See <a href="#">Table 9 on page 108</a> See <a href="#">Table 10 on page 109</a>

- a. Older versions of the DT9871 instrument may support a maximum sampling rate of 7.5 Samples/s.

## System Temperature Error for the DT9871U and DT9874

Table 9 lists the accuracy of the DT9871U and DT9874 for each thermocouple type at several temperature points over the dynamic range of the instrument.

**Table 9: Calculated Thermocouple Accuracy of the DT9871U and DT9874**

Input Temp.	Thermocouple Type <sup>a</sup>							
	J	K	T	E	S	R	B	N
-100° C	±0.17° C	±0.17° C	±0.16° C	±0.16° C	-----	-----	-----	±0.16° C
0° C	±0.15° C	±0.16° C	±0.16° C	±0.15° C	±0.2° C	±0.2° C	-----	±0.16° C
100° C	±0.18° C	±0.15° C	±0.16° C	±0.15° C	±0.18° C	±0.18° C	-----	±0.15° C
300° C	±0.15° C	±0.17° C	±0.16° C	±0.15° C	±0.18° C	±0.18° C	±0.23° C	±0.15° C
500° C	±0.15° C	±0.15° C	-----	±0.15° C	±0.18° C	±0.17° C	±0.21° C	±0.15° C
700° C	±0.15° C	±0.15° C	-----	±0.16° C	±0.18° C	±0.18° C	±0.17° C	±0.16° C
900° C	±0.15° C	±0.17° C	-----	±0.17° C	±0.18° C	±0.18° C	±0.19° C	±0.16° C
1100° C	±0.15° C	±0.16° C	-----	-----	±0.19° C	±0.18° C	±0.18° C	±0.16° C
1400° C	-----	-----	-----	-----	±0.18° C	±0.18° C	±0.17° C	-----


**a. Conditions for accuracy measurements:**

Warm-up time of 45 minutes. Inclusive of typical 0.15° C CJC error (maximum CJC error is 0.25° C).

Inclusive of typical 0.25  $\mu$ V offset error (maximum offset error is 2.5  $\mu$ V). Exclusive of thermocouple errors.

Exclusive of noise (see Figure 32 and Figure 33 for more information about system noise).

The histograms shown in Figure 32 and Figure 33 characterize the Gaussian system noise distribution for each of the available filter types on the DT9871U and DT9874. Note that converting  $\mu$ V error to temperature error depends on thermocouple type. For example, a K thermocouple changes approximately 39  $\mu$ V per degrees C; therefore, a noise level of 0.1  $\mu$ V adds less than 0.003° C error (0.1  $\mu$ V / 39  $\mu$ V) for a type K thermocouple.



**Figure 32: System Noise on the DT9871U and DT9874 Using No Software Filter (Raw Filter)**




Figure 33: System Noise on the DT9871U and DT9874 Using the Moving Average Filter

## System Temperature Error for the DT9871

Table 10 lists the accuracy of the DT9871 for each thermocouple type at several temperature points over the dynamic range of the instrument.

Table 10: Calculated Thermocouple Accuracy of the DT9871

Input Temperature	Thermocouple Type <sup>a</sup>							
	J	K	T	E	S	R	B	N
-100° C	±0.33° C	±0.37° C	±0.38° C	±0.31° C	-----	-----	-----	±0.44° C
0° C	±0.3° C	±0.33° C	±0.33° C	±0.28° C	±1.12° C	±1.14° C	-----	±0.39° C
100° C	±0.31° C	±0.29° C	±0.31° C	±0.27° C	±0.88° C	±0.86° C	-----	±0.35° C
300° C	±0.29° C	±0.34° C	±0.29° C	±0.26° C	±0.75° C	±0.71° C	±1.84° C	±0.33° C
500° C	±0.28° C	±0.31° C	-----	±0.26° C	±0.71° C	±0.66° C	±1.2° C	±0.33° C
700° C	±0.27° C	±0.3° C	-----	±0.27° C	±0.68° C	±0.63° C	±0.92° C	±0.33° C
900° C	±0.27° C	±0.34° C	-----	±0.28° C	±0.66° C	±0.6° C	±0.8° C	±0.33° C
1100° C	±0.28° C	±0.34° C	-----	-----	±0.64° C	±0.58° C	±0.71° C	±0.34° C
1400° C	-----	-----	-----	-----	±0.62° C	±0.56° C	±0.64° C	-----

a. Conditions for accuracy measurements:

Warm-up time of 45 minutes. Inclusive of typical 0.2° C CJC error (maximum CJC error is 0.3° C).

Inclusive of typical 5 μV offset error (maximum offset error is 50 μV). Exclusive of thermocouple errors.

Exclusive of noise (see Figure 34 and Figure 35 for more information about system noise).

The histograms shown in [Figure 34](#) and [Figure 35](#) characterize the Gaussian system noise distribution for each of the available filter types on the DT9871. Note that converting  $\mu\text{V}$  error to temperature error depends on thermocouple type. For example, a K thermocouple changes approximately  $39 \mu\text{V}$  per degrees C; therefore, a noise level of  $10 \mu\text{V}$  adds  $0.3^\circ \text{C}$  error ( $10 \mu\text{V} / 39 \mu\text{V}$ ) for a type K thermocouple.




Figure 34: System Noise on the DT9871 Using No Software Filter (Raw Filter)




Figure 35: System Noise on the DT9871 Using the Moving Average Filter

## RTD Specifications

[Table 11](#) lists the specifications for RTD channels on the TEMPpoint and MEASURpoint instruments.

**Table 11: RTD Specifications**

Feature	Specifications
RTD types (software-selectable)	Platinum 100 $\Omega$ , 500 $\Omega$ and 1000 $\Omega$
A/D converter resolution	24-bits
Sample rate	10 Samples/s <sup>a</sup>
Supported temperature range	-200 to +850° C (European standard)
Current source Absolute current:	425 $\mu$ A, $\pm$ 0.5% at 25° C (calibrated in firmware)
Drift:	10 ppm/° C maximum
Drift per year:	$\pm$ 100 ppm typical
Internal reference	+1.250 $\pm$ 0.002 V
Thermal disturbance channel-to-channel	None
Supported RTD alpha curves	See <a href="#">Table 12 on page 111</a>

a. Older versions of this instrument may support a maximum sampling rate of 7.5 Samples/s.

[Table 12](#) lists the RTD alpha curves that are supported by RTD channels.

**Table 12: Supported RTD Alpha Curves**

Alpha (Average Temperature Coefficient of Resistance ( $^{\circ}$ C))	Nominal Resistance at 0° C	Organization	Standard
0.00385	100 $\Omega$	British Standard	BS1904: 1984
		Deutschen Institut für Normung	DIN 43760: 1980
0.00392	98.129 $\Omega$	Scientific Apparatus Manufacturers of America	SAMA RC-4-1966

## Isolation and Protection Specifications

Table 13 lists the isolation and protection specifications for the analog input subsystem on the TEMPpoint, VOLTpoint, and MEASURpoint instruments.

**Table 13: Isolation and Protection Specifications**

Feature	Specifications
Overvoltage protection (power on/off) DT9871U, DT9871, and DT9874 thermocouple channels: DT9872 and DT9874 RTD channels: DT9873 and DT9874 high voltage channels:	$\pm 40$ V $\pm 40$ V $\pm 500$ V
ESD protection Arc: Contact:	8 kV 4 kV
Isolation voltage to the host computer	$\pm 500$ V
Channel-to-channel isolation	$\pm 500$ V

## Memory Specifications

Table 14 lists the memory specifications for the analog input subsystem on the TEMPpoint, VOLTpoint, and MEASURpoint instruments.

**Table 14: Memory Specifications**

Feature	Specifications
Data memory onboard	4 MByte
For Data logger built in, maximum time before old data is overwritten <sup>a</sup>	
48 channels @ 10 Hz:	30 minutes
48 channels @ 1 Hz:	5 hours
48 channels @ 0.1 Hz:	50 hours

- a. Assumes limit detection is off for all channels, and for thermocouple channels, assumes CJC data is not collected. If power fails, all temperature data in the system is lost. The channel input type and filter settings are still available after power on, but the channel and digital I/O labels and channel limits are lost.

## Temperature Stability Specifications

Table 15 lists the temperature stability specifications for thermocouple channels on the TEMPpoint and MEASURpoint instruments.

**Table 15: Temperature Stability Specifications for Thermocouple Channels**

Feature	Specifications
Additional error due to ambient temperature change <sup>a</sup> J-type thermocouple: K-type thermocouple: B-type thermocouple: E-type thermocouple: N-type thermocouple: R-type thermocouple: S-type thermocouple: T-type thermocouple:	0.010° C per degree ambient change, typical 0.011° C per degree ambient change, typical 0.014° C per degree ambient change, typical 0.010° C per degree ambient change, typical 0.011° C per degree ambient change, typical 0.012° C per degree ambient change, typical 0.012° C per degree ambient change, typical 0.010° C per degree ambient change, typical
Warm-up time	45 minutes
CJC Error:  Accuracy:  Drift per year:	±0.2° C  Corrected in ROM @ 25° C to zero error  ±50 ppm typical

a. Includes the A/D reference, gain, and CJC errors.

Table 16 lists the temperature stability specifications for RTD channels on the TEMPpoint and MEASURpoint instruments.

**Table 16: Temperature Stability Specifications for RTD Channels**

Feature	Specifications
System temperature error <sup>a</sup> Pt100: Pt500: Pt1000:	±0.07° C, ±0.005% of reading ±0.01° C, ±0.005% of reading ±0.007° C, ±0.005% of reading
Temperature resolution	±0.0003° C (based on a European PT1000 RTD)
Warm-up time	1 minute

a. The system temperature error is based on the auto zero and system noise error (±0.07° C for a Pt100 RTD, ±0.01° C for a Pt500 RTD, or ±0.007° C for a Pt1000 RTD) plus the gain error of the A/D and output impedance of the current source over the voltage range (±0.005% of the reading). For example, the maximum error of a Pt100 RTD at 100° C is ±0.075° C (±0.07° C plus a gain error of ±0.005° C).

## Voltage Measurement Specifications

Table 17 lists the voltage measurement specifications for the TEMPpoint, VOLTpoint, and MEASURpoint instruments.

**Table 17: Voltage Measurement Specifications**

Feature	Specifications
Input voltage range (no compensation) DT9871U and DT9874 thermocouple channels: DT9871: DT9872 and DT9874 RTD channels: DT9873 and DT9874 high voltage channels:	$\pm 0.0750$ V $\pm 1.2500$ V $\pm 1.2500$ V $\pm 10$ V, $\pm 100$ V, or $\pm 400$ V <sup>a</sup>
A/D converter resolution	24-bits
Voltage resolution DT9871U and DT9874 thermocouple channels: DT9871: DT9872 and DT9874 RTD channels: DT9873 and DT9874 high voltage channels:	0.015 $\mu$ V 0.3 $\mu$ V 0.3 $\mu$ V 1.2 $\mu$ V for the $\pm 10$ V input range; 12 $\mu$ V for the $\pm 100$ V input range; 48 $\mu$ V for the $\pm 400$ V input range
Sample rate	10 Samples/s <sup>b</sup>
Gain	1
Input impedance DT9871U and DT9874 thermocouple channels: DT9871: DT9872 and DT9874 RTD channels: DT9873 and DT9874 high voltage channels:	5 M $\Omega$ typical 5 M $\Omega$ typical >100 M $\Omega$ >1 M $\Omega$ (Power ON or OFF)
Input common mode voltage	$\pm 500$ V
Common mode rejection @ 60 Hz and 50 Hz	> 150 dB
Coupling	DC
System linearity DT9871U and DT9874 thermocouple channels: DT9871: DT9872 and DT9874 RTD channels: DT9873 and DT9874 high voltage channels:	$\pm 0.005\%$ $\pm 0.005\%$ $\pm 0.001\%$ $\pm 0.001\%$
System gain error (includes all noise sources; gain = 1) DT9871U and DT9874 thermocouple channels: DT9871: DT9872 and DT9874 RTD channels: DT9873 and DT9874 high voltage channels:	$\pm 0.00075\%$ of full-scale range $\pm 0.00075\%$ of full-scale range $\pm 0.00075\%$ of full-scale range $\pm 0.01\%$ of reading
System zero error (includes all noise sources; gain = 1; no filter) DT9871U and DT9874 thermocouple channels: DT9871: DT9872 and DT9874 RTD channels: DT9873 and DT9874 high voltage channels:	0.25 $\mu$ V RMS 5 $\mu$ V RMS $\pm 12$ $\mu$ V $\pm 300$ $\mu$ V for the $\pm 10$ V input range; $\pm 2$ mV for the $\pm 100$ V input range; $\pm 8$ mV for the $\pm 400$ V input range

Table 17: Voltage Measurement Specifications (cont.)

Feature	Specifications
System drift error, zero DT9871U and DT9874 thermocouple channels: DT9871: DT9872 and DT9874 RTD channels: DT9873 and DT9874 high voltage channels:	$\pm 0.02 \mu\text{V}/^\circ\text{C}$ typical $\pm 0.02 \mu\text{V}/^\circ\text{C}$ typical $\pm 0.10 \mu\text{V}/^\circ\text{C}$ $\pm 0.5 \mu\text{V}/^\circ\text{C}$ for the $\pm 10\text{ V}$ input range; $\pm 5 \mu\text{V}/^\circ\text{C}$ for the $\pm 100\text{ V}$ input range; $\pm 20 \mu\text{V}/^\circ\text{C}$ for the $\pm 400\text{ V}$ input range
System drift error, gain DT9871U and DT9874 thermocouple channels: DT9871: DT9872 and DT9874 RTD channels: DT9873 and DT9874 high voltage channels:	$\pm 4 \text{ ppm}/^\circ\text{C}$ $\pm 4 \text{ ppm}/^\circ\text{C}$ $\pm 10 \text{ ppm}/^\circ\text{C}$ $\pm 15 \text{ ppm}/^\circ\text{C}$
A/D reference Drift: Drift per year:	$\pm 8 \text{ ppm}/^\circ\text{C}$ maximum $\pm 100 \text{ ppm}$ typical
Full-scale long-term stability DT9871U and DT9874 thermocouple channels:  DT9871:  DT9872 and DT9874 RTD channels:  DT9873 and DT9874 high voltage channels:	$\pm 100 \text{ ppm/year}$ typical  $\pm 100 \text{ ppm/year}$ typical  $\pm 0.05^\circ\text{C}$ per year @ $0^\circ\text{C}$ ( $\pm 0.27^\circ\text{C}$ per year @ full-scale temperature)  $\pm 100 \text{ ppm/year}$ typical
Warm-up time for the DT9873 and DT9874 high voltage channels:	1 hour

- a. You configure the input range for each channel using software.
- b. Older versions of the instrument may support a maximum sampling rate of 7.5 Samples/s.

## Digital I/O Specifications

Table 18 lists the specifications for the digital input (DIN) and digital output (DOUT) subsystems on the TEMPpoint, VOLTpoint, and MEASURpoint instruments.

**Table 18: Digital I/O Specifications**

Feature	Specifications
Number of digital I/O lines	16 (8 In, 8 Out)
Number of ports	2, 8-bit (1 In, 1 Out)
Inputs Input type: High input voltage: Low input voltage: High input current: Low input current: Termination	DC +3 to +28 V < +1.5 V 2.2 k $\Omega$ resistor to 1.2 V 2.2 k $\Omega$ resistor to 1.2 V Series 2.2 k $\Omega$
Outputs Output type: Output driver: High output: Low output: Breakdown voltage: Contact impedance:	Solid-state relay CMOS $\pm 30$ V 0.4 V @ 400 mA $\pm 60$ V 1 $\Omega$
Isolation voltage To computer ground: Channel to channel	$\pm 500$ V $\pm 250$ V <sup>a</sup>

- a. Determined by the pin spacing in the 37-pin digital connector. For greater channel-to-channel isolation, use every other digital I/O line; using every other digital I/O line allows  $\pm 500$  V isolation channel-to-channel.

## Power, Physical, and Environmental Specifications

Table 19 lists the power, physical, and environmental specifications for the TEMPpoint, VOLTpoint, and MEASURpoint instruments.

**Table 19: Power, Physical, and Environmental Specifications**

Feature	Specifications
USB power +5 V Standby: +5 V Power On: +5 V Enumeration:	500 $\mu$ A maximum (360 $\mu$ A typical) 2 mA maximum (1 mA typical) 2 mA maximum (1 mA typical)
External power requirements	+5 V $\pm$ 0.25V @ 2 A (0.9 mA typical)
Physical Dimensions of enclosure:  Weight:	88.14 (H) x 212.85 mm (W) x 211.43 mm (D)  1704 g
Environmental Operating temperature range: Storage temperature range: Relative humidity: Altitude:	0° C to 55° C -25° C to 85° C to 95%, noncondensing up to 10,000 feet

## Regulatory Specifications

Table 20 lists the regulatory specifications for the TEMPpoint, VOLTpoint, and MEASURpoint instruments.

**Table 20: Regulatory Specifications**

Feature	Specifications
Emissions (EMI)	FCC Part 15, EN55022:1994 + A1:1995 + A2:1997 VCCI, AS/NZS 3548 Class A
Immunity	EN61000-6-1:2001
RoHS (EU Directive 2002/95/EG)	Compliant (as of July 1st, 2006)
Aerospace Material Specification	Compliant with AMS2750D

## Connector Specifications

This section lists the specifications for the following connector types:

- Thermocouple connectors
- RTD connectors
- High Voltage connectors

### Thermocouple Connectors

Table 21 lists the specifications for the thermocouple connectors used on the TEMPpoint and MEASURpoint instruments.

**Table 21: Thermocouple Connector Specifications**

Feature	Specifications
Thermocouple jacks	Cu-Cu Omega plugs (White SMPW-U-M)
Thermocouple connector	Omega part# PCC-SMP-U-100-R-CE-ROHS

### RTD Connectors

Table 22 lists the specifications for the RTD connectors used on the TEMPpoint and MEASURpoint instruments.

**Table 22: RTD Connector Specifications**

Feature	Specifications
4-Position screw terminal block header	Phoenix Contact 1803293
4-Position screw terminal block plug	Phoenix Contact 1803594

### High Voltage Connectors

Table 23 lists the specifications for the high voltage connectors used on the VOLTpoint and MEASURpoint instruments.

**Table 23: Voltage Connector Specifications**

Feature	Specifications
4-Position screw terminal block header	Phoenix Contact 1803293
4-Position screw terminal block plug	Phoenix Contact 1803594



## ***Connector Pin Assignments***

Table 24 lists the pin assignments for the 37-pin digital I/O connector on TEMPpoint, VOLTpoint, and MEASURpoint instruments.

**Table 24: Digital I/O Connector Pin Assignments**

Pin	Description	Pin	Description
1	Digital Input 0+	–	
2	Digital Input 1+	20	Digital Input 0–
3	Digital Input 2+	21	Digital Input 1–
4	Digital Input 3+	22	Digital Input 2–
5	Digital Input 4+	23	Digital Input 3–
6	Digital Input 5+	24	Digital Input 4–
7	Digital Input 6+	25	Digital Input 5–
8	Digital Input 7+	26	Digital Input 6–
9	Not Connected	27	Digital Input 7–
10	Digital Output 0	28	Not Connected
11	Digital Output 1	29	Digital Output 0
12	Digital Output 2	30	Digital Output 1
13	Digital Output 3	31	Digital Output 2
14	Digital Output 4	32	Digital Output 3
15	Digital Output 5	33	Digital Output 4
16	Digital Output 6	34	Digital Output 5
17	Digital Output 7	35	Digital Output 6
18	Not Connected	36	Digital Output 7
19	Not Connected	37	Not Connected



## ***About ISO-Channel Technology***

ISO-Channel Technology.....	124
Why ISO-Channel Technology is Your Best Return On Investment.....	125
Floating Signal Inputs Offer New Application Advantages .....	131

## ***ISO-Channel Technology***

All TEMPpoint, VOLTpoint, and MEASURpoint products use ISO-Channel™ technology to eliminate common mode noise and ground loop problems.

This appendix includes two white papers that describe the benefits of using ISO-Channel technology.

## Why ISO-Channel Technology is Your Best Return on Investment


When connecting signal sources to an instrument, it is important to eliminate the sources of error that can contribute to inaccuracies in your measurements. In most measurement instruments, this burden is on the customer. Instruments that use ISO-Channel technology, however, solve this problem for you – saving you tremendous setup and debug time and reducing costly grounding problems when connecting signals.

In today's economy, we understand that every equipment decision needs to make good fiscal sense. This section describes why instruments with ISO-Channel technology offer you the best return on investment.

### Understanding Ground Loops

When measuring signals, users often assume that the grounds of their signals and their measurement system are at the same potential. However, these ground potentials can differ by hundreds of millivolts.

If the difference in ground potential is large enough, current flows between the signal and your measurement system; this is called a ground loop (see [Figure 36](#)). Ground loops contribute noise that can greatly affect the accuracy of your measurements, especially when you are trying to measure low level signals precisely. Ground loop problems are the most common source of error in all measurements! Eliminating these errors, therefore, is critical when taking high accuracy measurements.




When a ground loop exists, the measured voltage,  $V_{out}$ , is the sum of the signal voltage,  $V_{source}$ , and the ground potential difference,  $V_{cm}$ , which exists between the signal source ground and the measurement system ground. These errors often appear as transients or periodic signals in the measurement. For example, if a ground loop is formed with 50 Hz or 60 Hz AC power lines, the unwanted AC signal appears as a periodic voltage error in the measurement.

Figure 36: Measurement System with a Ground Loop

## ISO-Channel Eliminates Ground Loops and Increases Common-Mode Rejection

ISO-Channel technology eliminates ground loop problems by using a **differential, isolated, floating front-end**. As you can see in [Figure 37](#), a floating voltage signal is not referenced to system ground.



**Figure 37: Floating Signals**

To measure floating signal sources, ISO-Channel technology uses differential analog input signals, a 24-bit Delta-Sigma A/D converter for each channel, and channel-to-channel isolation, as shown in [Figure 38](#).





Figure 38: ISO-Channel Technology

### ***Floating, Differential Signals***

ISO-Channel technology implements a virtually ideal differential measurement system that reads only the potential difference between the positive and negative terminals of the amplifier. For each channel, the differential signals are isolated in that they are referenced to a ground reference point that is not connected to earth ground. Ground loop problems are eliminated by ensuring that only one ground reference is used for each channel in the measurement system. The signal sources are isolated from each other and from the measurement instrument.



**Figure 39: Differential Signals and Common-Mode Voltage**


When the measurement instrument and signal source are at different ground potentials, the difference in potential is called common-mode voltage. The measurement instrument cannot discern between the signal and the common-mode voltage believing that the sum of these voltages is the actual signal. Of course, the common-mode potential is simply an error.

ISO-Channel technology provides common-mode rejection of 150 dB, which contributes an almost imperceptible error (33.5 million to 1) to  $V_{out}$ . Compare this to traditional data acquisition measurement instruments, which typically provide only 80 dB of common-mode rejection and therefore, contribute much more error on the order of 1 part per 10,000.

### ***Simultaneous Architecture***

Many measurement instruments on the market today provide multiplexed architectures, where one A/D is used to measure multiple channels. In this kind of architecture, if one channel goes down, all channels go down.

ISO-Channel technology, on the other hand, uses a simultaneous architecture, where each channel has its own dedicated 24-bit Delta-Sigma A/D, as shown in [Figure 40](#).



**Figure 40: Simultaneous vs. Multiplexed Architectures**

### ***Channel-to-Channel Isolation***

Besides differential inputs, floating channels, and a simultaneous architecture, ISO-Channel technology provides channel-to-channel isolation, not just isolation from the analog front-end to the computer ground. With this kind of isolation, the channels are individually isolated from each other and from other system components.

Typically, instrument manufacturers have used relays, isolation amplifiers, or optical isolation to provide channel-to-channel isolation. These methods have the following advantages and limitations:

- Relays – This technology provides good galvanic separation and can provide good accuracy and thermal properties, but relays are slow as they operate on one channel at a time (10 cycles/s), wear out over time, and are sensitive to magnetic fields. If one relay sticks, staying closed, the entire system fails!
- Isolation amplifiers – Isolation amplifiers are used in multiplexed architectures. While they are solid-state, they are expensive, not as accurate, require more power, and generate more noise and heat than other solutions.
- Optical isolation - Optical isolation is good in digital isolation systems but causes accuracy problems in analog isolation systems. It is also subject to long-term drift and requires considerably more power.


With ISO-Channel technology, the A/D is on the sensor side and has its own custom DC/DC converter. Then, optical or transformer isolation is used to transfer the A/D output data (the sensor data) **digitally**. And, due to the simultaneous architecture of ISO-Channel technology, all data is transferred in parallel.

## **Summary**

ISO-Channel technology offers built in system redundancy to protect your investment - if one channel fails, the remaining channels are completely unaffected! Instruments with ISO-Channel technology also adapt to the sensors that they are connected to, allowing a different ground reference for each signal without introducing errors! For these key reasons, ISO-Channel technology protects against problems in the field, and thereby, reduces costs – what a great return on your investment.


## Floating Signal Inputs Offer New Application Advantages

Precision measurement systems are often limited in that all inputs are connected to a single ground. Typically, multiplexer input configurations are set up this way, since all signal inputs are connected to the same return. Even differential input configurations use the same ground reference. The result is that accuracy and flexibility for accurate measurements can be severely compromised when noise or common mode voltage is present (see [Figure 41](#)).



**Figure 41: In multiplexed systems, all inputs are connected to a signal ground, which can cause errors when noise or common mode voltage is present.**

Crosstalk from one input signal can easily be reflected onto another input. The design movement to an A/D per channel can help this problem. But that is not sufficient in many cases (see [Figure 42](#)).




**Figure 42: Even when using an A/D per channel, noise can contribute errors to your measurement results.**

To minimize noise and ground loops, some newer systems offer isolation between the input signal ground reference and the computer ground. This effectively separates the computer ground from the measurement portion of the system. But still, there is no isolation between input sensor channels, which is a common source of error and frustration for user applications. Why?

The assumption is made that all signal sources have the same exact ground reference. After all...ground is ground...isn't it? Often this is not the case. For example, thermocouples for measuring temperature may be dispersed widely throughout an industrial setting, such as in the manufacture of air frames or in curing ovens. Grounds for these sensors may differ by several volts or even hundreds of volts. The resulting common mode voltage causes current to flow in the signal path, producing serious errors, which are very hard to diagnose and correct.

## Isolating Each Input


Oftentimes it is NOT apparent that ground references from various sensors such as thermocouples, RTDs, strain gages, etc., are at different voltage potentials. Factors that can contribute to these ground differences are extensive wiring from long runs, crosstalk from motors or generators, or high source impedance from the signal source. Without recognizing this extraneous voltage, the measurement system "sees" this noise or common mode voltage as the actual signal. These unwanted noise sources lead to measurement errors (see [Figure 43](#)).



**Figure 43: Common mode voltage is present when different ground potentials exist in your measurement system.**

In many applications, noise is a fact and a common occurrence. To prevent this noise from entering the signal path, the signal must be isolated on a channel-to-channel basis as well as from the PC ground reference.


Technology breakthroughs now allow channel-to-channel isolation to be accomplished effectively. Using an A/D per channel with a DC-DC converter for each A/D allows each signal input channel to be isolated from one another (see [Figure 44](#)). With this individual isolation per channel, each input channel can now “float” to its own ground reference. Separate channels are then effectively isolated from each other by the isolation barrier, up to  $\pm 500$  V for each channel. Now any noise or common mode voltage to that level is eliminated from the system measurement, allowing pristine results from each sensor without any interaction from any other sensor.



**Figure 44: An A/D per channel and a DC-to-DC converter for each A/D provides channel-to-channel isolation, where each signal can float to its own ground reference.**

Input channel return references are effectively separate instruments when the inputs are isolated. This individual isolation now allows the ground reference of each channel to measure at the level of this common mode voltage, up to  $\pm 500$  V. This capability allows some new application ideas to flourish.

Measurement of two signals, as shown in [Figure 45](#), can now have essentially 3 separate ground references: each signal input (signal 0 and signal 1) has a separate return reference; additionally, the PC has a third ground reference. This scheme can be extended for many signal inputs, such as 48 inputs in a single small measurement box, for a total of 49 different ground references.




**Figure 45: When measuring two input signals with channel-to-channel isolation, three ground references are provided (signal 0, signal 1, and PC ground).**

## New Application Derived from Isolated Channels

A typical application of measuring 48 channels of varying voltages from sensors, such as batteries, thermocouples, RTDs pressure sensors, etc., often must use different instruments because of the various ranges needed. Standard ranges of  $\pm 10$  V may handle some applications, but not others, to the required resolution and accuracy.

With isolation per channel, combinations of channels can be used to measure higher voltage ranges. [Figure 46](#) shows a configuration of 2 separate channels “ganged up” to measure a signal of up to 20 V. Normally each input would measure  $\pm 10$  V. But, by using two identical channels, a range of twice that level can be accommodated. The output readings of each A/D are then summed to give the very accurate result. This is possible because the isolation between channels allows the return of the first channel to “float up” to a level halfway between the input signal. This reflects the accurate impedance balance of each input, and the high common mode rejection of each stage.



**Figure 46:** Because each floating signal input is isolated from each other, you can use two separate channels, normally each configured for  $\pm 10\text{V}$ , to measure a  $\pm 20\text{V}$  signal. Simply sum the result of each channel to get your result.

## Summary

When you need the highest accuracy and the most flexibility from your measurement system, ensure that floating signal inputs are provided. This approach allows noise-free measurements in tough industrial settings. It also saves countless days of tracking down erroneous readings that inevitably result if these precautions are not taken from the project's beginning.

---

# Index

## A

- accessories 19
- accuracy specifications, thermocouple 108, 109
- alpha curves 111
- analog input 85
  - basic instrument specifications 106
  - calibration 90
  - channels 85
  - CJC circuit 87
  - conversion modes 92
  - data format for high voltage channels 94
  - data format for RTD channels 94
  - data format for thermocouple channels 94
  - differential configuration 43, 45
  - error conditions 94
  - filtering 93
  - input ranges 88
  - open thermocouple detection 87
  - out of range data 89, 90
  - resolution 90
  - RTD specifications 111
  - RTD types 88
  - sample clock 91
  - thermocouple specifications 107
  - thermocouple types 86
  - trigger source 91
  - wiring current loop inputs to high voltage channels 56
  - wiring current loop inputs to RTD channels 54
  - wiring current loop inputs to thermocouple channels 53
  - wiring RTD inputs 45
  - wiring thermocouple inputs 43
  - wiring voltage inputs to high voltage channels 50
  - wiring voltage inputs to RTD channels 50
  - wiring voltage inputs to thermocouple channels 49
- applet, Open Layers Control Panel 26, 101
- application wiring
  - current loop inputs to high voltage channels 56
  - current loop inputs to RTD channels 54
  - current loop inputs to thermocouple channels 53
  - digital inputs 59
  - digital outputs 60
  - RTD inputs 45
  - thermocouple inputs 43

- voltage inputs to high voltage channels 50
- voltage inputs to RTD channels 50
- voltage inputs to thermocouple channels 49
- applying power 31
- attaching the instrument to the computer 33

## B

- block diagrams 80
  - DT8871 81
  - DT8871U 80
  - DT8872 82
  - DT8873 83
  - DT8874 84

## C

- cables 33, 35
- calibration 90
- channel-to-channel isolation 97
- CJC circuit 87
- clocks, analog input 91
- cold junction compensation 87
- configuring the device driver 37
- connecting signals
  - current loop inputs to high voltage channels 56
  - current loop inputs to RTD channels 54
  - current loop inputs to thermocouple channels 53
  - digital inputs 59
  - digital outputs 60
  - RTD inputs 45
  - thermocouple inputs 43
  - voltage inputs to high voltage channels 50
  - voltage inputs to RTD channels 50
  - voltage inputs to thermocouple channels 49
- connecting to the host computer 33
  - using an expansion hub 35
- continuous analog input 92
- Control Panel applet 26, 101
- conversion modes 92
  - digital I/O 97
- conversion modes, continuous scan mode 92
- conversion rate 93
- customer service 103

## D

- data encoding 93
- data format
  - high voltage channels 94
  - RTD channels 94
  - thermocouple channels 94
- device driver 37
- differential channels 43, 45
- digital I/O
  - channel-to-channel isolation 97
  - connecting input signals 59
  - connecting output signals 60
  - lines 96, 97
  - operation modes 97
  - reading the digital input port in the analog data stream 92
  - resolution 97
  - specifications 117
  - subsystem specifications 117
- digital trigger 91

## E

- encoding data 93
- environmental specifications 118
- EP333 cable assembly 19, 58
- error conditions 94
- Excel, opening a data file 72
- external digital trigger 91

## F

- factory service 103
- features 14
- FIFO 93
- filters 93
- floating-point data 93
- formatting data
  - high voltage channels 94
  - RTD channels 94
  - thermocouple channels 94
- frequency 91

## H

- hardware features 14
- high drive digital outputs 60
- hot-swapping 33

## I

- input ranges 88
- installing the software 27
- ISO-Channel technology 123
- isolation 97
- isolation specifications 112
- IVI-COM driver 18

## L

- LEDs
  - LMT 34, 89, 90
  - OPN 34, 87, 89
  - Power 31
  - USB 34
- lines, digital I/O 96, 97
- LMT LED 34, 89, 90
- logging data to disk 71

## M

- Measure Foundry 18
- Measurement Application 18
  - configuring 67
  - defining alarm limits 69
  - exiting 75
  - features 63
  - logging data to disk 71
  - opening a data file in Excel 72
  - reading the digital input lines 74
  - running 64
  - updating the digital output lines 70
  - using the Chart Recorder 71
  - viewing a data file 73
- Measurement Calibration Utility 18
- mechanical relays, controlling 60
- memory specifications 113
- moving average filter 93

## O

- Open Layers Control Panel applet 26, 101
- open thermocouple detection 87
- operation modes
  - continuous scan mode 92
  - digital I/O 97
- OPN LED 34, 87, 89
- opto-isolators 96
- out of range data
  - high voltage channels 90

RTD channels 90  
thermocouple channels 89

## P

physical specifications 118  
power  
  applying 31  
  specifications 118  
Power LED 31  
protection specifications 112

## R

rack mounting 19  
raw filter 93  
recommendations for wiring 41  
recording data 71  
regulatory specifications 119  
requirements 26  
resolution  
  analog input 90  
  digital I/O 97  
returning instruments to the factory 103  
RMA 103  
RTD alpha curves 111  
RTD channels 88  
  data format 94  
RTD connections  
  2-wire 47  
  3-wire 46  
  4-wire 46  
RTD connector specifications 120  
RTD specifications 111  
RTD types 88

## S

sample clock 91  
sample rate 93  
SENSOR\_IS\_OPEN 88  
software packages 18  
software trigger 91  
solid-state relays 97  
  controlling 60  
sourcing 60  
specifications 105, 121  
  basic instrument 106  
  digital I/O 117  
  environmental 118  
  isolation and protection 112

memory 113  
physical 118  
power 118  
regulatory 119  
RTD 111  
RTD connectors 120  
system temperature error 108, 109  
temperature stability 114  
thermocouple 107  
thermocouple connectors 120  
voltage connectors 120  
voltage measurement 115  
STP37 screw terminal panel 19, 58  
system requirements 26  
system temperature error 108, 109

## T

technical support 102  
temperature error 108, 109  
temperature stability specifications 114  
thermocouple accuracy specifications 108, 109  
thermocouple channels 86  
  data format 94  
thermocouple connector specifications 120  
thermocouple types 86  
trigger source 91  
  external 91  
  software 91  
troubleshooting  
  procedure 100  
  technical support 102  
  troubleshooting table 100

## U

unpacking 25  
USB cable 33, 35  
USB LED 34

## V

voltage connector specifications 120  
voltage measurement specifications 115

## W

warm-up time 42  
wiring signals  
  current loop inputs to high voltage channels 56  
  current loop inputs to RTD channels 54

current loop inputs to thermocouple channels [53](#)  
digital inputs [59](#)  
digital outputs [60](#)  
recommendations [41](#)  
RTD inputs [45](#)  
thermocouple inputs [43](#)  
voltage inputs to high voltage channels [50](#)  
voltage inputs to RTD channels [50](#)  
voltage inputs to thermocouple channels [49](#)  
warm-up time [42](#)